

Starfish PPS Complete Catalog Updated May 6, 2024

Contact:
Marc Webb
903-245-4684
marc.webb@starfishpps.com

Part Number	Description
0004-2500-770	Gasket
0004-3003-830	Sealing ring
0004-3004-830	Sealing ring
0007-2573-750	Gasket
0007-2608-750	Gasket
0011-6208-000	Grooved ball bearing
0013-3137-060	Collar nut
0019-6202-150	Allen screw
0026-1659-000	Centering disk
0026-5682-170	Fan-type lock washer
0026-5871-170	Retaining ring
003015G27-001	SHAFT
00355V195-001	PIN
0038-0035-096	Coupling
0038-0056-096	Coupling
0038-9098-096	Coupling
00380035096	Coupling
00380056096	Coupling
00389098096	Coupling
004-304661-008	HEATER
004-304661-012	Heater
004120J33G0001	OIL DEFLECTOR
005418-003	TRANSMITTER
00638A386-004	GASKET
00647A857-001	GASKET
00655A770-010	O-Ring
00655A770-014	O-RING
00655A770-115	O Ring
00655A770-124	O-RING
00655A770-126	O Ring
00655A770-132	O-RING
00655A770-135	O-RING
00655A770-214	O Ring
00655A770-216	O Ring
00655A770-236	O-RING
00655A770-242	O-RING
00655A770-244	O RING
006607-018	Detector, gas transmitter
006748-002	Transmitter, combustible gas
006748-006	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
006748-008	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
006817-001	Board, PC, 505, 125OHM
006817-002	Board, PC, 505, 500OHM

Starfish PPS - Complete Catalog

Part Number	Description
006824-001	SENSOR, GAS
006824-002	SENSOR, GAS
006824-003	SENSOR, GAS
006824-004	SENSOR, GAS
006824-005	Gas Sensor
00705-A-1735	Sensor
007168-001	Detector, Gas
007168-014	PIRECL Infrared Hydrocarbon Gas Detector
007168-205	Gas Detector
007290-001	Flame Sensor Mounting Arm
007371-003	MODULE, DCIO, DIN RAIL
007800-011	KIT, SOFTWARE
0078N21N00N050C5	Temperature Sensor
0078N25N00N020E6B3	SENSOR, SPRING LOADED TEMP
0078R2500A020T32	RTD Rosemount
0078R25N00A020	RTD, Dual Platinum
0078R25N00A025T38KF	RTD
0078R25N00A120T22E5	RTD, Dual
008700-006	Flame Sensor
00870B450-001	RETAINER DU
008716-001	SENSOR, FLAME
009174-003	MODULE, EDIO
009700-001	TOOL, MAGNETIC
01-441-071	Bearing
010252-003	DISPLAY, RELAY
010254-005	DISPLAY, DCU
010254-006	DISPLAY, DCU
010535-001	MODULE, DISPLAY, UD10, EQP-DCU
010569-001	MODULE, DISPLAY, UD10, RELAY/4-20mA
0105C7213G3	MECHANISM
01066J70P0001	PLATE, LOCK
010765-006	Transmitter, DCU
01078J88P0001	Bolt
010973-001	REPLACEMENT BOARD
01104-TC-335	Thermocouple, Wheelspace
01141J37P0018	SPRING, PACKING
0116B6708G3B	Lamp, Blue Lens
0116B6708G3E	Indicating Lamp, Red Lens
01184J49P0001	SCREW,SET
0137B729P0001	Bushing
014394-001	Combustible Gas Transmitter
0154HN-1	SENSOR, P2/T2
018713194	Thread Lock
02028J49P0001	Heater, Strip
02101SP001	Speed Probe
021189157	Disk Spring
021189267	Disk Spring
02122J34P0001	Plug
02122J37P0001	Plug
021815109	Cap head screw
021815168	Cap Hd screw

Starfish PPS - Complete Catalog

Part Number	Description
021815169	Cap Hd screw
021815172	Cap Hd screw
021844065	Screw
0247A390P0008	PLATE, LOCK
024907	WASHER, TAB (M20)
025564632	Connector, male, straight, 1/2"
025564633	Connector, male, straight, 3/4"
025566381	Conduit, elbow, LR17
0263X0592G009	ASSEMBLY: SWITCH, AUX, W/ MECHANISM
0269A369034R	PHILA AUXILIARY SWITCH STATIONARY
0269A369034T	PHILA AUXILIARY SWITCH STATIONARY
028100-034	DETECTOR, FLAME
028247-001	DETECTOR, FLAME
028247-034	DETECTOR, FLAME
0282A2009G002	Coil, Electrical
0282A2009G008	Coil, Electrical
0291A6820AAP072	MODULE, COMBO, ANALOG
0291A6820AAP073	MODULE, INPUT, DIGITAL
0291A6820AAP074	MODULE, OUTPUT, RELAY
0291A6820ACP007	CONTROLLER, HIGH SPEED
0291A6820ACP008	BASE, 12 SLOT
03031-0189-0003	KIT, MOUNTING, 3051
030G10A8	GASKET, RING
031G10A6	GASKET, RING
031G10A8	GASKET, RING
0356C317G0002	Seal, Deflector
0360-02-00-0150	GASKET
0360-03-00-0150	GASKET
03666789P0006	PLATE, ., LOCK, 1-1/4" WD X 4" LG X 1/16" THK, STEEL
03666789P0007	LOCKPLATE
0391-00-004	O-RING
0391-00-038	O Ring
0391-00-136-T	O RING, HILLIARD
0391-00-170-T	O-RING
0391-00-399-T	O-RING
04-00059	Sensor, RPT VSR100 / VSR175
04-00209	Board, Temperature Sensor, VSR100 / VSR175
04-060-00	PH PROBE
0405-03-007-T	SCREW, HILLIARD
04089J46P0056	THERMOCOUPLE, CASING
04110J75P0047	Thermocouple
0432B515P0004	Valve
0432B570P0001	PISTON
0437B524P0001	VALVE
05-00020	Buss Bar, Laminated - VSR175
05-00030	PCB, DISPLAY, W/O FACIA (PCB42)
05-00105	Board, Flashing LED, VSR100 / VSR175
05-00207	CONTROL BOARD(PCB94), VSR100 / VSR175, M2
05-00213	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175

Starfish PPS - Complete Catalog

Part Number	Description
05343739P0002	RING, PISTON, 9-1/2"ID X 10-1/4"OD X 1/2"THK, BRONZE
05PV50CDRX-22CCCXX01	Breaker
060-1083-11-07	Transducer, Pressure, 0-1000PSIG
060-308-154	Pump, Lube and Scavenge
0631A539P0001	Spring
0632A933P0005	Ring
0636A369P0002	Gasket
0638A528P0001	Bushing
0647A136P0002	Bearing
0649A219P0001	Spring
0652L277G0010	Seal, Hydrogen, Turbine End, Set
0657603	GEARBOX, ROTOJET
0657604	GEARBOX, ROTOJET
0657605	GEARBOX, ROTOJET
0657606	GEARBOX, ROTOJET
06658978P0001	Spring
0685C0810G004	Elevating Motor, 120VAC/125VDC
0719A318P0007	LOCK PLATE
0719A679P0022	LOCK PLATE
0728C775P0002	Gasket
0731B820P0002	Bearing
075528-2733	SET, BALANCED FASTENER
075528-2929	PT Coupling Fastener Kit
075528-2990	BALANCED FASTENER SET
0771A136P0326	SCREW, MOUNTING
0776654	Kit, Seal
0789E879G0002	Oil Deflector
0789E891G0001	Oil Deflector
08-00002	IGBT DF200R12KE3 VSR100 / VSR175
08-00003	IGBT FD200R12KE3 VSR100 / VSR175
08-00040	Thyristor, Diode Module, VSR
08-00041	Thyristor, Diode Module
08-00114	IGBT VSR100 / VSR175
08-00115	IGBT VSR100 / VSR175
08501375-42	Thermocouple,
0870B672P0001	BUSHING, STEAM SEAL REGULATOR
09-00002	CAPACITOR .47UF 1200V for VSR100 / VSR175
09-00023	Capacitor, Fan VSR100 / VSR 175
09-00031	CAPACITOR 3300UF 400V VSR100 / VSR175
0930B432P0005	Valve Seat
09449090P0004	LUG,CENTERING
0946	SEAL
0950-00-028-T	SPRING, STAINLESS
0951-04-022-A	PAD, SEALING
1 1/2CFRJ13002F	THERMO VALVE
1 1/2CFSJ10002	Thermo Valve
1 1/2CFSJ11002	Thermo Valve
1 1/2CFSJ14002	Thermo Valve
1"CPT4466TSEA.125	Valve, Control
1-024553	Gasket, Cylinder Cover
1-640-01-3012	Aluminum Plate

Starfish PPS - Complete Catalog

Part Number	Description
1.2X2.6X100M	Basket, Strainer
1.2X2.6X100m	Basket, Strainer
1.5F2JLTJOS-EOR15S6A	Relief Valve
1/2INCH-S2000	Valve, Ball, Stainless
1/4P48	NOZZLE, FOG, AMMONIA
10-0551-1-135-200	Thermocouple, Wheelspace
10-0551-2-330-200	Thermocouple, Wheelspace
10-0551-2-332-200	THERMOCOUPLE, WHEELSPACE
10-0551-2-333-200	THERMOCOUPLE, WHEELSPACE
10-0551-2-335-200	Thermocouple, Wheelspace
10-0551-2-336-200	THERMOCOUPLE, WHEELSPACE
10-0551-2-337-200	Thermocouple, Wheelspace
10-0551-4-672-200	Thermocouple, Wheelspace
10-0589-001-200	Thermocouple, Exhaust
10-0620-012	THERMOCOUPLE, WHEELSPACE
10-0639-001-210	THERMOCOUPLE
10-0639-002-210	Thermocouple, Wheel Space
10-0639-004-210	Thermocouple, Wheel Space
10-0651-005-210	THERMOCOUPLE, WHEELSPACE
10-0879-001	THERMOCOUPLE, WHEELSPACE
10-1094-022-200	Thermocouple, Exhaust
10-1094-022-200-AR	THERMOCOUPLE, AS REMOVED
10-1578-001-210	Thermocouple, Immersion, EGT
10-2859-031-210	Thermocouple
10-319987	Insulator, Tube, Ceramic, Unison
10-3634-022-210	Thermocouple, Exhaust
10-3634-022-210-AR	THERMOCOUPLE, AS REMOVED
10-392775-4	Exciter, Ignition
10-392775-5	Exciter, Ignition
10-630225-1	PLUG, IGNITER
100-DA	Diaphragm Kit
1000208778	GASKET, FLANGE, FUEL NOZZLE, 1IN, 600LB
1000600	Strainer
10014-005	KIT, REPLACEMENT PARTS
1007-3-14	T3 Sensor
100P44C6NR	Switch, Pressure, Adj.
100P44C6R	Switch, Pressure, Adj.
100P47C6B	SWITCH, PRESSURE
100P4S1548-056	Switch, Pressure
100P4S1548-066	Switch, Pressure
100TC5DC6NR	Switch, Temperature
100TC5DC6R	SWITCH, TEMPERATURE
100TC5DCC6NR15	SWITCH, TEMPERATURE, ADJUSTABLE
100TC5DCC6R15	SWITCH, TEMPERATURE, ADJUSTABLE
100TC5FC6R	SWITCH, TEMPERATURE
101-2103	Weatherstripping, window, 50' roll
101109	Aerokroil
1011D-100	BODY, EX PACK
10150194	RELAY, DPDT
1015612	Plug, Valve, 4"
10170011	Switch, Pressure
1018363	Gasket

Starfish PPS - Complete Catalog

Part Number	Description
101A293AR-14	Relief Diaphragm
101A362BK-2601	GASKET, SPIRAL WOUND, GRAPHITE FILL, 3/16" THK,
101A636AF-1	BOLT, , 1" DIA, 3-1/4" LTH, 8UN, BRONZE ALLOY, HEX H
101A743CR-1	PIN, DOWEL, 1/4" DIA, 3/4" LTH, FERROUS METAL
101A750FA-1	GASKET, ., OIL FILTER, 8"ID X 8-3/4"OD, RUBBER, ROU
	SINGLE
101A782AD-102	GASKET, SPIRAL WOUND, , PIPE, 2500LB, 2-1/32"ID X 2-
	GRAPHITE FILL, 0.175" THK, SS, ROUND
101T6097P0002	Pin
101T6358P004	Valve, 8" Butterfly, Left
102147	SURGE PROTECTOR 12A12
1027-1-11	RTD, Detector, Resistance Immersion
1027-2-12	RTD, Detector, Resistance Immersion
102T8993P002	Valve, Gas Fuel Control
103M2215P0006	LINKNET-HT, MODULE
103M2719P0001	Driver, Woodward
103M2719P0002	DIGITAL VALVE POSITIONER, 125VDC, IP30
104C1150P001	Bearing, Turnbuckle
104T3771P001	VALVE, CHECK
104X109AD109	FUSE, 2AG, 1.5A, 250 V
104X123DE 016	Resistor
104X123DE016	Resistor
104X125AA175	DIODE
1053V3	Valve, Globe
105PP1S904	SWITCH, PRESSURE
1066-C-HT-69	Analytical
	1066 Liquid Analytical Transmitter
106765-07	CABLE VELOMITOR XA
106M1079-01	MODULE, POWER SUPPLY, AC
106M1081-01	MODULE, POWER INPUT, AC
107C6638P0063	SHIM PLATE, THRUST BRG TURBINE END
107C6638P0064	SHIM PLATE, THRUST BRG GENERATOR END
1080274	Cable - Exciter, Left Spark Ignition
1080275	Cable - Exciter, Right Spark Ignition
1081194	Seal, T/C
1081669	Valve, Check
1081670	Valve, Check
1081873	Wire Harness Assembly, N1 Sensor
1081976	Hose
1081978	Hose
1081981	Hose
1082126	Thermocouple, Immersion, EGT
1083362	Igniter, plug
1084936	Harness, FT8, Engine, Left
1084939	FILTER, HYDRAULIC PUMP
1084940	Clutch
1084947	HYDRAULIC SERVO VALVE
1085280	Bolt, Coupling
1085281	Nut
1085282	Washer, Insulating
1085283	Washer
1085415	Locknut
1085457	Bolt, Coupling

Starfish PPS - Complete Catalog

Part Number	Description
1085998	Transducer (N3) - Motional Speed
1087MKS-1BLONG	Strut, flow enhancer
1087MKS-1GMEDIUM	Strut, flow enhancer
1087MKS-1MSHORT	Strut, flow enhancer
1088025	Valve, Flow Divider
1088046	Speed Probe
1088177	Igniter, plug
109B4683G001	7E COMPRESSOR BOLT SET
109E3763G005	PROBE, FLEX, 3300 XL 8MM
109E3763G006	Cable, Proximitor
109E3763P201	Vibration Probe
109E3763P300	Key Phaser or Vib Probe
109E3763P500	Probe
109E3763P502	3300 XL 8MM
109E3763P600	Cable, Proximity
109E3763P602	Cable, Proximitor
109E3763P610	Probe
109E3763P700	3300 XL 8mm Proximitor Sensor
109E3763P702	3300 XL 5/8mm Proximitor Sensor
109E3763P703	3300 XL 5/8mm Proximitor Sensor
109E3763P809	Booster, LMS100
109E3763P812	Probe
109E3763P813	Probe
109E3763P952	Probe
109E3763P953	Probe
109E6646G0001	Heater, Strip
109E9348G006	SPARK PLUG, BALL JOINT
10AX002G0006	SWITCH
10AX002G10	PHILA AUXILIARY SWITCH STATIONARY
10AX002G3	PHILA AUXILIARY SWITCH STATIONARY
10F10M511M201	SWITCH, PRESSURE
10P053	Valve, Balance
10SV17NC10	PUMP/MOTOR
110181-14	CLOSURE
110181-16	CLOSURE
110909A	Aerokroil
110C1032G1	SE-Breaker Operator Sub-Asm
110P12C6B	Switch, Pressure
1112SD	SNUBBER, PRESSURE
112P12C6B	Switch, Pressure, 10"-120"
112T1672P0001	RELAY: VARIOUS 518L01-1 PILOT OPERATED DIRECTIONAL
11300216	Yarway SAS BOA , PCB
11305	Pump Repair Kit
113T1089P0005	CABLE, RTD, J2 Bearing Temp
1141J37PT23	SPRING
114A3517P001	Valve Seat
114A6734P004	PLATE, LOCK
114A6734P007	Lock Plate
114CE0025TAB1SC017AXW	Thermowell

Starfish PPS - Complete Catalog

Part Number	Description
114CE0120TAB3SC032AXW	Thermowell
114E6078G0002	DEFLECTOR, OIL, OUTER
1150556	Turning Tool Adapter
115436-1	Hose, Flexible
115762	Hose, Convaluted
115763	Hose, Convaluted
115764	TUBE & HOSE, CONVOLUTED
1157M31P01	Bolt
115T8956P0001	GASKET
115X108.9X1.5	RING, BACKUP, FILTER HOUSING
116B6708G3	LAMP, INDICATING
118-78-00225484	HEATER
118D6753P009	Gasket
11A1AB4M5Q4	Transmitter
12 AWG XHHW	12 AWG XHHW SINGLE STRAND
12 AWWG XHHW	12 AWG XHHW SINGLE STRAND
12-00061	Transformer, Current - VSR100 / VSR175
12-00062	EM Filter
12-00083	Fan, Main Cooling, VSR175
1201-T1037	
120E8112G0001	Oil Deflector
1211245-26	Actuator, VSV
1211425-002	ACTUATOR, VSV
1211425-002-OH	VSV Actuator
1211425-003	Actuator
1211425-003-OH	ACTUATOR, OVERHAULED
1211425-006	Actuator
1211425-007	Actuator
1211426-007	Actuator
1211427-007	Actuator
121T4154P0001	Exciter
122732-002	Insulator
122809-001	O-Ring
122P82C6413NR	Switch, Pressure
122P84C6413NR	SWITCH, PRESSURE
122P84C6NR413	SWITCH, PRESSURE
122P84C6NR443	SWITCH, PRESSURE
122P87CC6443	SWITCH, PRESSURE
123765-03-80	Filter, Fuel
124T5712P0001	FLAME TRACKER
124T7623P2002	Valve
124T7741G0002	SCANNER, FLAME, DRY, DETECTOR, KIT
125680-01	MODULE, I/O
125720-01	MODULE, OUTPUT, 4-CHANNEL RELAY
125736-01	MODULE, I/O
125744-01	MODULE, RACK INTERFACE, TMR
125744-02	MODULE, RACK INTERFACE, STANDARD
125760-01	MODULE, I/O
125768-01	MODULE, I/O
125792-01	MODULE, ENHANCED KEYPHASOR
125800-01	MODULE, I/O
125800-02	MODULE, I/O

Starfish PPS - Complete Catalog

Part Number	Description
125808-01	BLOCK, PROXIMITOR ET, EURO STYLE
125808-02	BLOCK, PROXIMITOR ET, EURO STYLE
125808-03	BLOCK, EXTERNAL TERMINATION
125808-05	Term Block
125808-08	Term Block
125840-01	MODULE, POWER INPUT
125840-02	MODULE, POWER INPUT
125D441AA-1	FILTER, OIL, 11"LG, 25 MICRON, SS MESH
126599-01	MODULE, I/O
126615-01	MODULE, I/O
126623-01	MODULE, I/O
126632-01	MODULE, I/O
126640-01	MODULE, I/O
126648-01	MODULE, I/O
126648-02	MODULE, I/O
126957-01F	RACK, 3500, BENTLY NEVADA
127610-01	POWER SUPPLY, AC
1279-00-040-T	Retaining Ring
128015-01	BLOCK, PROXIMITOR ET, TERM STRIP
128229-01	MODULE, I/O
128240-01	MODULE, I/O
12833	RING, SEAL
128702-01	BLOCK, EXTERNAL TERMINATION
128718-01	BLOCK, EXT TERM, KEYPHASOR, EURO STYLE
128726-01	BLOCK, EXT TERM, KEYPHASOR, TERM STRIP
1288M66P04	STRIP, SEAL
128C306AA-1	VALVE, TURBINE BOILER FEED PUMP, 1-15/16" ID X 4" THRD, STEEL, NON-ASBESTOS
1293	Shunt 500A/50mV
12943	Seal
129478-01	MODULE, POWER INPUT
129486-01	POWER SUPPLY, HIGH VOLTAGE DC
1294M38P01	GASKET
1294M38P02	Gasket
129525-0005-02	Cable
129525-0010-02	Cable
129529-0005-02	Cable, Bently
129530-0005-02	Cable, Bently
129530-0025-02	Cable, Bently
129595-0010-02	CABLE, B NEVADA
129715-138-040-05-05	PROBE, FLEX, 3300 XL 8MM
129957-085-057-05	Cable, Proximity
12A-F12L-50-BN-SS	Filter Valve
12A-F12L50-BN-SS	Filter Valve
12A-F16L-50-BN-SS	Valve, Check
12A-F16L50-BN-SS	Valve, Check
12B01ATS	Flame Sensor
12VF12-SS	QUICK COUPLING
1300R010 ON/-V-B6	FILTER, ELEMENT
1300R025 W/HC/-V	O-RING
1303M20P01	Pressure Probe
1303M20P02	Pressure Probe

Starfish PPS - Complete Catalog

Part Number	Description
130419-0025-02	CABLE, BENTLY
1304M52G03	Plug, Borescope, S2
1304M52G04	Plug, Borescope, S2
130539-20	Cable
130539-50	Cable
1311-1006	VALVE, SOLENOID
1311-917	Valve, Solenoid
1311-933	Valve, Solenoid
1311-933-AR	VALVE, SOLENOID
131151-01	Cable, Bently
131178-01	Cable, Bently
13220-1406	VALVE, SOLENOID,
1326-8002	FILTER, HYDRAULIC, CARTRIDGE
1327-202	FILTER
1327-204	FILTER
132B7791G001	PIPING, PURGE AIR, 0909
132B7792G001	PIPING, PURGE AIR, 0909
132P41C6B	Switch, Pressure, Adj (Neo-Dyn)
132P41C6BNR	SWITCH, PRESSURE, ADJ
132P42C6BR	SWITCH, PRESSURE
132P44C6B	SWITCH, PRESSURE
132P44C6BNR	Switch, pressure
132P44C6BR	SWITCH, PRESSURE
132P46C6BNR	SWITCH, PRESSURE
132P46CC6BNR	switch, pressure
132P48C3R	SWITCH, PRESSURE
132P48C6BNR	Switch, Pressure, Adj.
132P48C6BR	SWITCH, PRESSURE
132P48CC3R	SWITCH, PRESSURE
132P48CC6BNR	Switch, pressure
132P49C6B	SWITCH, PRESSURE
132P49C6BNR	SWITCH, PRESSURE
132P4S129	Pressure Switch
132P4S185	SWITCH, PRESSURE
132P4S408-001	Pressure Switch
132P4S408-003	Pressure Switch
132P4S408-007	Pressure Switch
132P4S408-008	Pressure Switch
132P4S408-009	Pressure Switch
132P4S408-102	Switch, Pressure
132P4S408-121	Switch, Pressure
132P4S408-123	Switch, Pressure
132P4S429	Pressure Switch
132T4FC6	SWITCH, TEMPERATURE
132T4FC6HNR	SWITCH, TEMPERATURE, ADJUSTABLE
132T4FC6NR	SWITCH, TEMPERATURE
132T4HC6	SWITCH, TEMPERATURE
133292-01	POWER SUPPLY, LOW VOLTAGE DC
133300-01	MODULE, POWER INPUT
133323-01	MODULE, I/O
1333M60P01	Spacer
1333M60P02	Guide

Starfish PPS - Complete Catalog

Part Number	Description
1333M67P01	BEARING, ACTUATOR
1333M68P01	BEARING, SLOT LOADED, ACTUATOR, COMPRESSOR
1333M69P01	Bearing, rod end
1336M28P01	Bearing, Rod End
1337M46P03	Washer
133A1624P15	WASHER
133A1624P36	Washer
133A1624P37	Washer
133A1624P40	Washer
133A1624P48	Washer; 1/2
133A1624P6	Washer
133A1624P64	Washer
133A1624P67	WASHER
133A1624P7	Washer
1340M24P02	BOOT, DUST AND MOISTURE SEAL
1345M58G40	CLAMP
1347M18P01	BOLT
134T7506P0001	Adapter
134T8027P0001	Motor, Electric
1350-5027	Servo, LPC-IGV
1350-5274	Servo Valve
135031-01	MODULE, I/O
135473-01	MODULE, I/O
135489-01	MODULE, I/O
135489-02	MODULE, I/O
135489-03	MODULE, I/O
135489-04	MODULE, I/O
1355-111	O Ring
1355-169	O Ring
1355-423	Seal, Gas
135T5408P0001	Pump, Jacking
136180-01	MODULE, COMMUNICATION GATEWAY
136188-01	MODULE, I/O
136188-02	MODULE, I/O
137A3516P001	Hose, Flexible Metal
137A3516P002	Hose, Flexible Metal
137A3516P003	Hose, Flexible Metal
137A3518P003	Hose
137A4662P001	Thermocouple
137A4662P002	Thermocouple
137A4662P003	Thermocouple
137A4662P004	Thermocouple
137A4662P005	Thermocouple
137A4662P006	Thermocouple
137A4662P011	Thermocouple
137A4662P012	Thermocouple
137A4662P021	Thermocouple
137A4662P022	Thermocouple
137A4662P031	Thermocouple
137B729P0001	Bushing
137D2440P0001	Flushing Valve
138131-A010	CABLE, BENTLY, 10FT

Starfish PPS - Complete Catalog

Part Number	Description
138607-01	MODULE, STANDARD TRANSIENT DATA INTERFACE
138607-02	MODULE, TMR TRANSIENT DATA INTERFACE
138700-01	MODULE, I/O
138708-01	MODULE, I/O
138C9173G003	DEFLECTOR, OIL
1390-607	GASKET, 2" PIPE, ANSI FLANGE, SPIRAL WOUND
139299-001	LED Indicator
139E7771G005	Fuel Nozzle Tip
139T5765P0009	VALVE, BUTTERFLY, 8IN
14-412570-1-1-FSHEAVE	SHAFT, FAN, W/ BUSHING
140-152	TRANSFORMER, CURRENT
140-252	TRANSFORMER, CURRENT
140-302	TRANSFORMER, CURRENT
140-402	TRANSFORMER, CURRENT
140-SD-38548	TRANSFORMER, POWER
140100-110	O Ring
140471-01	MODULE, I/O
140471-02	MODULE, I/O
140482-01	MODULE, I/O
140482-02	MODULE, I/O
140734-02	MONITOR, PROX/SEISMIC
140734-03	MONITOR, AERODERIVATIVE
140734-05	MONITOR, DYNAMIC PRESSURE
141-152	TRANSFORMER, CURRENT
141-302	TRANSFORMER, CURRENT: 3000:5
141-402	TRANSFORMER, CURRENT
141A7363P0001	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
141A7364P0001	ASSEMBLY: MODULE, AERODERIVATIVE
141A7371P0001	PREFILTER, AIR
141A7377P0001	Valve, Fuel
141A8859P0001	VALVE, VENT, FUEL SYSTEM, DLE - 15 PPM
141A8869P0001	ASSEMBLY: DETECTOR, GAS, COMBUSTIBLE
141A8877P0001	T10 POWER SYSTEM STABILIZER
1420050949	O Ring
142C5824P0001	SHIM
142I-SD-14684	TRANSFORMER, POWER
142I-SD-14684MA	TRANSFORMER, POWER
142P82C6NR413	Switch, Pressure
142P8S34	SWITCH, PRESSURE
143-103-000-532	Sensor, Dynamic
143-106-000-011	SENSOR, ACOUSTIC
143-106-000-111	SENSOR, ACOUSTIC
143-106-000-121	SENSOR, ACOUSTIC
143A6072P0001	PIN, ., VALVE, LOWER STEM NUT, 3/8" DIA, 4-1/2" LTH, F METAL
143B2775P002	Nozzle Pin
143B2775P003	Nozzle Pin
143B2775P2	PIN, NOZZLE
143B280G0004	Nozzle, Fuel, Cap
143B3045G003	DEFLECTOR, AIR
143D7407G004	Bull Horn
144-303-000-221	Accelerometer

Starfish PPS - Complete Catalog

Part Number	Description
144-303-000-311	Accelerometer
1442861	Cable
145193-01	3300 XL 5/8mm Proximity Sensor
14590A	TEST MATCH
145E1156L0001	KIT, HARDWARE
145E3639L0001	CABLE, TERMINAL BLOCK, KIT
146031-01	MODULE, I/O
146032-01	MODULE, I/O
146564001	Stami Temperature Guage
147-802	TRANSFORMER, CURRENT
1473M46P03	Ring
1473M46P04	Ring
1474M24G01	BRACKET, LPT
1474M32G01	Bolt, Shear
1474M32G02	Bolt, Shear
148654-01	HMI, BENTLY NEVADA
1487589-1	Cable, Bently
149369-01	MODULE, ENHANCED KEYPHASOR
149716-01	MODULE, I/O
149986-02	MODULE, CONTROL, 4-CHANNEL RELAY
1499M88P02	SPACER
149M1613P0001	EX2100, DSPX/EISB Assembly
149M1684P0001	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVle
149M1691P0001	RESISTOR
15-5CAVH0-5E	FUSE, 80000 AMP
15.5CAVH1E	FUSE 15.5 KV
1502DG-4A-4.5F	GAUGE, DIFFERENTIAL, 0-30
1506M44P08	NUT, SELF-LOCKING, HEX
1509M85P04	NUT, SELF-LOCKING DOUBLE HEXAGON
151X1202EAP04	DTBS MKVIE CARD INSULATOR
151X1202XJP03	Support Bracket, 3-I/O Pack, 12"
151X1202YE03SA04	BRACKET, 4IN S-CARD, DIN MOUNT
151X1202YE04PP05	COVER, 7-INCH S-CARD, DIN MOUNT
151X1207BB31S	EX2100, DSPX/EISB Assembly
151X1207BD01WK09A	Cable
151X1207CK02SA12	MODULE, DE-EXCITATION 77mm
151X1207DA01WK02	Cable, Excitation
151X1213BP03PC02	CAPACITOR, 350V
151X1213BP06PC01	DIODE, BEARING
151X1213PE07SA01	ECTB / EPCT CARD ASSY
151X1215DG02SA52	Blower Assembly
151X1215DG60SA51	Blower Assembly
151X1219DC20SA13	FAN
151X1224GAP0001	FAN,24VDC W/STAB CONNECTIONS
151X1225	Cable
151X1225BE12WK01	Cable
151X1235BE04SA03	ESys Module (Simplex)
151X1235DB15SA01	EX2100e, Power Bridge Assy.
151X1235DB15SA03	PCM Assembly, EX2100e, 35A, with ERSE
151X1235DG06SA01	BLOWER MODULE 115V
151X1235DG06SA03	Blower Assy, 115V, Drawer Type

Starfish PPS - Complete Catalog

Part Number	Description
151X1235MT01WK03	ASSEMBLY, THERMISTOR, 3 FEET
151X1235RM10SA01	REGULATOR PCM
151X1235RM10SA03	REGULATOR PCM
151X1236LTSA01	TERMINAL
151x1235be12wk01	
152P82CC3418	SWITCH, PRESSURE
1538M42P01	Gasket
1540M69P09	Cushioned Clamp
1540M69P206	CLAMP, ENGINE CABLE
1540M69P207	Clamp
1540M69P310	Cushioned Clamp
155-305998-112	HEATER
1554M38P01	Gasket
155D7946P0015	BOLT,HEX HEAD
156-700401-275	Heater
156-700401-276	HEATER
156-700401-472	HEATER
156A1076P013	UNION
156A1591P018	STUD: TURBINE,TYPE BODY BOUND,DIAMETER 1.5 IN, TPI,THREAD LENGTH 2.5 IN,LENGTH 11.1 IN,MATERIAL
15830-1061A	Valve, Solenoid
15830-1061D	Valve, Solenoid
15830-1596A	VALVE, SOL
158A7444P001	Thermoswitch
158A7444P002	Thermoswitch
159A840	Seal
159C6704G02	Fan Blade
160P44C6	SWITCH, DIFFERENTIAL PRESSURE, ADJUSTABLE
160P44C6BRS	SWITCH, PRESSURE
160P46C6BNR	TLO Filters Differential Pressure Switch
160P46CC6B	SWITCH, PRESSURE
160P4S36	Adj. Diff. Pressure Switch
160P4S43	SWITCH, PRESSURE
1611-003	PSM-ME-RS232/RS485
161204-01	MODULE, EGD GATEWAY
161216-01	MODULE, I/O
161216-02	MODULE, I/O
1622M24P01	Plug, Borescope
162P42C6BHR	Switch, Press., Adj., Diff.
162P42C6BNR	Switch, Press., Adj., Diff.
163C4108G006	SEAL,STA,AIR-#2
163C4796G006	SEAL, AIR
163C4798G001	SEAL, OIL
163C4799G001	SEAL, BEARING
1640-00002	Kit, Clamshell
1642M98G01	VALVE, CHECK, AIR
1646M48P11	Nut
164871-01	Term Block
164877-01	Block, External Termination
164883-01	Block, Term
164C2354G001	PUMP
165858-01	Block, External Termination

Starfish PPS - Complete Catalog

Part Number	Description
165A159CD	BFP Turbine Thrust Shoes, Set
165A3856P0002	GASKET, ., VALVE, 7-5/16"1D X 10-1/2"OD, GARLOCK 30
1689-1112	ROUND, .256" THK, S1NGLE
169459-01	Sensor, Temp, VBV accumulator
169459-02	MODULE, I/O
1696M81P13	MODULE, I/O
1697M73P02	T/C; T48
1700R12ABAEZZZ	Wire, Retaining
1702169	TRANSMITTER
1704M61P03	Plastic Frame Pre-Filter, M5,w/o downstream gasket
1704M62P05	Sleeve
1704M63G07	WASHER
1704M63G08	ARM
1704M63G09	ARM
1704M63G10	ARM
1704M63G15	ARM
1704M63G16	ARM
1711-1047	Switch, Prox
172C9091P003	Seal, Dogbone Shroud
1730D24001	Igniter
1730D24P001	Igniter
1738D57G01	IGNITOR, ASSEMBLY
173C8443AKG04	SCR ASSEMBLY EX2000
173C9123BB003	ASSEMBLY,TERMINATION BLOCK
173C9123BB004	ASSEMBLY,TERMINATION BLOCK
1743155	desc check filter
1746-NI8	MODULE, INPUT, ANALOG, 8 CH
1746-NR8	MODULE, INPUT, RTD, 8 CH
1751-147	MODULE
1751-6058	Module, Transformer
1751-6091	MODULE, 16 CHAN
1756-IRT8I	THERMOCOUPLE, RTD, CONTROL LOGIX
1756-OF4	MODULE, 4 PT A/O, I OR V
1756-PB75R	POWER SUPPLY, CONTROL LOGIX, REDUNDANT
1756IB16I	MODULE, 30VDC INPUT
1761864	Filter
176449-01	MONITOR, PROXIMITOR
176449-02	MONITOR, PROX/SEISMIC
176449-03	MONITOR, AERODERIVATIVE
176449-05	MONITOR, DYNAMIC PRESSURE
176A13/M005RL	Sensor, Dynamic
176B2050P0002	GASKET, PRESSURE SEAL HEAD
1771-ASB	Remote I/O Adapter Module
1771-CT	I/O Chassis Cable
1771-DB	BASIC Module
1771-IBD	DC (10-30V) Input Module
1771-IL	MODULE, ISOLATED ANALOG INPUT
1771-IR	MODULE, INPUT, RESISTANCE TEMP DETECTOR
1771-OB	MODULE, OUTPUT, 10 TO 60 VDC
1771-P5	Power Supply Module
1774M59P01	Gasket

Starfish PPS - Complete Catalog

Part Number	Description
177897-01	Output Relay Module
178195	Hose, Assembly, Sprint System
178196	Hose, Assembly, Sprint
1784-1028	Converter - Isolated Linearized
1784-575	CONVERTER
1784-653	INPUT, TC, TYPE K
1784-655	RTD Input
1784-659	Converter - Non-Isolated Pass Through
1784-675	RTD, 200 OHM
1785-KE	Communication Interface Module
178850-05	PROXPAC XL REPLACEMENT PROX AND COVER
178C6072G002	IGNITOR ASSEMBLY
1792M79P01	Orifice, Plate
1792M79P02	Orifice, Plate
1792M79P03	Orifice, Plate
1792M79P04	Orifice, Plate
1792M79P05	Orifice, Plate
1792M79P06	Orifice, Plate
1792M79P07	Orifice, Plate
1792M79P08	Orifice, Plate
1792M79P09	Orifice, Plate
1792M79P10	Orifice, Plate
1792M79P11	Orifice, Plate
1792M79P12	Orifice, Plate
1792M79P13	Orifice, Plate
1792M79P14	Orifice, Plate
1792M79P15	Orifice, Plate
1792M79P16	Orifice, Plate
1792M79P17	Orifice, Plate
1792M79P18	Orifice, Plate
1794-7	Water Filler Cap
1797-01	Cable, T5:4
1797M98P01	Pressure Probe
1798-01	Cable, T5:4
1800M58P01	Clamp, Coupling
1800R005ON /-V-KB	Element, Filter, MLO
1801262AFSM2	VALVE, BALL, 3 IN, 150 LB
180P44C6NR	Switch, pressure
180P44C6R	SWITCH, VACUUM
180SHT-301	Transformer, Current
181D5816G0001	Seal, air
181D5816G0002	Seal, Gas
181D5816G001	Seal, air
181D5816G002	Seal, Gas
181D5816G01	Seal, air
181D5816G02	Seal, Gas
1821M49G01	Anti-Clocking Pin
1826M46G01	Tube, Air, check valve
182888	Gasket
184389-01	MODULE, I/O
184684-01	MODULE, ENHANCED KEYPHASOR
1847M57P03	Wire, HPT

Starfish PPS - Complete Catalog

Part Number	Description
18484	KIT, FASTENER, NOX COUPLING
184A9809P001	SHIM, GEARRACK
185-SS 2"	BASKET, STRAINER
185-SS 2"-GSKT	Gasket
185-SS 3"	BASKET, STRAINER
185-SS 3"-GSKT	GASKET
1854M45G02	HPC Blade Retainer
1855M35P08	Bolt
185A1117P011	Sensor
185A1117P012	Sensor
185A1354P219	O-RING
185A1354P237	O ring
185A1354P271	O-RING
185A1364P001	Hydraulic Actuator
185A1632P005	Screen, Gas Strainer
185A1632P5	Screen, Gas Strainer
186C1916P008	Bolt, Hex Head
186C1916P013	Bolt
186C1916P022	Bolt
186C1916P029	Bolt
186C1980G001	SEAL, BOTTOM, TRANSITION TUBE
186C1981G001	SEAL, TOP, TRANSITION TUBE OUTER
186C6386P0001	DISC, CRV STOP, 20IN
18745-04-00	PROXIMITOR 7200
1879430000	POWER DISTRIBUTION BLOCK
187C7986G001	DEFLECTOR, OIL
1885M58P02	SPR, Wire - Flat
1886-5039	Servo Valve
188C9483G001	Deflector
188D4719G001	TUBE, CROSSFIRE
188D7278G001	Seal, Oil
188D7918G001	Crossfire (Xfire) Tube Retainer
188D9489G008	Spark Plug Assembly
18L0009WH	CAPACITOR, PROTECTIVE, SURGE, 13.8KV
190B1704G01	Handle
1912F-18-30	VALVE, GLO
191775	Washer - Lock, .173X.280X.03
191776	WASHER-LOCK, .1995X.323X.03
192B3452P003	GASKET
192B3817P001	CLAMP SEGMENT
194D7733P0001	Valve Stem
1950-00-2F	Pressure Switch
1950-5-2F	Pressure Switch
1957M62P01	SLEEVE
1962M86P02	T48 Thermocouple
1962m886p02	
1962m886p023	
1967M28P01	BRACKET, FWD CLG
196B1714P005	RETAINER, CROSSFIRE TUBE
196D1985G004	Spark Plug Assembly
1978M21G01	Check Valve Overhaul Kit
1978M21P01	Check Valve, FLAPPER

Starfish PPS - Complete Catalog

Part Number	Description
197C3155G002	End Seal
199D3157P116	Seal
199D3474P001	Crossfire (X-fire) Tube
199D3477P001	Crossfire (X-fire) Tube
1C2888	Valve, Check
1C2890	Valve, Check
1C31203G01	REMOTE I/O NODE CONTROLLER, EMERSON OVATION
1C31233G04	Ovation Module
1C3569G02	PUMP, HYDRAULIC, ACTUATOR
1C3569G03	PUMP, HYDRAULIC, ACTUATOR
1C3569G03-RENTAL	PUMP, HYDRAULIC, ACTUATOR
1C3569G3	PUMP, HYDRAULIC, ACTUATOR
1C484540-63	HOUSING, FILTER
1C6096	Tooling, ignitor depth gauge
1C6138G01	TOOL, DRILL, LM2500
1C6361G01	TOOL SET, RADIAL DRIVE
1C8018G01	GT Lift Fixture, LM2500+G4
1C8182G01	Tooling, Seal Removal
1C8200G02	Lift Fixture, LM2500GG
1C8340G01	GG Lift Fixture, LM2500+G4
1C8400G02	Fixture, Check-Actuator, VSV
1C8505P04	TOOL
1C9353P02	Tooling
1C9359G02	Tooling, VIGV
1C9381G01	Bracket, Shipping, Steam / FuelManifold
1C9381G02	Bracket, Shipping, Steam / FuelManifold
1C9393G01	Adapter Set, Pressure Test Rig
1C9403G01	Fixture, Check, VSV/VIGV Actuators
1C9408G01	Fixture, Torque Measuring - VSV Assembly
1C9412P01	Fixture, Retention, HPC VSV
1C9450G01	Tool, Closure Set Nozzle – Fuel Gas System
1C9621G01	Fixture, DLE Manifold
1CPT4466TSEA12-AR	VALVE, FLOW CONTROL, AS REMOVED
1D106G18A	Coil
1D3TR	Pump, Jacking
1INCH-S8000	Valve, Ball
1SVDK7	Pump, Water Wash
2-114	O-RING, HIGH TEMP
20-0122-001	Sensor
200091-106	GASKET, COVER
200091-297	ASSEMBLY: SEAL
20010	GIMBAL EXP JOINT
200565-15	CLOSURE
200728-126	STUD
200752-7	NUT
2008M74G01	Plug, Borescope, S2
2010C	GAUGE, MAGNAHELIC
201B222P34	CABLE, IGNITION
201B2626G009	Stud, Coupling
201B2635P001	LOCK NUT
201B2636P001	Lock Nut

Starfish PPS - Complete Catalog

Part Number	Description
201B3363G001	SEAL, ASSEMBLY
201J995002	Probe Assy
20285.11	ELEMENT, AIR / OIL
20317V	O-RING
20345V	O-RING, GLO FILTER HOUSING
20359V	O-RING
203D4523P0001	DISC, MAIN STEAM CONTROL VALVE
2040K-31B-3-JE24	Fan Cooled Heat Exchanger
2043-3385-000	Centrifugal Clutch, complete
204D3251G001	Probe Holder
204D5128	MOUNT
204D5128P001	Mount, Turbine
204D5128P002	Mount, Turbine
2051CG3A22A1AB4M5DFQ4	Coplanar Pressure Transmitter
2051CG4A22A1AB4M5DFQ4	Coplanar Pressure Transmitter
2051CG5A22A1AB4M5DFQ4	Coplanar Pressure Transmitter
2063951	ELEMENT, FILTER
207C3512G003	Ball Joint, Assy, SS, W/ 3/4" Compression Tubing Connection,
207C3558P001	Crossfire (Xfire) Tube Retainer
20820	Expansion Joint
208B8585P0020	1.25" , 7 TPI , Swivel Eyet Bolt
208D3803P0001	Valve Disc
208D5458P0001	Cabinet, Woodward, Micronet
208D9845P0021	Power Supply
2091907	Element, Filter, MLO
2092M71P01	Nut
2092M71P02	Nut
20ET	FUSE
20ST30505	CMP CABLE GLAND T3CDS
21000-16-05-00-105-03-02	Proximity Probe
21000-28-05-00-119-03-02	Probe
21000-XX-10-00-050-XX-02 Mod 174232-02-01	Probe, Vib
2117M48P01	WASHER
2117M48P02	WASHER
211D4318P0008	CABLE-MICRONET HIGH DENSITY
21236	CABLE, IGNITER
214C7152P001	STUD
214CRTSMB1S3M0065SL	Temperature Sensor
214CRTSMB1S4E0047SL	RTD
214CRWSMB1D3E0027SL	Temperature Sensor
214CRWSMB1D3E0042SLE6AT1C3B1WDG3XW	Temperature Sensor
214CRWSMB1D3E0152SLE6AT1C3B1WDG3XW	Temperature Sensor
214CTJSMT1SGE0050SLKAAT1C3WD	Temperature Sensor
21504-0-060-10-02	Probe
21504-0-32-10-02	8MM PROXIMITY PROBE -- 3/8-24
21504-0-60-10-02	8MM PROXIMITY PROBE -- 3/8-24
21508-02-12-10-02	7200 8MM PROXIMITY PROBE
215A2462P001	Washer
215A3192G001	Key
215A4218P003	PIN, BUCKET, SEAL SHANK

Starfish PPS - Complete Catalog

Part Number	Description
216A3107P0001	Valve
216A3111P0001	ADAPTER
216A3155P0001	CABLE, T2/T25 RTD
216A3156P0001	CABLE, VBV/VSV/IGV
216A3157P0001	CABLE, IGV/LVDT/XN2, LEFT
216A3158P0001	CABLE, IGV/LVDT, RIGHT
216A3159P0001	CABLE, XN25 SPEED
216A3160P0001	CABLE, CHIP DETECTOR, A/B
216A3161P0001	CABLE, VBV/VSV/LVDT
216A3162P0013	CABLE, TEMP LUBE & SCAVENGE
216A3163P0001	CABLE, TEMP LUBE RTD, D&E SUMPS
216A3164P0001	CABLE, VBV/VSV-LVDT, RIGHT SIDE
216A3165P0001	CABLE, CRF ACCELEROMETER
216A3166P0001	CABLE, TEMP COMPRESSOR DISCHARGE, T3
216A3167P0001	CABLE, UV FLAME DETECTOR
216A3168P0001	CABLE, XNSD SPEED
216A3169P0001	CABLE, TRF ACCELEROMETER
216A3170P0001	CABLE, OFF-ENGINE, T/C, T48
216A3171P0001	CABLE, EGT THERMOCOUPLE, LOWER
216A3248P0001	CABLE, STAGING VALVES, LEFT
216A3298P0002	Detector, Gas
216A3298P0003	DETECTOR, GAS
216A3299P0002	IR GAS DET
216A3299P0003	IR GAS DET
216A3315P0001	ELEMENT, TEMP, RTD, DUAL
216A3333P0001	Filter, H2O Injection Skid
216A3462P0001	Relay, GE
216A3468P0001	Gasket
216A3526P0001	SENSOR, GAS
216A3598P0001	600 DEGREE DET
216A3600P0001	CABLE, ENGINE, RTD
216A3600P0001-40	CABLE, CLUTCH OIL DRAIN RTD
216A3604P0001	CABLE, ENGINE, NPT SPEED
216A3605P0001	CABLE, ENGINE
216A3606P0001	CABLE, MAG CHIP DETECTOR
216A3607P0001	CABLE, CRF ACCEL
216A3608P0001	CABLE, TRF ACCELEROMETER
216A3609P0001	CABLE, ELECTRICAL CONTROL
216A3628P0001	ASSEMBLY: BRUSH, EARTHING
216A3629P0001	ASSEMBLY: BRUSH, EARTHING
216A3693P0001	Gasket
216A3740P0001	SWITCH, FLOAT, GEN, COOL WATER LEVEL
216A3741P0001	Bearing, Brush
216A3744P0001	BUSHING, BEARING
216A3753P0001	Valve, Check
216A3759P0001	FLOW METER
216A3766P0001	Flow Meter
216A3802P0001	CABLE, IGV/LVDT/XN2, RIGHT
216A3803P0001	CABLE, IGV/LVDT, RIGHT
216A3804P0001	CABLE, VBV/VSV/IGV
216A3821P0001	Pump, Hyd
216A3822P0001	Filter, Make up, Norway

Starfish PPS - Complete Catalog

Part Number	Description
216A3832P0001	GEN PROTECTION SYSTEM COMPR
216A3838P0001	VALVE, CHECK
216A3842P0001	LQ25T
216A3844P0001	Valve, Bypass, Liquid Fuel
216A3847P0001	EXCHANGER
216A3848P0001	SEPERATOR
216A3864P0001	CABLE, DYNAMIC PRESSURE SENSOR
216A3912P0001	Nozzle, Size 5
216A3927P0001	Safety Cable Terminator
216A3984P0001	CURRENT OUTPUT & RELAY
216A4050P0001	Clutch
216A4052P0001	Seal, Brush, NDE, Outer
216A4056P0001	Filter, Air
216A4095P0001	Check Valve
216A4096P0001	Check Valve
216A4342P0001	Intercooler Control Valve
216A4378P0001	Pump, lube oil
216A4396P0001	CABLE, OFF-ENGINE
216A4414P0002	Pump, Cooling Water
216A4416P0002	LMS100 Intercooler Pump Assembly
216A4430P0001	Valve, Check
216A4431P0001	Return Line Filter
216A4454P0001	VALVE, CHECK
216A4470P0001	
216A4471P0001	RTD
216A4501P0001	Power Supply, Micronet
216A4546P0001	QUAD BOX
216A4554P0001	Cable, Thrust Sensor
216A4555P0001	Cable, Thrust Sensor
216A4560P0001	REPEATER, HART
216A4604P0002	LUBE PUMP
216A4605P0001	Mineral Lube Pump
216A4619P0001	ASSEMBLY: METER, FLOW
216A4619P0002	Meter, Flow
216A4620P0001	RTD
216A4653P0001	HEATER
216A4690P0001	VALVE, SOLENOID,
216A4694P0001	GEARBOX, ROTOJET
216A4705P0001	CABLE, STAGING VALVE, RIGHT
216A4842P0001	WOODWARD, MICRONET+,
216A4843P0001	WASHER, SEAL, SET OF 4
216A4979P0001	HEATER
216A4980P0001	HEATER; TMSS-18315E2T2T36XX,400V/480V,21.5/31KW,1-3PH,15
216A4982P0001	Heater, 2-1/2 NPT
216A5020P0001	HEATER
216A5033P0001	LIGHT FIXTURE, 24V, 50W
216A5060P0001	GSOV, Woodward
216A5068P0001	Nozzle, Size 2
216A5069P0001	Nozzle, Size 8+
216A5103P002	Pump, Hydraulic
216A5118P0001	Y Strainer

Starfish PPS - Complete Catalog

Part Number	Description
216A5118P0001GSKT	Y Strainer
216A5129P0002	AMPLIFIER, DYNAMIC
216A5169P0001	Heator, Stator
216A5179P0002	CO2 MANUAL PULL
216A5213P0001	VALVE, CHECK
216A5227P0001	COUPLING, ASSY
216A5254P0001	Transducer, Proximity
216A5257P0001	NUT, HEX, FLEX LOCK
216A5266P0001	CABLE, RESOLVER
216A5267P0001	CABLE, MOTOR FEEDBACK
216A5268P0001	Cable, Electrical, Power
216A5269P0001	VALVE, THERMO, CONTROL
216A5270P0001	WASHER, FLAT, WIDE, STANDARD
2170-3305-000	Ring
21747-080-00	EXTENSION CABLE
2178-3375-000	Bearing cover
2178-3400-010	Worm Wheel Shaft
2181-1488	SWITCH, TEMPERATURE
218A4483P23	TRANSFORMER
219B6607G007	Stud Assembly Set
219B6702P001	Plate, Lock
219B6733P003	Bolt
22-32-0-024-1420	RELAY, FINDER, MODULAR CONTACTOR
22-32-0-230-1320	RELAY, FINDER, MODULAR CONTACTOR
2202-19T016F01	1PR/22 AWG, SHD, PLENUM, GRY JKT
221952-001	Contact
2227	VALVE, GLO
224B3215P0007	Thermowell, Thermocouple
224B9719P001	Lockplate
224B9719P002	Lockplate
224C5607G0003	CABLE
225130-001	KIT, Calibration
225269	DETECTOR, ELECTRONIC
225312-001	COVER, DUST
226365-119	QUAD-BOX, TERMINAL
226365-131	QUAD BOX
226365-132	BOX, JUNCTION, QUAD
226365-520	CONDULET B
226555-101	TRANSMITTER, COMBUSTIBLE
226585-001	Detronics transmitter
226A1359P0001	SCANNER, FLAME
226A1501P002	VALVE, SOLENOID
226A2436P001	Thermowell, integral housing
226A2436P1	Thermowell, integral housing
227B6087P002	Plug, Borescope
227B6088G003	Plug Assembly, borescope
227B608G002	Plug Assembly, borescope
227B6112G001	SCREW, SET
227B6112G003	NUT, SET
227C9753P002	
227C9753P004	
227C9753P006	

Starfish PPS - Complete Catalog

Part Number	Description
228C7374P0001	CHAMBER, BALANCE GE STM TURB MAIN STOP VLV I L24+
231-11-137	SEAL, BUFFALO PUMP, VOLUTE
232P4S134-124	Switch, Pressure
233C2501G001	SITE TUBE
2351	VALVE, CHECK
235546-000	Cable, Speed XN25
236B6391P0004	Bushing
236C1115P004	Bolt
236C1187G001	ASSEMBLY,BULL HORN WEAR COVER
23732-01	ACCELEROMETER
23733-03	MODULE, ACCEL
23870-14	LEAD, FLEXIBLE, SPARK PLUG IGNITION
23970-13	Igniter Cable
239A5601-4	Switch
239A5601-5	Switch
239A5622G001	DEFLECTOR, SEAL
239A5892P1	Pressure Switch
239B5942P001	Lockplate
239B9719P007	Plug, Borescope
239B9719P010	BOLT, CLEARANCE METER PLUG
24-296	SOLENOID VALVE
240833EXPB	225 Degree Thermal Spot Detector
240835EXPB	450 Degree Thermal Spot Detector
241C2842G001	Measurement Tip
24204B	SWITCH ROTARY
24304B	SWITCH ROTARY
2435M99P01	O-RING, HIGH TEMP
243C2835P001	BEARING, SPHERICAL
245C5731P0001	RING, VALVE, THREADED
246B2323AAG02	Circuit, Breaker, Exciter
24765-02-00	SENSOR, CASE EXPANSION TRANSDUCER
24765-02-01	Sensor, CASE EXPANSION TRANSDUCER - DC LVDT
247C5209G01	Tooling, Drill Guide, Fuel Nozzle
248A5904P001	Hydraulic Cylinder
248A5904P001-KIT	HYDRAULIC CYLINDER SEAL KIT
248A5943P001	TRANSDUCER, ROTARY
249A2662P0001	Pump, Jacking Oil
249A4019P0001	Release Module
249A4031P0001	VALVE, SOL
249A4071P0001	BOLT, HEX
249A4125P0001	Module, Alarm
249A4139P0001	CABLE,NETCON LAYOUT LOW DENSITY DISCRETE,GR
249A4202P0001	CPU, MICRONET
249A4202P0002	Module, Micronet plus CPU5200
249A4262P0001	Coupling, GLO
249A4292P0001	FLANGE KIT, SPLIT, 1-1/2 IN, 6000LB, S
249A4398P0001	HOSE, ASSEMBLY
249A4446P0001	Pump, Fuel
249A4465P0001	Valve, GS16
249A4476P0001	CABLE, T/C
249A4652P0001	Temp Detector

Starfish PPS - Complete Catalog

Part Number	Description
249A4667P0001	VALVE, CHECK
249A4695P0001	TRANSMITTER
249A4696P0001	TRANSMITTER
249A4697P0001	TRANSMITTER
249A4698P0001	TRANSMITTER
249A4699P0001	TRANSMITTER
249A4700P0001	FOD SOCK
249A4733P0001	Transmitter, Level
249A4747P0001	CABLE, EGT THERMOCOUPLE, LOWER
249A4751P0001	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
249A4756P0001	SWITCH, VIBRATING FORK, LIQUID LEVEL
249A4854P0001	CLAMP, U
249A4904P0001	POWER SUPPLY, 24VDC INPUT
249A4931P001	Pump, VG
249A4931P002	Pump, VG
249A4959P0001	Cycle release module
249A4992P0001	Detector, gas
249A9250P0001	RECTIFIER MODULE
249A9364P0001	Belt
249A9404P0001	Board, PC, 505, 500OHM
249A9532P0001	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
249A9597P0001	Bellows
249A9862P0001	AL8001440DEV:38 DEVIATED MODULE
250A1155P0001	Pump, Jacking
250A1407P0001	VALVE, CHECK
250A1429P0001	Filter Element
250A1635P0001	INDICATOR
250A1787P0001	Solenoid Valve
250A1787P0001-AR	Solenoid Valve
250A1971P0001	Filter, Element
250A2005P0001	IR Gas Detector
250A2617P0001	Filter, inlet
250A2624P0001	Relay
250A4318P0001	
250A4590P0001	CABLE, RTD
250A4726P0001	CONTROL BOARD(PCB94), VSR100 / VSR175, M2
250A4727P0001	Velcro
250A4968P0001	VALVE, SOLENOID
250A5079P0001	Motor
250A5080P0001	MOTOR, STARTER
250A5768P0001	Kit, Flange (Metric)
250A5892P0001	SENSOR, GAS
250A6978P0001	Velcro
250A7060P0001	Switch, Pressure
	Gas
	Transmitter
25100SS04TXCG	Diaphragm Seal
2511A	RTD, Dual
25192-009	Cable, Accel
252-PVUU-PQBX-C6-EB	RELAY, OUTPUT
25200-001-040-T00	CABLE, ACCEL, CRF/TRF
25200-003-020-T36	Cable, RTD

Starfish PPS - Complete Catalog

Part Number	Description
25200-003-030-T36	CABLE, ENGINE, RTD
25200-003-040-T36	CABLE, CLUTCH OIL DRAIN RTD
25200-003-050-T36	Cable
25200-003-140-T36	CABLE, RTD
25200-014-030-T36	CABLE, NPT SPEED
25200-014-040-T36	CABLE, ENGINE, NPT SPEED
25200-014-050-T36	Cable, PT Speed NPT
25200-014-075-T36	Cable, NPT Speed
25200-014-135-T36	Cable
25200-019-050-T36	Cable, Dual Element (200 ohm RTD)
25200-020-040-T36	Cable, T5:4
25200-020-050-T36	Cable, T5:4
25200-021-030-T36	CABLE, ENGINE
25200-021-050-T36	Cable
25200-021-055-T36	CABLE, T/C
25200-022-035-T36	CABLE, UV FLAME SENSOR
25200-024-040-T36	Cable, Chip Detector
25200-030-050-T36	Cable
25200-031-060-T36	CABLE
25200-036-050-T36	Cable
25200-039-025-T00	Cable, Sensor
25200-040-025-T36	CABLE, DUAL RTD/VSV LVDT, T2 SENSOR
25200-040-050-T36	Cable, Dual RTD/VSV/LVDT
25200-040-100-T36	Cable, Off-Engine, Dual RTD/VSV/LVDT
25200-041-030-T36	CABLE, MAG CHIP DETECTOR
25200-041-040-T36	Cable, Chip Detector
25200-041-050-T36	Cable, Chip Detector
25200-041-085-T36	CABLE
25200-041-130-T36	CABLE, CHIP DETECTOR, SCAVENGE
25200-044-050-T36	Cable
25200-046-040-T36	Cable, VSV
25200-046-045-T36	Cable, VSV Servo Valve
25200-046-050-T36	Cable
25200-046-130-T36	CABLE, SERVO VALVE, VSV
25200-060-050-T36	Cable
25200-A01-030-T00	CABLE, CRF ACCEL
25200-A01-040-T00	CABLE
25200-A07-030-T36	CABLE, ELECTRICAL CONTROL
25200-A07-050-T36	Cable, NGG1 GG Speed
25200-A07-060-T36	CABLE, ELEC, NGG1 GG SPEED
25200-A07-x050-T36	Cable
25200-A13-040-T00	CABLE, TRF ACCELEROMETER
25200-A14-050-T36	Cable, PT Speed NPT
25200-A45-035-T36	CABLE, STAGING VALVE, RIGHT
25200-A45-050-T36	Cable
25200-B40-040-T36	CABLE, OFF-ENGINE, T2 SENSOR DUAL RTD/VSV LVDT,
25200-CDP-030-T36	CABLE
252588	VBV Boot, Norway
25361-04	Ignition Lead

Starfish PPS - Complete Catalog

Part Number	Description
25362-34	CABLE, IGNITION SYSTEM
25363-10	Lead, Ignition
25363-11	Lead, Ignition
25363-12	Lead, Ignition
25363-13	Lead, Ignition
25363-14	Lead, Ignition
25364-50	Lead, Ignition
25364-51	Lead, Ignition
25364-52	Lead, Ignition
25364-53	Lead, Ignition, Flexible, 32 foot
254A7229P0008	FILTER
255A4167P001	Pin, Borescope
255A4309P001	THERMOCOUPLE
255A4309P002	Thermocouple, Wheel Space
255A4309P004	Thermocouple, Wheel Space
255A4330P001	Fitting, T/C
255A4332G004	T/C Tube
255A4708AP004	THERMOCOUPLE, COMPRESSOR DISCHARGE
255A4708P004	Thermocouple, Comp Discharge
255A4991P3	Gasket
25600-001-009-OE	CABLE, LPT, SPEED
25600-001-040-T36	CABLE, T2/T25 RTD
25600-001-045-V36	Cable
25600-001-050-T36	CABLE, T2/T25 RTD
25600-001-050-V36	Cable
25600-001-055-V36	Cable
25600-002-006-OE	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT
25600-003-006-OE	CABLE, ELECTRICAL, VBV/VSV/LVDT
25600-003-040-T36	CABLE, CLUTCH OIL DRAIN RTD
25600-004-005-OE	CABLE, TEMP, LIQUID MANIFOLD
25600-005-005-OE	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
25600-005-030-T36	CABLE, VBV/VSV/IGV
25600-005-040-T36	CABLE, VBV/VSV/IGV
25600-005-050-V06	CABLE, TEMP, LUBE & SCAVENGE, SUPPLY
25600-005-050-V36	CABLE, TVBV/VSV/IGVO
25600-006-005-OE	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
25600-007-005-OE	CABLE, SPEED, GAS GENERATOR
25600-007-040-T36	CABLE, IGV/LVDT/XN2, LEFT
25600-007-050-T36	CABLE, IGV/LVDT/XN2, RIGHT
25600-007-050-V36	CABLE, IGV/LVDT, LEFT
25600-008-005-OE	CABLE, SPEED, GAS GENERATOR
25600-008-040-T36	CABLE, IGV/LVDT, RIGHT
25600-008-050-T36	CABLE, IGV/LVDT, RIGHT
25600-008-050-V36	CABLE, IGV/LVDT, LEFT
25600-009-007-OE	CABLE, CHIP DETECTOR, A/B/COM
25600-010-008-OE	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
25600-010-040-T36	CABLE, XN25 SPEED
25600-010-050-T36	CABLE, XN25 SPEED
25600-010-050-V36	Cable
25600-012-005-OE	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
25600-012-025-V36	CABLE, CHIP DETECTOR, A/B

Part Number	Description
25600-012-040-T36	CABLE, CHIP DETECTOR, A/B
25600-012-040-V36	Cable
25600-012-050-T36	CABLE, CHIP DETECTOR, A/B
25600-013-025-V36	CABLE, CHIP DETECTOR, C/D/E/COMM
25600-013-030-T36	CABLE, CHIP DETECTOR, C/D/E
25600-013-040-T36	CABLE, CHIP DETECTOR, C/D/E
25600-013-040-V36	Cable
25600-016-040-T36	CABLE, VBV/VSV/LVDT
25600-016-050-T36	CABLE, VBV/VSV/LVDT
25600-016-050-V36	CABLE, VBV/VSV/LVDT, LEFT
25600-016-055-V36	Cable
25600-019-020-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-030-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-040-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-050-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-050-V36	Cable
25600-020-030-T36	CABLE, TEMP LUBE RTD, D&E SUMPS
25600-020-040-T36	CABLE, TEMP LUBE RTD, D&E SUMPS
25600-020-050-T36	CABLE, TEMP LUBE RTD, D&E SUMPS
25600-020-050-V36	Cable
25600-021-040-T36	CABLE, VBV/VSV-LVDT, RIGHT SIDE
25600-021-050-T36	CABLE, VBV/VSV-LVDT, RIGHT SIDE
25600-021-050-V36	CABLE, VBV/VSV/LVDT, RIGHT
25600-021-055-V36	Cable
25600-022-040-T00	CABLE, CRF ACCELEROMETER
25600-026-040-T36	CABLE, TEMP COMPRESSOR DISCHARGE, T3
25600-026-050-T36	CABLE, TEMP COMPRESSOR DISCHARGE, T3
25600-026-055-V36	Cable
25600-026-060-T36	CABLE, TEMP COMPRESSOR DISCHARGE, T3
25600-027-040-T36	CABLE, UV FLAME DETECTOR
25600-027-043-T36	CABLE, UV FLAME DETECTOR
25600-027-060-T36	CABLE, UV FLAME DETECTOR
25600-027-120-T36	CABLE, UV FLAME DETECTOR
25600-029-040-T36	CABLE, MANIFOLD TEMPERATURE
25600-029-050-T36	CABLE, MANIFOLD TEMPERATURE
25600-030-030-T36	CABLE, XNSD SPEED
25600-030-040-T36	CABLE, XNSD SPEED
25600-030-040-V36	Cable
25600-030-050-T36	CABLE, XNSD SPEED
25600-031-006-OE	CABLE, LPT, SPEED
25600-032-040-T00	CABLE, TRF ACCELEROMETER
25600-034-030-T36	CABLE, OFF-ENGINE, T/C, T48
25600-034-040-T36	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
25600-034-050-T36	CABLE, OFF-ENGINE, T/C, T48
25600-036-030-T36	CABLE, EGT THERMOCOUPLE, LOWER
25600-036-040-T36	CABLE, EGT THERMOCOUPLE, LOWER
25600-036-050-T36	CABLE, EGT THERMOCOUPLE, LOWER
25600-040-025-V36	CABLE, STAGING VALVE
25600-040-030-V36	CABLE, STAGING VALVE
25600-040-040-T36	CABLE, STAGING VALVES, RIGHT
25600-040-060-T36	CABLE, STAGING VALVES, RIGHT
25600-041-025-V36	CABLE, STAGING VALVE

Starfish PPS - Complete Catalog

Part Number	Description
25600-041-040-T36	CABLE, STAGING VALVES, LEFT
25600-041-060-T36	CABLE, STAGING VALVES, LEFT
25600-044-045-V36	CABLE, T/C T48, RIGHT
25600-044-060-V36	Cable
25600-045-045-V36	CABLE, T/C T48, LEFT
25600-045-060-V36	Cable
25600-048-040-T36	CABLE, TBV
25600-048-040-V36	CABLE, CDP, 16TH STAGE BLEED VALVE
25600-048-050-T36	CABLE, TBV
25600-048-050-V36	CABLE, XN25
25600-048-060-V36	Cable
25600-049-040-T36	CABLE, 8TH STAGE BLEED VALVE
25600-049-060-V36	CABLE, 8TH STAGING BLEED VALVE
25600-049-065-V36	Cable
25600-056-040-T36	CABLE, TBV
25600-057-040-T00	CABLE, DYNAMIC PRESSURE SENSOR
25600-057-065-T00	CABLE, OFF-ENGINE
25600-058-045-T36	CABLE, LIQUID FUEL VALVES
25600-059-045-T36	CABLE, LIQUID FUEL VALVES
25600-060-025-V36	CABLE, STAGING VALVE, GAS SWITCH
25600-060-040-T36	CABLE, DRAIN VALVES
25600-060-045-T36	CABLE, DRAIN VALVES
25600-072-040-T06	CABLE, IGNITION TRANSFORMER
25600-072-040-V06	Cable
25600-072-055-V36	Cable
25600-A12-012-T00	CABLE, PATCH
25600-A29-040-T36	CABLE, MANIFOLD TEMPERATURE
25600-A29-045-T36	CABLE, LIQUID FUEL TEMPERATURE
25600-A29-050-T36	CABLE, MANIFOLD TEMPERATURE
25600-A58-045-T36	CABLE, LIQUID FUEL VALVES
25600-A59-045-T36	CABLE, LIQUID FUEL VALVES
25600-C42-040-T36	CABLE, STAGING VALVES
25890-40	Lead, Ignition
25890-41	Lead, Ignition
25890-42	Lead, Ignition
25890-43	Lead, Ignition
25890-44	Lead, Ignition
258A4439P001	Heater
258A4447P001	Gasket, immersion heater
258A4503P001	THERMOCOUPLE, WHEELSPACE
258A4784P013	PLATE, LOCK
258A4784P015	Plate, lock, bull horns
258A4860P002	Filter
25945-71	Lead, Ignition
25945-72	Lead, Ignition
25945-73	Lead, Ignition
259B2434ABP18	CABLE, MARK VI
259B2451BYG01	FILTER, EMI
259B2451FCG07	PCNOH1B/SPID ASM DIN RAIL MTG
25FLFXS	NUT, 6 PT
26141812P002	AMPLIFIER, FLAME
261A1301P0001	Valve, relief

Starfish PPS - Complete Catalog

Part Number	Description
261A1812P003	Scanner, Flame
261A1812P004	Scanner, Flame
261A1812P005	Scanner, Flame
261A1812P006	Scanner, Flame
261A1812P007	Scanner, Flame
261A1812P008	Scanner, Flame
261A1812P009	Scanner, Flame
261A1812P010	Scanner, Flame
261A1812P011	Scanner, Flame
261A1812P012	Scanner, Flame
261A1812P013	Scanner, Flame
261A1812P014	Scanner, Flame
261A1812P015	Scanner, Flame
261A1812P3	Scanner, Flame
262A3561P002	PLUG, HEX HEAD
262A3716P001	THERMOCOUPLE, COMPRESSOR INLET
26387-000	Thermocouple T5:4
26490-000	T3 Sensor
264A6889P0005	NUT
26530-12-10-00-000-189-21-03-00	PROBE, BENTLY NEVADA
267218	RELAY, TRIPPING, AREVA
267B6699P0003	CABLE, POWER & JUMPER
267B6699P0009	CABLE, TDBS POWER
267B6699P0016	CABLE, POWER, 5-PIN PIGTAIL
267B7555P0002	IGNITION TRANSFORMER POWER
268642-120	Power Supply
268A1290P003	Switch, Pressure
268A1431P001	Lockplate
268A1439P001	Stretch Nut
270250	FOD Sock
2708740	CONTACT, RS485
27112-050	Cable
27112-065	Cable
27210450	DETECT A FIRE UNIT
272A1721P0002	PIN, STEM/DISK
27304-000-120-T36	Cable, Electrical, Temp
27304-701-040-T00	CABLE, DYNAMIC PRESSURE SENSOR
27304-701-065-T00	CABLE, OFF-ENGINE
27304-808-045-T00	Cable, Valve Feedback
27304-814-045-T00	Cable, Power
273800	Clutch
27391C18 / EG8004	Brush, Grounding, Jeumont (2X)
275A8898P011	Thermocouple
277218	HOSE, TLO PUMP SUCTION L1
277219	HOSE, TLO PUMP L2
277220	HOSE, Lube oil Scavenge " L3
277222	Hose, Hydraulic
277A2906P001	Pump
278A2181VRP3	BOARD, ARKNET CONTROL
279A1396P001	SWITCH, LIMIT
279A1396P005	Switch
279A1396P007	Switch

Starfish PPS - Complete Catalog

Part Number	Description
281854	Spacer, Front Clevis
281855	Clevis, Aft Mount
281856	Bearing
281857	Bearing, Turnbuckle
281859	Mount, Turbine, Aft
281859-AR	AS REMOVED; Mount, Turbine, Aftermarket
281859-OH	Mount, Turbine, Aft, REBUILT
281860-1	Bearing, Rod
281860-2	Bearing, Rod
281861	Nut, Jam, aft mount
281862	Nut, Jam, aft mount
281863	Nut, Jam
281864	Nut, Jam
281865	Link, Engine Mount
281866	Bolt, Aft Mount, Top
281867	Bolt, Aft Mount, Bottom
281B7946G1301	FIRE PROTECTION, 4X CONFIG, DIN (LFPI)
281B7946G1302	LFPI, TPIM CONFIG, DIN
28240-C00	CABLE, ASSEMBLY, DRIVER TO VALVE
283748	Starter Card
286A5443PR5	LED COLOR CAP TRANSLUCENT RED ET-16
286A6290P003	PLUG, SQUARE HEAD
286A6290P007	plug, pipe
286A6346P012	Heater
2873-250	SEAL
2873-300	Seal
2873-400	Metal Gasket Ring, E Seal
2873-600	Metal Gasket Ring, E Seal
287783	FABRIC EXPANSION JOINT
287837	FABRIC EXPANSION JOINT ASSY
287A1397P001	LUBRICANT, HEAVY DUTY, ANTI-SEIZE
287A1399P023	FITTING, CONN,MALE,WITH STOP COLLAR
287A1496P101	VALVE, BUTTERFLY
287A1614P004	RING: TYPE PACKING, SIZE 107MM ID X 125MM OD, MA GRAPHITE
287A1692P001	Bolt, Hex Head, TP, Shoulder Bolt
287A7888G001	Tubing, Thermocouple
288005	FLANGE ADAPTER,TRF VENT,2
288055-01	MODULE, STANDARD TRANSIENT DATA INTERFACE
288056	Hose, Assembly, Sprint System
288057	Hose, Assembly, Sprint System (TW1)
288062-02	MODULE, TACHOMETER
2880641-12	Washer, Insulating
2880642-12	Washer
2883226	Nut
2883343-07012	Bolt, Coupling
2883343-12014	Bolt, Coupling
2883395-4	Locknut
288780	Fixture, Lift, LM6000
288822	FWD Mount Bolt
289174	Duct, VBV
289188	Manifold Sprint, Water

Starfish PPS - Complete Catalog

Part Number	Description
289189	Manifold, Sprint System
289195	Hose, Assembly, Sprint System
289196	Hose, Assembly, Sprint
289239	Hose, Assembly, Gas Supply
292A319G23	PLUG, TEST
293A0910P006	Bolt
293B254A20	RELAY, AUXILIARY
294A0151P004	Locking Plate
294A0151P022	Lockplate
294A4087P0001	Booster, LMS100
294A4118P0001	FILTER, AIR
294A4635P0001	SCREEN, REPLACEMENT, 100 MESH
294A4636P0001	SCREEN, REPLACEMENT, 100 MESH
294A4637P0001	Indicating Lamp, Red Lens
294A4639P0001	Lamp, Blue Lens
294A4654P0001	LAMP, INDICATING, GREEN LENS
294A4661P001	ASSEMBLY: LAMP HOLDER, RED
294A4662P0001	ASSEMBLY: LAMP HOLDER, GREEN
294A4725P0001	125A, 690V FUSE
294A4737P0001	FUSE, FAST ACTING, 22X58MM, 690V, 32A
294A4754PP0001	SENSOR, SPRING LOADED TEMP
297A0559P003	THERMOCOUPLE
297A2331P0001	STRAP, GROUNDING, BRAID, 3/16"THK X 1-5/8"WD X 10
298A0530P0007	Switch, Limit
298A0530P007	Right Angle Bodied Switch
298A8221P001	NUT, RETAINER, Fuel Nozzle
298A8252P001	PLATE, LOCK
298A8989P002	Probe
299370-12C	BOLT, HEX
2BFCF14002D	VALVE, THERMOSTATIC
2BOCT12001	3 Way Temperature Control Valve
2BOKIT-12001	Repair Kit, 3 Way Temperature Control Valve
2C14699	Fixture, Lift-Compressor stator Case upper
2C6103G08	Protractor Tool Set, Gas Generator Rigging
2C6103G09	Protractor Tool Set, Gas Generator Rigging
2C6613G01	Gauge, Immersion Depth, Igniter
2C6883G01	Tooling, Drilling Guide, Fuel Nozzle
2C6883G01-DLE	Tooling, Drilling Guide, DLE Fuel Nozzle
2C6962G05	Gage, sight - VSV Actuation Arms
2C6966G07	Gage, sight - VSV Actuation Arms
2C8016G03	Gage, Sight VSV Stage 5 Actuation Arms
2C8102G02	Tooling, Torque Fixture
2CC/TR	Pump, Jacking
2G-377P-800F	Filter Silencer
2GXY9	RTV SILICONE
3"GASKET F/764-SS	GASKET, INLET SCREEN, Y-STRAINER
3/3VX1180	Belt, Gates
3/3VXKB1180	Belt
3/5VX1060	BELT
3/5VX1500	3 Band Belt

Starfish PPS - Complete Catalog

Part Number	Description
30.499815.1.202	BRUSH HOLDER AND CLAMP
3016M78P03	Strap, Upper
301914	O Ring
3024084	Filter
302A1620P012	PLUG, PIPE
302A1620P013	PLUG, PIPE
302A4010P002	THERMOCOUPLE, EXHAUST
302A4597P010	Gasket
302A4597P069	GASKET, FLANGE, FUEL NOZZLE, 1IN, 600LB
302A4597P070	Gasket
3032M38P48	Stud
3032M38P52	Stud
303A3530P0001	Spring
304661009	Heater
304726	Filter Element
304FG 1/2	600# spiral wound
304FG 2	150# spiral wound
305136	Exciter
305193052	Heater
3051CD3A22A1AK6	Filter Pressure Differential Transmitter
3051CG3A02A1AE5H2B1DF	Coplanar Transmitter
3051CG5A02A1A	Pressure Transmitter
3051CG5A02A1AH2B1E5M5	Transmitter
3051S1CD2A2E12A1AB4N1	Transmitter
3051S1CD2A2E12A2AKA	TRANSMITTER
3051S1CD3A2E12A2AKA	TRANSMITTER, PRESSURE
3051S1CD3A2E12A2AKAA0229	Transmitter, pressure
3051S1TA1A2E11A2AKA	TRANSMITTER, PRESS
3051S1TG3A2E11A2AKA	Fuel Gas Pressure Transmitter
3051S1TG3A2E11A2JKDQ4	Transmitter, pressure
3051S1TG4A2E11A2AKA	SENSOR, PRESSURE
3051S2CG3A2E12A1AK5Q4	SCALABLE PRESSURE TRANSMITTER
3051S2TG3A2	Transmitter
3051S2TG3A2A11A1AB4M5Q4	Transmitter
3051S2TG3A2E11A1AB4M5Q4	Transmitter
3051TA2A2A21AC6	Transmitter, pressure
3051TA2A2B21AKD	TRANSMITTER
3051TA3A2B21AC6	Inline Pressure Transmitter
3051TG2A2A21AC6	TRANSMITTER, PRESSURE
3051TG2A2A21AK6	Compressor Discharge Pressure PS3
3051TG3	TRANSMITTER
3051TG3A2A21AB4C6	GLO Pressure Transmitter
3051TG3A2A21AB4K6Q4	GLO Pressure Transmitter
3051TG3A2B21KB4K7M6RK	GLO Pressure Transmitter
305925014	HEATER
305U250	Jeumont Diode
305UR250	Jeumont Diode
3076/029	Pump
3076/029-Major RK	Major Repair Kit for 3076/029
3076/029-MinorRK	
307A9298PXX	3076/029 Minor Repair Kit
	CABLE; T2 INLET

Starfish PPS - Complete Catalog

Part Number	Description
3084308-001	PreFilter, 24x24x4 in.
308FX2-ST	SWITCH, ETHERNET
310-SP-1	VALVE, 310A, PRESSURE REGULATING
31000-16-10-0-133-03-02	PROXIMITY PROBE HOUSING
3102HA1FSCNAQ4ST	TRANSMITTER, LEVEL, ULTRASONIC
3116682/01	BRUSH, CARBON
311735202	Key, Machine
311A5178P008	LVDT Transducer
311A5178P023	SENSOR
311A5802P002	CABLE, IGNITER
311A5802P003	Igniter Cable
312434	Synthetic Lube Oil Supply Filter
3131744-01	DIODE
3131745-01	FUSE, 250V, 1000A
313233	Hose, Gas
313234	ELBOW
313359A	Hose, Lube, GLO
313830101	Clamp Plate
313A7231P0008	DIAPHRAGM
313A7233P0016	SHIELD
314093901	Clamp Plate
314163901	Key
3144PD6A1K7B5M5CNQ4QT	Rosemount 3144P Temperature Transmitter
314A4091P0001	GLAND, TC CABLE, GT GENERATOR BEARING
314A5030P01	SENSOR, FLAME
314A5051P1	SOLENOID VALVE
315A2660P003	FILTER, HYDRAULIC
315A2708P119	Gas Detector/Transmitter for IBH valve Position Transmitter
315A4045G001	Stop Seal
315A9636P001	Bolt
316255	Synthetic Lube Oil Scavenge Filter
316A4525P0001	GASKET
316B3767P0004	BOLT, HEX HEAD
316B4525P0001	GASKET
317947601	Clamp Plate
318078	Nut - Plain, Hex
318079	Nut - Plain, Hex
31830-1057	VALVE, SOL
31830-1057A	VALVE, SOL
31830-1063A	VALVE
31830-1063E	Valve, Drain
31830-1147	Valve, Solenoid
31830-1597E	Valve, Solenoid, Fuel Manifold
31840-1058A	Circle Seal Valve
31840-1417	Valve, Drain
31840-1598A	Valve, Solenoid
31840-1598C	Valve, solenoid
31840-1602	Fuel Manifold Drain Valve
31840-X	VALVE 24VDC
31861-1059	
31861-1059A	VALVE, SOL
31861-1059B	VALVE, SOL

Starfish PPS - Complete Catalog

Part Number	Description
31861-1059C	Valve, Solenoid
31861-1140	VALVE, SOL
31861-1140A	VALVE, SOL
31861-1140B	VALVE, SOL
31861-1599C	Valve
31861-1600	Valve, solenoid
31861-1600C	Valve
31861-1623A	VALVE, SOL
31861-1623B	Valve, solenoid
318A9711P001	Gasket
318A9713P027	Gasket
318A9713P056	Gasket
318A9801P002	Plug, Borescope
31902-02	Woodward
32-24588SEB	Control Valve for SCR
320B5226P0001	Cover
3215548-4	Valve, Bleed Air
3215548-4-AR	Valve, Bleed Air
3215548-4-OH	VALVE, BLEED AIR
3215552-5	Valve, Bleed Air
3215568-2-AR	VALVE, BLEED AIR, AS REMOVED
3215568-2-OH	VALVE, BLEED AIR, OVERHAULED
323A2354P2	RESISTOR
323A2354P3	RESISTOR
323A2354P33	Resistor
323A2354P41	Resistor
323A2357P21	FUSE, 1.5A
323A2440P15	SHUNT
323A3347P14	Cable, Assembly, Mark VI, 14 ft, for T48
323A3347P16	Cable, Assembly, Mark VI, 16 ft, for T48
323A3347P18	Cable, Assembly, Mark VI, 18 ft, for T48
323A3347P20	Cable, Assembly, Mark VI, 20 ft, for T48
323A3348MF05	Cable
323A4747NZP50A	SWITCH
323A4747UUP4	ETHERNET PATCH CABLE - 50 FT
323A5750P16	Cable, Assembly, Mark VI, 16 ft, for T48
323B7988P005	Carbon Brush
323B7989P002	BRUSH, GROUNDING
324A5325P005	Gasket
324A5700P001	Valve, Solenoid
324A5973P002	Hose
324A5973P022	HOSE- HYDRAULIC
324A9109P005	GASKET, RING
324A9109P006	GASKET, RING
324A9109P107	GASKET, RING
324A9109P111	Gasket
324B7453P0004	STUD, BODY BOUND
3255455201-02	Plastic Frame Pre-Filter, M5,w/ downstream gasket
325B4830P001	Wear Shim
32810-867	VALVE, ATKOMATIC
32820 OH kit	Circle seal 1/2 OH kit
32820-002	Circle Seal "GAS"

Starfish PPS - Complete Catalog

Part Number	Description
32820-002PNAA1E	Circle seal 1/2 NO valve
32820-1111	Valve, Dump, Fuel
32840-1650	Valve
32840-1682	Valve, Solenoid
32861-1603	Nat Gas vent valve
32861-626	Nat Gas vent valve
328A7327P002	Ignition Transformer
328A8480P054	Thermocouple
328A8483P001	Thermocouple
328A8483P002	Thermocouple
328A8483P005	THERMOCOUPLE
328A8483P050	THERMOCOUPLE
328A8630P001	Thermocouple
328A8630P002	Thermocouple
328B691G0004	Holder, Brush
329635-C102	Valve, Fuel Metering
329A3529P001	TRANSDUSER VIBRATION VELOCITY
329A3529P021	Vibration Cable
329A3529P029	Sensor, Vibration
329A3529P040	Probe, Vibration
329A3529P055	Cable, Vibration Sensor
329A3529P056	Cable, Vibration Sensor
329A3529P057	CABLE: TYPE VIBRATION
329A3529P091	Vibration Sensor
3300	RACK, BENTLY NEVADA
3300/01	System Monitor
3300/01-01	System Monitor
3300/03	System Monitor
3300/03-01-00	System Monitor
3300/03-02-01	MONITOR, SYSTEM
3300/11	Power Supply
3300/11-01-02-00	Power Supply
3300/12	Power Supply
3300/12-01-20-00	Power Supply
3300/14	Power Supply
3300/14-01-20-00	Power Supply
3300/14-02-20-00	Power Supply
3300/15	Dual Vibration Monitor
3300/15-02-01-02-00-00-00	Dual Vibration Monitor
3300/15-03-01-02-00-00-00	Dual Vibration Monitor
3300/16	Dual Vibration XY/Gap Monitor
3300/16-01-01-02	DUAL VIBRATION XY/GAP MONITOR
3300/16-02-01-01-00-00-01	Dual Vibration XY/Gap Monitor
3300/16-02-01-01-00-00-02	Dual Vibration XY/Gap Monitor
3300/16-02-01-02-01-00-01	Dual Vibration XY/Gap Monitor
3300/17	VIBRATION MONITOR
3300/20	Dual Thrust Monitor
3300/20-02-01-00-00-00	Dual Thrust Monitor
3300/20-02-01-02-00-00	Dual Thrust Monitor
3300/48-01-01-00	MONITOR, CASE EXPANSION
3300/48-01-01-01-00	MONITOR, CASE EXPANSION

Starfish PPS - Complete Catalog

Part Number	Description
3300/50-03-01-00-00	MONITOR, TACHOMETER
330100-90-05	3300 XL 8mm Proximitor Sensor
330101-0-20-20-11-00	PROBE 3300 8MM
330101-00-08-10-12-05	PROBE, 3300, 8MM
330101-00-12-10-02-00	PROBE, 3300XL, 8MM
330101-00-16-10-02-00	PROBE, VIBRATION, 8MM
330101-00-20-10-02-00	PROBE, KEYPHASER
330101-00-20-10-02-05	PROBE, KEYPHASER
330101-00-24-10-02-00	PROBE, VIBRATION, 8MM
330102-00-20-10-02-00	CABLE, 3300 XL 8MM
330102-00-20-10-02-05	CABLE, 3300 XL 8MM
330102-00-20-50-02-00	Probe
330102-00-28-05-02-05	Proximity Probe
330102-00-68-05-02-05	Vibration Probe
330103-00-016-90-1200	Probe, Bently
330105-02-12-05-02-00	Key Phaser or Vib Probe
330105-02-12-05-02-05	Key Phaser or Vib Probe
330105-02-12-10-02-00	PROBE, VIBRATION, REVERSE MOUNT
330105-02-12-10-02-05	PROBE, VIBRATION, REVERSE MOUNT
330105-02-12-20-02-00	Proximitor Sensor, 3300XL 8mm
330106-05-30-05-02-05	PROBE 3300 8MM RVS MNT
330106-05-30-10-02-00	Transducer, Proximity
330106-05-30-10-02-05	PROBE 3300 8MM BENTLY RVS MNT
330130-040-00-00	CABLE, EXTENSION
330130-045-00-05	Extension Cable
330130-045-01-05	CABLE, EXTENSION, ARMOR
330130-080-00-00	CABLE, EXTENSION
330130-080-01-00	CABLE, EXTENSION, ARMOR
330130-080-01-05	CABLE, EXTENSION, ARMOR
330130-080-02-05	CABLE, EXTENSION
330130-080-12-00	3300 XL 5/8mm Extension Cable
330130-080-12-05	3300 XL 5/8mm Extension Cable
330130-085-00-05	Probe
330130-085-01-05	Cable, Proximitor
330171-0-20-10-02-05	PROBE
330171-00-20-10-02-05	PROBE
330173-00-16-90-02-00	TRANSDUCER
330180-085-01-05	CABLE, EXTENSION
330180-12-05	PROXIMITOR 3300XL
330180-50-00	330180-50-00
330180-50-05	330180-50-00
330180-51-00	3300 XL Proximitor Sensor
330180-51-05	3300 XL Proximitor Sensor
330180-90-00	3300 XL 5/8mm Proximitor Sensor
330180-90-05	3300 XL 5/8mm Proximitor Sensor
330180-91-00	3300 XL 5/8mm Proximitor Sensor
330180-91-05	3300 XL 5/8mm Proximitor Sensor
330180-X0-05	3300 XL 5/8mm Proximitor Sensor
330190-XXX-01-05	3300 XL 8MM
330195-02-12-05-05	Cable
330195-02-12-10-05	PROBE, REVERSE MOUNT
3301HA1S1V3AE0105RAE1M1	Transmitter, Level

Starfish PPS - Complete Catalog

Part Number	Description
3301HA1S1V3AE0109RAE1M1C1	Transmitter, Level
3301HA1S1V3AE0202RAE1M1C1	TRANSMITTER
3301HA1S1V3AE0305RAE1C1	TRANSMITTER, LEVEL, GUIDE WAVE RADAR
3301HA1S1V3AE0305RAKA	TRANSMITTER, GUIDED WAVE RADAR
3301HA1S1V3AE0401RAE1	Transmitter, Level
330425-01-05	ACCELEROMETER
330500-02-01	Velomitor, 2 wire
330525-01	PROBE, VELOMITER
330701-0-15-50-01-05	PROBE, 11MM, 3300 XL
330701-01-41-10-02-00	PROBE 3300 XL 11MM - 1/2-20
330701-01-41-10-02-05	PROBE 3300 XL 11MM - 1/2-20
330705-02-18-10-02-00	PROBE 3300 XL 11MM 3/8-24 REVERSE
330707-0-22-10-02-00	PROBE 3300 XL 11MM 5/8-18
330708-00-20-50-02-00	PROBE, 3300 XL, ARMORED
330730-080-00-00	CABLE EXTENSION 3300 XL 11MM
330730-080-00-05	CABLE EXTENSION 3300 XL 11MM
330750-60	Transducer
330780-90-00	PROXIMITOR, 3300 XL 11MM
330780-90-05	PROXIMITOR, 3300 XL 11MM
330800-28-00-085-03-02	Probe, Vibration
330850-90-05	PROXIMITOR 25MM 3300XL
330851-04-0-40-50-00-05	PROBE, 25MM, 3300 XL
330851-04-00-27-10-01-00	3300 Probe XL, 25mm
330851-05-0-27-10-00-05	PROBE 25MM 3300 XL
330854-080-24-00	Cable, Extension
330854-080-24-05	EXTENSION CABLE 3300 XL 25MM
330876-03-90-01-00	PROBE, BENTLY NEVADA
330878-90-00	Proximitor Sensor 50MM 3300XL
330878-90-05	Proximitor Sensor
330880-28-00-085-02-02	Probe, Vibration
330880-28-00-085-03-02	Probe, Vibration
330880-28-00-105-02-02	Probe, Vibration
330880-28-00-105-03-02	PROBE, VIBRATION
330880-28-00-136-03-02	VIBRATION PROBE ASSEMBLY
330881-16-00-250-00-02	PROBE
330901-51-82-10-02-00	PROBE PROXIMITY 3300 NSV 1/4-28 UNF
330930-040-00-00	CABLE, EXTENSION, 3300 NSv
330930-060-00-00	3300 NSV EXTENSION CABLE
331B6301G0001	Cable
334A1012P0001	Cable, Electrical, Driver
334A1018P0001	Cable, Electrical, Feedback
334A1019P0001	Cable, Electrical, Feedback
334A1020P0001	Cable, Electrical, Driver
334A1074P0001	Sprint Valve
334A1077P0001	Sprint Valve
334A1137P0001	MODULE, 16 CHAN
334A1216P0001	RELAY
334A1427P0001	CIRCUIT BREAKER, 440VAC/125DC, 2P
334A1434P0001	RELAY CONTACTS
334A1439P0001	Cooler
334A3725P0001	Woodward valve
334A3764P0001	Hose Assembly

Starfish PPS - Complete Catalog

Part Number	Description
334A3940P0001	SENSOR, GAS
334A4116P0001	Hose, Jacking
334A4117P0001	Hose, Jacking
334A4118P0001	Hose, Jacking
334A4842P0001	CONVERTER, 24VDC
334A4910P0001	Pump, VFD
334A4911P0001	Pump, VFD
334A4916P0001	POWER SUPPLY
334A4982P0001	FUSE
334A5052P0001	NUT, SS
334A5059P0001	CABLE, ELECTRICAL CONTROL
334A5061P0001	CABLE, VSV SERVO
334A5062P0001	Cable, TC, T48
334A5065P0001	Cable, T3
334A5066P0001	CABLE, UV FLAME SENSOR
334A5077P0001	GEARBOX, ROTOJET
334A5110P0001	ADAPTER
334A5127P0001	VALVE,BUTTERFLY,ACTUATOR
334A5128P0001	VALVE,BUTTERFLY,ACTUATOR
334A5158P0001	Flow Transmitter
334A5197P0001	TRANSDUCER, LINEAR
334A5217P0001	FILTER
334A5299P0001	CONNECTOR & CABLE
334A5370P0001	Cable, Dual Element (200 ohm RTD)
334A5462P0001	ADAPTER, 90 DEG
334A5498P0001	Pump, Lube, DC
334A5498P0002	PUMP
334A5527P0001	BOLT
334A5528P0001	NUT, LOCK
334A5528PP0001	NUT, LOCK
334A5604P0001	Heater
334A5641P0001	ASSEMBLY: GAS DETECTOR, 505, METRIC
334A5641P0002	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
336A4929G1	Cable
336A4937AAG170	CABLE, PBUS POWER, JPDH TO TBCI-JE1, 170IN
336A4937BKG004	Cable, Mark VI
336A4937BKG008	Cable, Mark VI
336A4937BKG010	Cable, Mark VI
336A4937BKG072	CABLE, PBUS POWER, JPDH TO PACK, BLK, 72IN
336A4937BKG084	Cable, Mark VI
336A4937BKG216	Cable, Mark VI
336A4937BKG264	CABLE, MARK VI
336A4937BUG004	Cable, Mark VI
336A4937BUG010	Cable, Mark VI
336A4937BUG084	Cable, Mark VI
336A4937BUG168	CABLE, MARK VI
336A4937BUG180	Cable, Mark VI
336A4937EAG010	Cable, Mark VI
336A4937EDG060	Cable, Mark VI
336A4937EDG120	CABLE, P03S, POWER SUPPLY TO JPDS, 120IN
336A4937EEG144	Cable, Mark VI
336A4937EEG216	Cable, Mark VI

Starfish PPS - Complete Catalog

Part Number	Description
336A4937EFG072	Cable, Mark VI
336A4937EFG080	CABLE, PBUS POWER, JPDS/JPDM TO ETHERNET SW
336A4937EFG150	Cable, Mark VI
336A4937EHG030	Cable, Mark VI
336A4937EHG080	Cable, Mark VI
336A4937EWG065	WIRES, 65"JPDB-JACX/600W PS
336A4937FHG145	CABLE, PBUS POWER, JPDM-J1/TSVC-J28, 145IN
336A4937GNG030	CABLE, ACRO150W 28VDC OUT 9PIN MNL-30
336A4937RDG004	Cable, Mark VI
336A4937RDG010	Cable, Mark VI
336A4937RDG084	Cable, Mark VI
336A4937RDG108	CBL, PAC PWR, RED 108IN
336A4937RDG180	WIRES, 180IN PAC POWER-JPDL 20AW
336A4937RDG200	Cable, Mark VI
336A4940CTP2	RACK
336A4940DNP508FX2M	SWITCH, ETHERNET
336A4940DNP508FX2M-S	SWITCH, ETHERNET, SURPLUS
336A4940DNP508TX	SWITCH, ETHERNET
336A4940DNP509FX	SWITCH, ETHERNET
336A4940DNP516TX	SWITCH, ETHERNET
336A4940DNP516TX-AR	SWITCH, ETHERNET, AS REMOVED
336A4940DNP517FX	SWITCH, ETHERNET
336A4940DNP517FX-S	SWITCH, ETHERNET, SURPLUS
336A4940DTP10BK	Cable, Mark VI
336A4940DTP10BL	Cable, Mark VI
336A4940DTP10RD	Cable, Mark VI
336A4940DTP11BL	Cable, Mark VI
336A4940DTP12BL	Cable, 12ft
336A4940DTP12RD	Cable, Mark VI
336A4940DTP14BL	Cable, Mark VI
336A4940DTP14RD	CABLE, MARK VI
336A4940DTP15BL	Cable, Mark VI
336A4940DTP18RD	CABLE, MARK VI
336A4940DTP20BK	CABLE, MARK VI
336A4940DTP4BK	Cable, Mark VI
336A4940DTP4BL	Cable, Mark VI
336A4940DTP4RD	Cable, Mark VI
336A4940DTP5BK	Cable, Mark VI
336A4940DTP5BL	Cable, Mark VI
336A4940DTP5RD	Cable, Mark VI
336A4940DTP6BK	Cable, Mark VI
336A4940DTP6BL	Cable, Mark VI
336A4940DTP6RD	Cable, Mark VI
336A4940DTP7BK	Cable, Mark VI
336A4940DTP7BL	Cable, Mark VI
336A4940DTP7RD	Cable, Mark VI
336A4940DTP8BK	Cable, Mark VI
336A4940DTP8BL	Cable, Mark VI
336A4940DTP8RD	Cable, Mark VI
336A4940DTP9BK	Cable, Mark VI
336A4940DTP9BL	Cable, Mark VI
336A4940DTP9RD	Cable, Mark VI

Starfish PPS - Complete Catalog

Part Number	Description
336A5026BGP4BL	Cable
336A5026P01	CABLE, ADAPTER
336A5126AGP1	DIODE
336A5196AAP8	CARD, COMPACT FLASH MEMORY
341A2967P0026	GASKET, SPIRAL WOUND, 7"ID X 8"OD, GRAPHITE FILL SS, ROUND
341A2967P0068	Gasket
341A2967P0132	Gasket, Spiral Wound, 24" ID x 25-1/2" OD, Flexitallic, Carl THK, 316L SS, Round, NS
341A2968P0025	GASKET, SPIRAL WOUND, 5-7/8"ID X 6-15/16"OD, GRAP 3/16" THK, SS, ROUND
341A2968P0128	GASKET
341A2968P0178	GASKET
341A4533G0001	Seal
342A3647P480W28	Power Supply
342A3647P960W28	Power Supply
342A3647PD40A48	Diode
342A3648P240W28	Power Supply, 240W, 125DC>28DC
342A3648P480W28	Power Supply,480W 28VDC
342A3648P960W24	Power Supply
342A3648P960W28	
342A3648P960w28	
342A4922P28V150DHNC	POWER SUPPLY, MARK VI
342A4922P28V150DL	POWER SUPPLY; MARK VI
342A4922P28V150DLA	POWER SUPPLY, MARK VI
342A4922P28V500DL	POWER SUPPLY; MARK VI
344A9322G005	Vibration Cable
3466-348-AR	WWARD SIO
347A5056P001	VALVE, SOL, BLEED AIR
347A5056P001COIL	VALVE, SOL, BLEED AIR, REPLACEMNT
347A5056P002	VALVE, SOL, BLEED AIR
347A5056P004	VALVE, SOL, BLEED AIR
3500/05-01-01-01-00-00	Rack
3500/15-01-00-00	ASSEMBLY: POWER SUPPLY
3500/15-01-00-01	ASSEMBLY: POWER SUPPLY
3500/15-01-01-00	ASSEMBLY: POWER SUPPLY
3500/15-01-01-01	ASSEMBLY: POWER SUPPLY
3500/15-01-02-00	ASSEMBLY: POWER SUPPLY
3500/15-01-02-01	ASSEMBLY: POWER SUPPLY
3500/15-01-03-00	ASSEMBLY: POWER SUPPLY
3500/15-01-03-01	ASSEMBLY: POWER SUPPLY
3500/15-01-04-00	ASSEMBLY: POWER SUPPLY
3500/15-01-04-01	ASSEMBLY: POWER SUPPLY
3500/15-02-00-00	ASSEMBLY: POWER SUPPLY
3500/15-02-00-01	ASSEMBLY: POWER SUPPLY
3500/15-02-01-00	ASSEMBLY: POWER SUPPLY
3500/15-02-01-01	ASSEMBLY: POWER SUPPLY
3500/15-02-03-00	ASSEMBLY: POWER SUPPLY
3500/15-02-03-01	ASSEMBLY: POWER SUPPLY
3500/15-02-04-00	ASSEMBLY: POWER SUPPLY
3500/15-02-04-01	ASSEMBLY: POWER SUPPLY
3500/15-03-00-00	ASSEMBLY: POWER SUPPLY
3500/15-03-00-01	ASSEMBLY: POWER SUPPLY

Part Number	Description
3500/15-03-01-00	ASSEMBLY: POWER SUPPLY
3500/15-03-01-01	ASSEMBLY: POWER SUPPLY
3500/15-03-02-00	ASSEMBLY: POWER SUPPLY
3500/15-03-02-01	ASSEMBLY: POWER SUPPLY
3500/15-03-04-00	ASSEMBLY: POWER SUPPLY
3500/15-03-04-01	ASSEMBLY: POWER SUPPLY
3500/15-04-00-00	ASSEMBLY: POWER SUPPLY
3500/15-04-00-01	ASSEMBLY: POWER SUPPLY
3500/15-04-01-00	ASSEMBLY: POWER SUPPLY
3500/15-04-01-01	ASSEMBLY: POWER SUPPLY
3500/15-04-02-00	ASSEMBLY: POWER SUPPLY
3500/15-04-02-01	ASSEMBLY: POWER SUPPLY
3500/15-04-03-00	ASSEMBLY: POWER SUPPLY
3500/15-04-03-01	ASSEMBLY: POWER SUPPLY
3500/15-04-04-00	ASSEMBLY: POWER SUPPLY
3500/15-04-04-01	ASSEMBLY: POWER SUPPLY
3500/15-05-00-01	POWER SUPPLY, AC
3500/20-01-01-00	ASSEMBLY: RACK INTERFACE
3500/20-01-01-01	ASSEMBLY: RACK INTERFACE
3500/20-01-02-00	ASSEMBLY: RACK INTERFACE
3500/20-01-02-01	ASSEMBLY: RACK INTERFACE
3500/20-02-01-00	ASSEMBLY: RACK INTERFACE
3500/20-02-01-01	ASSEMBLY: RACK INTERFACE
3500/20-02-02-00	ASSEMBLY: RACK INTERFACE
3500/20-02-02-01	ASSEMBLY: RACK INTERFACE
3500/22-01-01-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-01-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-01-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-02-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-02-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-02-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-01-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-01-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-01-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-02-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-02-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-02-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22M	MODULE, STANDARD TRANSIENT DATA INTERFACE
3500/25-01-01-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-01-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-01-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-02-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-02-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-03-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-03-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-03-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-04-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-04-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-05-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-05-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-01-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-01-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR

Part Number	Description
3500/25-02-01-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-02-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-02-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-03-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-03-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-03-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-04-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-04-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-05-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-05-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/32-01-00	MODULE, 4-CHANNEL RELAY
3500/32-01-01	MODULE, 4-CHANNEL RELAY
3500/32-01-02	MODULE, 4-CHANNEL RELAY
3500/40-01-00	ASSEMBLY: MONITOR, PROXIMITOR
3500/40-01-01	ASSEMBLY: MONITOR, PROXIMITOR
3500/40-02-00	ASSEMBLY: MODULE, PROXIMITOR
3500/40-02-01	ASSEMBLY: MODULE, PROXIMITOR
3500/40-03-00	ASSEMBLY: MODULE, PROXIMITOR
3500/40-03-01	ASSEMBLY: MODULE, PROXIMITOR
3500/40-03-02	ASSEMBLY: MODULE, PROXIMITOR
3500/40-04-00	ASSEMBLY: MODULE, PROXIMITOR
3500/40-04-01	ASSEMBLY: MODULE, PROXIMITOR
3500/40M	MONITOR, PROXIMITOR
3500/42-01-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-01-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-02-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-02-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-03-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-03-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-04-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-04-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-04-02	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-05-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-05-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-05-02	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-06-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-06-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-06-02	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-07-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-07-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-08-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-08-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-09-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-09-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-10-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-10-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42M	MONITOR, PROX/SEISMIC
3500/44-01-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-01-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-01-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-02-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-02-01	ASSEMBLY: MODULE, AERODERIVATIVE

Part Number	Description
3500/44-03-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-03-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-05-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-05-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-05-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-06-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-06-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-07-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-07-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-07-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-08-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-08-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-08-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44M	MONITOR, AERODERIVATIVE
3500/50M	MODULE, TACHOMETER
3500/64-01-00	ASSEMBLY: DYNAMIC PRESSURE
3500/64-01-01	ASSEMBLY: DYNAMIC PRESSURE
3500/64-01-02	ASSEMBLY: DYNAMIC PRESSURE
3500/64-02-00	MODULE, I/O
3500/64-02-01	MODULE, I/O
3500/64-02-02	MODULE, I/O
3500/64M	MONITOR, DYNAMIC PRESSURE
3500/91-01-01-00	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-01-01	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-01-02	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-02-00	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-02-01	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-02-02	ASSEMBLY: GATEWAY COMMUNICATION
3500/91M	MODULE, EGD GATEWAY
3500/92	MODULE, COMMUNICATION GATEWAY
3500/92-01-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-01-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-01-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-02-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-02-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-02-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-03-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-03-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-03-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-04-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-04-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-04-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/93	ASSET, CONDITIONING MONITOR
350500-00-00-00-01-01 (mod 161472-01)	Amp, Dyn Pressure
350500-00-00-00-11-05	AMPLIFIER, PRESSURE, BENTLY NEVADA
3507598	Filter, Element
350900-023	Accelerometer
350900-044	Accelerometer
350900-077	Accelerometer
350900-083	Accelerometer
350A4013P0001	Key
351A3236P0001	Pick Up, Magnetic

Starfish PPS - Complete Catalog

Part Number	Description
351A3236P001	Pick Up, Magnetic
351A3445P0002	Thermocouple
351A3488P003	Thermocouple type K.ext.
351A3488P005	THERMOCOUPLE, WHEELSPACE
351A3488P006	THERMOCOUPLE
351A3488P023	Wheel-space Thermocouple
351A3488P024	THERMOCOUPLE
351A3488P029	THERMOCOUPLE
351A3488P031	THERMOCOUPLE
351A3496P008	Thermowell, 316
351A7620P104	Kit, Servo
351A9090P012	Pressure Switch
351A9091P002	Switch, Pressure
351A9091P002q	Switch, Pressure
351A9092P003	Switch, Temp
351A9092P014	Switch, Temp
351A9554P001	Hydraulic Pump
351A9623P302	PROBE: TYPE VIBRATION DETECTION
351A9623P502	3300 XL 8MM
351A9623P602	Cable, Proximitior
351A9623P702	3300 XL 5/8mm Proximitior Sensor
353A4330P005	Pressure Transmitter
353B1135P002	Pin
353B1136P001	Pin
353B3535P001	Nut, Round
3543-169	Ring, Spacer, valve
354A1400P001	Seal
354A1513P014	LEAD, FLEXIBLE, SPARK PLUG IGNITION
354A1513P104	Ignition Lead
354A1513P110	Lead, Ignition
354A1513P111	Lead, Ignition
354A1513P112	Lead, Ignition
354A1513P113	Lead, Ignition
354A1513P114	Lead, Ignition
354A1513P134	CABLE, IGNITION SYSTEM
354A1513P140	Lead, Ignition
354A1513P141	Lead, Ignition
354A1513P142	Lead, Ignition
354A1513P143	Lead, Ignition
354A1513P144	Lead, Ignition
354A1513P150	Lead, Ignition
354A1513P151	Lead, Ignition
354A1513P152	Lead, Ignition
354A1513P153	Lead, Ignition, Flexible, 32 foot
354A1513P171	Lead, Ignition
354A1513P172	Lead, Ignition
354A1513P173	Lead, Ignition
354A1513P174	Lead, Ignition
354A1513P181	Lead, Extension
354A1513P184	Lead, Ignition
354A1513P185	Lead, Ignition

Starfish PPS - Complete Catalog

Part Number	Description
354A1513P186	Lead, Ignition
354A1513P187	Lead, Ignition
354A1513P188	Lead, Ignition
354A1513P189	Lead, Ignition
354A1617P001	VALVE, SOLENOID
354A1709P102	Exciter
354A1709P103	Exciter
354A3606P007	VALVE, CHECK
355B6801P001	Nut
356A3211P001	Igniter, HT
356A3217P001	Igniter
357A1233P106	Filter Assembly
357A2304P0001	Gasket
357B1004P012	Pin Dowel
358A6954P001	Flow Regulator
361A2285P007	Detector, Temp
361A2285P113	Detector
361A2289P010	Thermocouple - KK-316LSS12-U-THS(4")-110.0",- WITH A
361A2289P128	Thermocouple
361A2289P135	Thermocouple, Wheelspace
361A2289P148	Thermocouple, Wheelspace
361A2289P193	Thermocouple, Wheelspace
361A2289P327	THERMOCOUPLE, WHEELSPACE
361A2289P330	Thermocouple, Wheelspace
361A2289P332	THERMOCOUPLE, WHEELSPACE
361A2289P333	THERMOCOUPLE, WHEELSPACE
361A2289P335	Thermocouple, Wheelspace
361A2289P336	THERMOCOUPLE, WHEELSPACE
361A2289P337	Thermocouple, Wheelspace
361A2289P672	Thermocouple, Wheelspace
361A2289P766	Thermocouple
361A2327P024	Turbine exhaust thermocouple cable
361A2327P026	CABLE, TC
361A2327P031	Thermocouple
361A2373G001	RTD, Dual
361A2538P003	CLAMP
361A2558P002	Cable, Flame Scanner
361A2943P004	Valve, Check
361A6207P006	VALVE
361A6233P0002	Regualtor
362A1052P004	Flame Sensor
362A1052P104	Flame Sensor
362A1052P404	Flame Sensor
362A1052P406	FLAME TRACKER
362A1053P001	CABLE, UV FLAME DETECTOR
362A1053P002	CABLE, UV FLAME DETECTOR
362A1053P031	CABLE, UV FLAME DETECTOR
362A1053P036	CABLE, UV FLAME DETECTOR
362A1102P017	Thermocouple, Exhaust
362A1102P022	Spring Loaded Thermocouple
362A1331P002	VALVE, CHECK

Starfish PPS - Complete Catalog

Part Number	Description
362A1514P001	Seal, set
362A1591P001	Hose, Flexible, Primary Can
362A1885G001	RTD, Dual
362A1885G008	Thermocouple
362A1997P040	CABLE, SERVO
362A1998P040	CABLE, LVDT
362A2968P003	Switch
362A3342P0005	Cable, Interconnect
362A3342P002	CABLE, UV FLAME DETECTOR
362A3342P010	CABLE
362A3345P103	CABLE, T/C
362A3345P105	CABLE, T/C
362A3345P106	CABLE, T/C
362A3345P203	T/C cable
362A3798P002	THERMOCOUPLE
362A3798P004	THERMOCOUPLE
362A3798P023	THERMOCOUPLE
362A3798P026	THERMOCOUPLE
362A3952P001	Igniter, HT
362A6563P001	Actuator
3638-036	FITTING, ROD PORT
363A5542P001	Pressure Switch
363A5542P003	Pressure Switch
363A5542P007	Pressure Switch
363A5542P008	Pressure Switch
363A5542P009	Pressure Switch
363A5542P056	Switch, Pressure
363A5542P066	Switch, Pressure
363A5542P102	Switch, Pressure
363A5542P121	Switch, Pressure
363A5542P123	Switch, Pressure
363A5543P011	Switch, Pressure
363A5543P221	Switch, Pressure
364A7036P0003	KIT, REPAIR
365A3217P001	Igniter
365A3217P003	Igniter
365A3217P004	Igniter
366A772G2	COIL
368887	HOSE, ASSY, HYDRAULIC START RETURN
368A6037P001	Lube Oil Filter
368B4055P001	Carbon Brush
369B1369P0001	Relay
36A167401AAP07	Brush, Electrical Set
36A167402AAP08	Brush, Electrical Set
36C774345AAG01	ASSEMBLY, MFC
371A6417P001	Valve, Control
371A6421P002	VALVE, AUX GAS STOP
372A1159P100	Gasket
372A1159P109	Gasket
372A1159P110	GASKET
372A2221P022	Thermocouple, Exhaust
372A2221P022-AR	THERMOCOUPLE, AS REMOVED

Starfish PPS - Complete Catalog

Part Number	Description
372A2287P010	Thermocouple
372A2287P332	Thermocouple
372A2287P333	Thermocouple
372A2287P336	Thermocouple
372A2287P766	Thermocouple
372A3188P002	Accelerometer
372A3281G001	RTD, Dual
3778008P01	CABLE
377A1000P0001	Motor, Lube
377A1000P001	Motor, Lube
377A1001P0001	Motor, GLO
377A1001P001	Motor, GLO
377A1009P0002	Motor, Electric, Gen Enclosure Fan
377A1024P0000	Element, Filter
377A1047P0000	GASKET, FLANGE, 1IN-150LB, 316SS, SWOR
377A1072P0000	BOLT, HEX
377A1074P0000	NUT, HEX
377A1125P0000	Door Latch
377A1142P0000	Seal, Door
377A1151P0000	Filter
377A1151P0001	Filter
377A1152P0001	FILTER, ELEMENT, 3 MICRON, GLO
377A1164P0000	VALVE, CONTROL
377A1196P0001	Auto/Manual Release SOV
377A1196P0002	CABLE, ELEC, OPR CONTROL HEAD
377A2233P0001	Plain Nut Discharge Head
377A2245P0001	CO2 Hose
377A2245P0002	CO2 Hose
377A2318P0001	Orifice
377A2326P0001	GAUGE, DIFFERENTIAL, 0-30
377A2452P0001	BASKET, STRAINER
377A2492P0001	GUARD, SWITCH RAMP
377A2522P0001	Coupling
377A2540P0001	SWITCH, FLOW
377A2560P0001	BOLT, HEX
377A2561P0001	BOLT, HEX
377A2564P0001	Coupling
377A2584P0001	Sprint Valve
377A2589P0001	Valve
377A2590P0001	Valve
377A2591P0001	Valve, solenoid
377A2687P0001	VALVE, SOLENOID
377A2796P0001	Relay
377A6542P0001	TRANSDUCER, VOLTS LM SERIES
377A6552P0001	Valve, Check
377A6553P0001	Signal conditioner
377A6580P0001	Transmitter
377A6581P0001	Compressor Discharge Pressure PS3
377A6583P0002	Transmitter, pressure
377A6712P0001	SOCKET, TEST BLOCK
377A6716P0001	Innova touch screen
377A6726P0001	MODULE

Starfish PPS - Complete Catalog

Part Number	Description
377A6813P0001	Transmitter, Level, GLO
377A6816P0002	MODULE, SYSTEM, SYNCHRONIZING
377A6847P0003	METER, FLOW
377A6857P0001GSKT	GASKET, 764-SS-2"
377A6857P0001STRN	Y STRAINER BSKT 2" 100 MESH
377A6899P0001	FUSE, MIDGET, 15A
377A6914P0001	PUMP, START
377A6914P0001-AR	PUMP, START
377A6927P0001	Amp, Dyn Pressure
377A6983P0001	Detector, Level
377A7014P024	SRV,W/ 6 INCH FSHR VALVE, DUAL LVDT
377A7053P102	Element, Strainer Basket
377A7701P0001	Valve, solenoid
377A7707P0001	Module, input, fire system
377A7711P0001	Accumulator
377A7725P0001	Cable, Process Control
377A7740P0001	VALVE, SOL
377A7746P0001	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
377A7762P0001	CURRENT OUTPUT & RELAY
377A7763P0001	Exchanger, Heat
377A7763P0002	Exchanger, Heat
377A7807P0001	RTD
377A7811P0001	Gasket
377A7813P0001	GSOV, Woodward
377A7814P0001	MANUAL PULL
377A7825P0001	Valve, Check
377A7866P0002	THERMO VALVE
377A7873P0001	Turnbuckle
377A7898P0001	Y-STRAINER
377A7898P0001-GSKT	GASKET, Y-STRAINER
377A7898P0001-STRN	BASKET, MESH, Y-STRAINER
377A7898P0002	Y-STRAINER
377A7957P0001	SCREEN, INLET, Y-STRAINER
377A7957P0001GSKT	GASKET, INLET SCREEN, Y-STRAINER
377A8007P0001	Valve,fuel
377A8010P0001	Cable, Engine
377A8017P0001	Valve
377A8054P0001	GSOV, Woodward
377A8134P0001	AC Unit
377A8153P0001	Manual Pull Module
377A9841P002	Filter
377A9841P003	Filter
378A1742P0001	VALVE, SOLENOID
379A9705P012	THERMOCOUPLE, WHEELSPACE
379A9705P053	Thermocouple
379A9798P010	Transducer
379A9798P040	Transducer
37C75KSB	SCREW, COUNTERBORE
38-18604-2024-3	Screen ASSY
38-18604-2025-3	Screen ASSY
38-18604-2026-3	Screen ASSY
3813-08-003-C	Valve, Transfer

Starfish PPS - Complete Catalog

Part Number	Description
381A6159P315	Valve
381A6160P306	Valve
381A6160P307	Valve
381A6160P311	Valve
3820-11-001-A	FILTER, HYDRAULIC
382A1079P0001	Transmitter, pressure
382A1201P0001	ISGH FILTER
382A1203P0001	Filter, Element, Sprint
382A1209P0002	Valve, Fuel Metering
382A1213P0001	Bently Nevada Interface Module
382A1250P0001	SEAL
382A1251P0001	Seal
382A1252P0001	Metal Gasket Ring, E Seal
382A1284P0001	WATER INJECTOR PUMP
382A1286P0001	BOLT, HEX
382A1294P0001	SWITCH, FLOW
382A1351P0001	Valve, Check
382A1357P0001	Transmitter
382A1367P0001	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
382A1379P0001	Flame Sensor
382A1426P0001	GAUGE, DIFF PRESSURE
382A1450P0002	EX2100e - Aero Parts Kit
382A3006P0001	Starter Motor
382A3006P0001-AR	Starter Motor
382A3006P0001-OH	Starter Motor
382A3743P0001	RTD Module
382A3746	
382A3746P0001	Logic Fast Input, 16 Point, Grouped
382A3780P0001	VALVE, PRESSURE SAFETY
382A3780P0003	VALVE, PRESSURE SAFETY
382A3781P0001	VALVE, PRESSURE RELIEF
382A3782P0001	VALVE, PRESSURE SAFETY
382A3782P0003	VALVE, PRESSURE SAFETY
382A3791P0001	TRANSMITTER, ROTOR, EARTH FAULT
382A3800P0001	VBV Boot
382A3860P0100	Starter Motor
382A3860P0H1B	MOTOR, STARTER
382A3861P0100	Clutch
382A3861P0100-OH	Clutch
382A3918P0001	GASKET, SPIRAL WOUND
382A3918P6005	GASKET, SPIRAL WOUND
382A3945P0001	PLUG, C 8 WIRE
382A3946P0001	CONNECTOR, H-SHAPED
382A3947P0001	CAP
382A3948P0001	CABLE, TERMINAL BLOCK
382A4000P0001	450 Degree Thermal Spot Detector
382A4003P0001	Strobe Dual Listed ATEX, UL
382A4068P001	VALVE, SOLENOID
382A4154P0001	FOD Sock
382A4161P0001	TLO Filters Differential Pressure Switch
382A4168P0001	Switch, pressure
382A4169P0001	Switch, Pressure, Adj.

Starfish PPS - Complete Catalog

Part Number	Description
382A4170P0001	Switch, Temperature
382A4171P0001	SWITCH, TEMPERATURE, ADJUSTABLE
382A4172P0001	Switch, Pressure
382A4173P0001	SWITCH, PRESSURE
382A4174P0001	Switch, Pressure
382A4449P0001	ASSEMBLY: DETECTOR, GAS, COMBUSTIBLE, 505, ME
382A4454P0001	Gasket, FLG
382A4465P0001	Flame Sensor
382A4495P0001	CABLE, LIQUID FUEL VALVES
382A4496P0001	CABLE, LIQUID FUEL VALVES
382A4497P0001	CABLE, DRAIN VALVES
382A4501P0001	VICOR, DC CONVERTER
382A4544P0001	POWER SUPPLY
382A4546P0001	MODULE, RELAY
382A4652P0001	Detector, gas
382A4669P0001	Flame Sensor
382A4670P0001	Flame Sensor Mounting Arm
382A4677P0001	VALVE, NEEDLE
382A4694P0001	FLOW METER,VORTEX
382A4695P0002	ASSEMBLY, METER/CONVERTER, FLOW, 2IN
382A4720P0001	SENSOR, GAS
382A4742P0001	Pump, Jacking Oil
382A4762P0001	A30 Con Complete
382A4774P0001	Generator/Gearbox DC Lube Pump
382A4775P0001	Motor, GLO Lube
382A4776P0001	Magnetrol Switch
382A4821P0001	VALVE, FLOW CONTROL, WATER INJ.
382A4821P0001-AR	AS REMOVED VALVE, WATER
382A4828P0001	Woodward Driver
382A4828P0001-AR	WOODWARD DRIVER
382A4848P0001	Transmitter
382A4866P0001	PSM-ME-RS232/RS485
382A4891P0001	TBV Gasket
382A5230P0001	MOTOR
382A5237P0001	C10 Low Speed Detector
382A5248P0001	Switch, pressure
382A5249P0001	switch, pressure
382A5250P0001	Switch, Press., Adj., Diff.
382A5254P0001	VALVE, SOL
382A5275P0002	GSOV
382A5291P0001	PRESSURE, DIFF
382A5322P0001	Gas Valve, Woodward
382A5340P0002	FLOWMETER AND CONVERTER ASSEMBLY
382A5355P0001	TRANSMITTER, PRESSURE
382A5355P0003	TRANSMITTER, PRESSURE
382A5374P0002	Flow Meter - Nox Water
382A5374P0003	Flow Meter - Nox Water
382A5376P0001	TRANSMITTER, PRESSURE
382A5380P0001	Cable
382A5391P0001	450 Degree Thermal Spot Detector
382A5392P0001	450 Degree Thermal Spot Detector
382A5412P0001	SWITCH, HORN

Starfish PPS - Complete Catalog

Part Number	Description
382A5412P0002	SWITCH, HORN
382A5419P0001	STROBE
382A5426P0001	Gen Lube Pump
382A5454P0001	VALVE, BYPASS
382A5465P0002	Valve, solenoid
382A5471P0002	Valve, solenoid
382A5476P0002	Valve
382A5485P0001	Valve, Control
382A5488P0001	Washer
382A5489P0002	Fuel Manifold Drain Valve
382A5504P0002	Valve
382A5505P0002	Valve, Solenoid, Fuel Manifold
382A5506P0002	Nat Gas vent valve
382A5507P0002	Heater
382A5508P0002	Heater, GLO
382A5509P0002	Heater
382A5510P0001	HEATER
382A5510P0002	Heater
382A5512P0001	Exchanger, Heat
382A5517P0001	Gland, cable
382A5519P0001	MOTOR, START
382A5524P0001	GSOV
382A5526P0001	VALVE, DRAIN
382A5528P0001	Valve, Fuel, Liquid
382A5530P0001	Valve
382A5532P0001	Valve
382A5533P0001	Valve, Metering
382A5533P0002	Valve, Metering
382A5547P0001	Motor, GLO Lube
382A5578P0001	Pump, Water Wash
382A5582P0001	Relay
382A5582P01	Relay
382A5599P0001	Probe, Vibration
382A5610P0001	Heater
382A5619P0001	Nozzle
382A5640P0001	VALVE, SOL
382A5646P0001	VALVE, SOLENOID
382A5648P0001	Fan, Generator
382A5652P0001	
382A5653P0001	FILTER HOUSING ASSEMBLY
382A5653P0002	FILTER HOUSING ASSEMBLY
382A5655P0001	TRANSMITTER
382A5656P0001	TRANSMITTER
382A5656P0003	TRANSMITTER
382A5656P0004	TRANSMITTER
382A5657P0001	TRANSMITTER, PRESSURE
382A5658P0001	Fuel Gas Pressure Transmitter
382A5658P0003	Transmitter, pressure
382A5659P0001	SENSOR, PRESSURE
382A5660P0001	TRANSMITTER, PRESS
382A5661P0001	Transmitter, pressure
382A5662P0001	Transmitter, pressure

Starfish PPS - Complete Catalog

Part Number	Description
382A5669P0001	HEATER
382A5672P0001	Switch, Level
382A5673P0001	Transmitter, Diff
382A6205P0001	AIR CONDITIONER
382A6206P0001	AIR CONDITIONER
382A6217P0001	IR Gas Detector
382A6227P0001	VALVE, CHECK
382A6229P0001	Transmitter, Level
382A6232P0001	SHAFT, GEN. VENT FAN
382A6235P0001	TRANSMITTER
382A6238P0001	MODULE. DCIO, DIN RAIL
382A6238P0001-AR	MODULE, DCIO, AS REMOVED
382A6241P0001	Dry Line Discharge Pressure Switch
382A6242P0001	SENSOR, FLAME
382A6242P0002	SENSOR, FLAME
382A6250P0001	SWITCH, DOOR
382A6265P0001	CO2, MANUAL PULL
382A6272P0001	PUMP, LIQUID
382A6280P0001	Valve, Check
382A6287P0001	Wire, CABLE, TRAY
382A6293P0001	CABLE
382A6294P0001	Cable
382A6294P001	Cable
382A6298P0001	4 WIRE (12AWG), 3 INS & 1 BARE
382A6317P0001	Valve, LQ25
382A6329P0001	THREAD CONVERTER, 3 INCH TO 2 INCH
382A6332P0001	WIRE,SHIELDED
382A6335P0001	GLO Pressure Transmitter
382A6340P0001	VALVE, SOL
382A6342P0001	Term Block
382A6345P0001	4" Single Expansion Joint
382A6353P0001	Valve, CDP
382A6354P0001	Valve, CDP
382A6354P0001-OH	VALVE, CDP
382A6355P0001	Valve, CDP
382A6355P0001-OH	VALVE, CDP
382A6356P0001	Valve, drain
382A6388P0001	Auto/Manual Release SOV
382A6389P0001	COUPLING, COMPLETE- MOTOR HUB, PUMP HUB, NEC INSERT
382A6399P0001	Valve, Solenoid
382A6400P0001	Valve
382A6402P0001	SWITCH, HORN
382A6459P0001	CABLE
382A6461P0001	VALVE, CHECK
382A6461P0002	Valve, Check
382A6517P0001	Pump, Start
382A6540P0001	Cable, RTD
382A656548P0001	Fan, Generator
382A6600P0001	CABLE, NPT SPEED
382A6604P0001	Cable, T3
382A6621P0001	Valve, Check

Starfish PPS - Complete Catalog

Part Number	Description
382A6632P0002	Pump
382A6641P0001	Valve, Check
382A6646P0001	CABLE, DUAL RTD/VSV LVDT, T2 SENSOR
382A6647P0001	Cable, Sensor
382A6662P0001	BOLT
382A6668P0001	Valve, Control
382A6674P0001	Valve, Check
382A6688P0001	TRANSMITTER, PRESSURE
382A6793P0001	WIRE
382A6798P0001	WIRE
382A7005P0001	TRANSFORMER, CURRENT
382A7010P0001	PUMP, MLO AC Pump
382A7010P0002	PUMP, MLO AC Pump
382A7010P0003	PUMP, MLO AC Pump
382A7013P001	Pump, Lube, DC
382A7014P0002	Element, Filter, MLO
382A7024P0001	Exchanger
382A7051P0001	Pump, VFD
382A7064P0001	Pump Motor Assembly
382A7067P0001	Valve, Check
382A7123P0001	VALVE, GAS SHUTOFF
382A7146P0001	Valve, External Gas Fuel Vent
382A7169P0001	Valve
382A7174P0001	Gauge
382A7180P0001	Transmitter, Level
382A7186P0001	Valve, Relief, 3-Inch - 24 VDC - Gas blowoff Valve
382A7186P0001-AR	Valve, Relief, 3-Inch - 24 VDC - Gas blowoff Valve - AS RE
382A7188P0001	Valve, Control, LQ25
382A7188P0001-AR	Valve, Liquid Fuel
382A7191P0001	VALVE, BALL, MANUAL, 3 IN, SCHEDULE 40
382A7191P0002	VALVE, BALL, MANUAL, 3 IN, SCHEDULE 40
382A7198P0001	Valve, Water
382A7198P0001-AR	VALVE, WATER, AS REMOVED
382A7203P0001	Y STRAINER, INLET SCREEN
382A7203P0001BSKT	SCREEN, REPLACEMENT, 100 MESH
382A7203P0001GSKT	Y STRAINER GASKET
382A7215P0001	Lube Pump
382A7236P0001	Valve, Drain, Manifold
382A7241P0001	WASHER, BEVELED
382A7257P0001	Cable, Off-Engine
382A7258P0001	Cable, Off-Engine
382A7259P0001	Cable, Off-Engine
382A7260P0001	Cable, Off-Engine
382A7261P0001	Cable, Off-Engine
382A7262P0001	Cable, Off-Engine
382A7264P0001	Cable, Off-Engine
382A7265P0001	Cable, Off-Engine
382A7266P0001	Cable, Off-Engine
382A7267P0001	Cable, Off-Engine
382A7268P0001	Cable, Off-Engine
382A7269P0001	Cable, Off-Engine
382A7270P0001	Cable, Off-Engine

Part Number	Description
382A7271P0001	Cable, Off-Engine
382A7272P0001	Cable, Off-Engine
382A7273P0001	Cable, Off-Engine
382A7274P0001	Cable, Off-Engine
382A7275P0001	Cable, Off-Engine
382A7276P0001	Cable, Off-Engine
382A7277P0001	Cable, Off-Engine
382A7278P0001	Cable, Off-Engine
382A7279P0001	Cable, Off-Engine
382A7280P0001	Cable, Off-Engine
382A7281P0001	Cable, Off-Engine
382A7282P0001	Cable, Off-Engine
382A7283P0001	Cable, Off-Engine
382A7284P0001	Cable, Off-Engine
382A7285P0001	Cable, Off-Engine
382A7286P0001	Cable, Off-Engine
382A7287P0001	Cable, Off-Engine
382A7292P0001	TRANSMITTER, PRESSURE
382A7293P0001	TRANSMITTER, PRESSURE
382A7296P0001	ASSEMBLY: METER, FLOW
382A7298P0001	METER, FLOW
382A7299P0002	Flow Meter, linear link
382A7300P0001	Cable
382A7308P0001	Drain Trap
382A7308PP0001	TRAP, DRAIN
382A7311P0001	Motor, Hydraulic Starter
382A7312P0001	Nozzle, Size 10
382A7315P0001	ASSEMBLY: DETECTOR, GAS
382A7318P0001	ASSEMBLY: POWER SUPPLY
382A7319P0001	Block, External Termination
382A7322P0001	Valve, Fuel, Metering
382A7325P0001	VALVE, PURGE
382A7325P0001-AR	VALVE, PURGE
382A7326P0001	VALVE, VENT
382A7327P0001	ASSEMBLY: INTERFACE, TRANSIENT DATA
382A7328P0001	ASSEMBLY: GATEWAY COMMUNICATION
382A7329P0001	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
382A7330P0001	SENSOR, FLAME
382A7331P0001	ASSEMBLY: MONITOR, PROXIMITOR
382A7332P0001	ASSEMBLY: MONITOR, PROX/SEISMIC
382A7333P0001	Block, External Termination
382A7334P0001	Block, Term
382A7335P0001	RACK, INSTRUMENT
382A7348P0001	FILTER
382A7352P000	CONTROLLER, PANEL MOUNT
382A7362P0001	ACCUMULATOR, HYDRAULIC
382A7363P0001	ACCUMULATOR, HYDRAULIC
382A7370P0002	Pump, Hydraulic
382A7370P0003	Pump, Hydraulic
382A7380P0001	VALVE, RELIEF
382A7393P0001	VALVE, PRESS CONTROL
382A7394P0001	VALVE, PRESS CONTROL

Starfish PPS - Complete Catalog

Part Number	Description
382A7395P0001	VALVE, SOLENOID
382A7408P0002	LIQUID FUEL
382A7408P0003	LIQUID FUEL
382A7409P0004	PUMP, WATER INJECTION
382A7422P0000	Pump, Water Wash
382A7450P0001	Valve, Shut Off
382A7451P0001	VALVE, CONTROL, ASSY
382A7487P0001	Valve, Check
382A7496P0001	Check Valve
382A9205P0001	Accelerometer
382A9206P0001	Accelerometer
382A9207P0001	Accelerometer
382A9208P0001	Accelerometer
382A9209P0001	Accelerometer
382A9210P0001	Accelerometer
382A9215P0001	Signal conditioner
382A9227P0001	PLATE, ORIFICE
382A922PV500DL	Accelerometer
382A9245P0001	HEATER 5KW CHROMALOX
382A9246P0001	HEATER
382A9250P0001	HEATER
382A9252P0001	FLAME ARRESTER
382A9253P0001	CABLE, WOODWARD
382A9254P0001	CABLE ASSEMBLY, LOW DENS. ANALOG,12FT
382A9255P0001	CABLE-MICRONET HIGH DENSITY
382A9258P0001	PUMP, STARTER
382A9260P0001	Probe, Vibration
382A9359P0001	Flow METER
382A9359P0002	METER, FLOW
382A9360P0001	Flow Regulator
382A9361P0001	Flow Regulator
382A9372P0001	STUD
382A9374P0001	STUD
382A9406P0001	Power Supply
382A9408P0001	Detector, Temp
382A9462P0001	Valve, Solenoid
382A9518P0001	TEMP, ELEMENT
382A9529P0001	Cable, Off-Engine
382A9540P0001	Filter, H2O Injection Skid
382A9594P0001	HEATER, IMMERSION, 3", 150 LB RAIS
382A9602P0001	DUPLEX, GAS, FUEL, 3" 3um
382A9606P0001	Filter Element
382A9622P0001	Cable, Accelerometer
382A9623P0001	Cable, NPT Speed
382A9625P0001	Cable, Electrical
382A9634P0001	Switch, Ethernet, 8 Port
382A9637P0001	RTD, MLO Tank
383543	Shaft, Fan, Gen
383A4156P0020	DIGITAL SPEED SENSOR
383A4156P0032	MODULE, I/O
383A4156P0058	Module, Micronet, Analog I/O
383A4156P0058-OH	MODULE, OVERHAULED

Starfish PPS - Complete Catalog

Part Number	Description
383A4156P0065	Module, Actuator Netcon CONT.2C
383A4205P0002	Diode Module
3840-01-021	Filter, H2O Injection Skid
3850-14-009	DUPLEX, GAS, FUEL, 3" 3um
3862-4	Kit, Clamshell
3862-5	Bolt Kit LPC Inlet Expansion
3862-6	KIT, BOLT, VBV DUCT
3862-7	KIT, BOLT, VBV DUCT, EXPANDED
386A3003P0001	450 Degree Thermal Spot Detector
386A3008P0001	225 Degree Thermal Spot Detector
386A3009P0001	THERMAL BET
386A3014P0001	4-20 mA Gas Module
386A3018P0001	Status Module
386A3089P0001	CHASSIS
386A3092P0001	450 Degree Thermal Spot Detector
386A3125P0001	HORN, DUAL
386A3126P0001	HORN
386A3126P0002	HORN
386A3127P0001	DETECTOR, THERMAL SPOT, 450 DEGREE
386A3136P0001	STROBE
386A3142P0001	Nozzle, Size 9+
386A3175P0001	VALVE, BLOCK, 2-WAY, COAX
386A3176P0001	Valve, 3 way
386A3188P0001	Element Kit, Filter
386A3206P0001	Cooler
386A3206P0002	EXCHANGER, HEAT
386A3227P0002	Pump, lube oil
386A3227P0003	PUMP, LUBE OIL
386A3384P0001	HORN
386A3385P0002	Woodward DRIVER
386A3537P0001	SIGHT GLASS
386A3567P0001	GAUGE, SIGHT
386A3568P0001	Fan, Vent
386A3568P0002	Fan, Vent
386A3587P0001	MODULE, I/O
386A3662P0001	Washer
386A3695P0001	SWITCH, LEVEL
386A3793P0008	VALVE, GLOBE, 2IN, 150LB, RAISED FACE
386A3796P0001	BOLT, HEX
386A3798P0001	BOLT, HEX
386A3811P0001	Valve, solenoild, J3 Pressurization
386A3904P0001	Module, Transformer
386A3985P0002	Motor, 200 HP
386A6008P0001	DETECTOR, TEMPERATURE
386A6008P0002	RTD
386A6401P0001	Manifold, inlet flow straightener
386A6409P0001	SIGHT GLASS
386A6434P0001	BOLT
386A6466P0001	Cable, Hydraulic Starter Clutch Oil
386A6527P0001	Relay
386A6553P0001	Transmitter, Level
386A6581P0001	Filter

Starfish PPS - Complete Catalog

Part Number	Description
386A6632P0002	Pump Assembly
386A6636P0001	Water Injection Pump Discharge Filter
386A6676P0001	TRANSMITTER
386A6685P0001	Element, Filter, MLO
386A6687P0001	Filter
386A6687P0001-AM	FILTER, AFTERMARKET
386A6700P0001	Transmitter,Level
386A6701P0001	Transmitter, Level
386A6703P0001	Transmitter, Level
386A6778P0001	Nozzle, Size 9
386A6796P0001	4 WIRE (10AWG), 3 NUMBERED INS & 1 BARE
386A6804P0001	VAVLE
386A6857P0001	Valve, Fuel, 2"
386A6860P0001	CABLE, ASSEMBLY, DRIVER TO VALVE
386A6864P0001	Cable, Clutch HTVAS Vibration
386A6873P0001	Accumulator
386A6874P0001	SENSOR, FUEL TEMP
386A6878P0001	Hose, Brush
386A6881P0001	HOSE
386A6889P0001	Clamp
386A6897P0001	ASSEMBLY: DETECTOR, GAS, COMBUSTIBLE, 505, ME
386A6925P0001	Regulator
386A6979P0001	NUT, HEAVY HEX
386A6981P0001	Valve, Check
386A6988P0001	TRANSMITTER, PRESSURE
386A6994P0001	CABLE, ACCEL, CRF/TRF
386A7026P0001	Bellows
386A7026P0001FAB	Expansion Joint
386A7026P0001FABRIC KIT	Expansion Joint
386A7048P0001	VIBRATION PROBE ASSEMBLY
386A7054P0001	BATTERY CHARGER, 24VDC, 150 AMP, 230
386A7061P0001	Cable
386A7063P0001	Cable, Chip Detector
386A7082P0001	POWER SUPPLY; MARK VI
386A7135P0001	Valve
386A7270P0001	Meter, Flow
386A7314P0001	Bolt
386A7315P0001	Washer
386A7361P0001	Pump, LMO
388A1370P0006	Module, Netcon Field Term.
388A1858P0001	Power Supply
389A4510P0001	Board, PC, 505, 500OHM
389A4512P0001	SENSOR, GAS
389A4521P0001	Flame Sensor
389A4639P0001	PLATE, LOCKING, SET OF 20
389A4640P0001	GASKET, HEAT EXCHANGER
389A4658P0001	SEAL, WASHER
389A4827P0001	Stator Gasket Set
389A4853P0001	COMPOUND, LOCKING
389A4911P0001	HEATER, EXCITER, SET OF 3
389A5116P0001	KIT, FUSE, SET OF 5
389A5117P0001	GASKET, SET OF 2

Part Number	Description
389A5222P0001	ASSEMBLY, LOUVRE
389A5224P0001	FILTER, AIR, SET OF 2
389A5345P0001	GASKET, SET OF 2
389A5386P0001	FUSE, 80000 AMP
389A5447P0001	Transmitter, pressure
389A5449P0001	TRANSMITTER, LEVEL, GUIDE WAVE RADAR
389A5453P0001	Detector, gas
389A5471P0001	Heater
38R277	CGI Gasket, 2 1/2", 150#, 304SS
38R289	CGI Gasket, 3", 600#, 304SS
390A0081P0001	FITTING, FEED THROUGH ELECTRICAL
390A0086P0001	ADAPTER WIRELESS AP
390A0112P0002	VALVE, CONTROL
390A0117P0001	Filter Element
390A0206	IP CAMERA
390A0206P0001	IP CAMERA
390A0211P0001	VALVE
390A0250P0001	Valve, Control
390A0415P0001	FLOW METER
390A0499P0001	VALVE, FUEL
390A0754P0001	DVP, 24VDC, IP30, TB Input
390A0756P0001	Cable, Electrical, GSOV
390A0826P0001	HORN
390A1088P0001	FUSE
390A1251P0001	TRANSMITTER
390A1396P0001	Connector
390A1403P0001	LINKNET-HT
390A1404P0001	LINKNET-HT
390A1405P0001	LINKNET-HT
390A1406P0001	LINKNET-HT
390A1407P0001	LINKNET-HT
390A1408P0001	LINKNET-HT
390A1425P0001	Cable, Electrical, Resolver
390A1425P0002	Cable, Electrical, Resolver
390A1426P0001	Cable, Electrical, Power
390A1427P0001	Cable, Electrical, Resolver
390A1427P0002	Cable, Electrical, Resolver
390A1448P0001	DETECTOR
390A1460P0001	SENSOR, TEMPERATURE
390A1528P0001	FLOW METER
390A1530P0001	FLOW CONVERTER
390A1652P0001	Coupling, Start System
390A1773P0001	Transmitter, pressure
390A1783P0001	Transmitter, pressure
390A1784P0001	TRANSMITTER, PRESSURE
390A1826P0001	Pump, VFD
390A1891P0004	FLOW METER
390A1925P0001	Cable, VSV
390A1933P0001	AEROSOL SIGNS
390A2022P0001	BLOWER
390A2026P0001	FLOW METER
390A2046P0001	Transmitter, Level

Starfish PPS - Complete Catalog

Part Number	Description
390A2089P0001	Transmitter, pressure
390A2096P0001	Filter, final
390A2102P0001	RTD, Dual
390A2115P0001	Transmitter
390A2116P0001	VALVE, BALL, 2 INCH
390A2117P0001	VALVE, BALL, 2 INCH
390A2120P0001	VALVE
390A2121P0001	Valve, Gas Shutoff
390A2122P0001	Valve, External Gas Fuel Vent
390A2262P0001	ELEMENT TEMP, FTD PLATINUM
390A2284P0001	SWITCH, CONVERTER, ETHERNET TO FIBER
390A2319P0001	NUT, ZINC PLATED
390A2323P0001	Pump, H2O injection
390A2357P0001	SENSOR
390A2372P0001	BOLT, HEX
390A2434P0001	GAUGE VALVE
390A2438P0001	VALVE, FLOW CONTROL, ASSY
390A2451P0001	VALVE, BALL., 1 1/2IN
390A2451P0001-R0001	VALVE, BALL, 1 1/2 INCH 150 LB RF, S
390A2478P0001	DETECTOR
390A2509P000	CABLE, 2 PAIRS SHIELDED
390A2567P0001	CABLE, 2 PAIRS, SHIELDED
390A2568P0001	CABLE, 1 PAIR, SHIELDED
390A2569P0001	CABLE, SHIELD, 2C/2.5MM, 600/1000V
390A2570P0001	CABLE, SHIELD, 3C/2.5 MM, 600/1000V
390A2742P0001	Valve, Check
390A2757P0001	TRANSMITTER
390A2770P0001	Drain Valve
390A2771P0001	Valve, Shutoff
390A2986P0001	PUMP, STARTER
390A3018P0001	Filter
390A3020P0001	Element, Temp
390A3083P0001	CABLE, 3 FT
390A3095P0001	VALVE, CHECK
390A3117P0001	Detector, Level
390A3130P0001	Valve, Solenoid
390A3135P0001	Valve, Solenoid
390A3139P0001	VALVE, CHECK
390A3140P0001	Turbine Enclosure Fan - Direct Drive
390A3140P0001-AR	Turbine Enclosure Fan - Direct Drive - AS REMOVED
390A3140P0001-OH	Turbine Enclosure Fan - Direct Drive - OVERHAULED
390A3185P0001	Conduit
390A3192P0001	PRESSURE TRANSMITTER
390A3311P0001	Filter
390A3330P0001	DISPLAY, DCU
390A3347P0001	Element, Temp
390A3383P0001	MODULE, EDIO
390A3384P0001	MODULE, EDIO
390A3392P0001	Horn
390A3393P0001	CO2, MANUAL PULL
390A3394P0001	CO2 MANUAL PULL

Starfish PPS - Complete Catalog

Part Number	Description
390A3396P0001	Coupling
390A3459P0001	ASSEMBLY: DETECTOR, GAS
390A3536P0001	VALVE, RELIEF
390A3543P0001	SWITCH, ETHERNET
390A3665P0001	BOOSTER, PNEUMATIC. GENERATOR TRAIL
390A3705P0001	HORN ACK KEYSWITCH
390A3707P0001	EMERGENCY KEYSWITCH
390A3742P0001	PRESURE TRANSMITTER
390A3776P0001	DC-AC INVERTER
390A3791P0001	FIREWALL 3000
390A3793P0002	HIGH-DENSITY MEDIA CONV
390A3801P0001	DC-AC INVERTER
390A3808P0001	KIT, POWER CABLE
390A3958P0001	Breaker
390A3973P0001	Heater
390A4229P0001	MOTOR, 7.5 HP
390A4242P0001	LIGHT FIXTURE, EMERGENCY EXIT
390A4269P0001	RELAY, SYNC
390A4349P0001	CONVERTER, ANALOG
390A4351P0001	POWER SUPPLY, 24V DC, 5A
390A4361P0002	Pump, H2O injection
390A4362P0001	AMPLIFIER, PRESSURE, BENTLY NEVADA
390A4366P0001	Fan Assembly, Turbine
390A4389P0001	CABLE GLAND, 1/2", NPT ENTRY THREAD
390A4415P0002	Regulator
390A4416P0001	
	Water Injection Pump Relief Valve
390A4429P0002	Regulator, Press
390A4545P0001	TEST MATCH
390A4768P0001	CABLE, 16AWG, NICKEL PLATED COPPER TRIAD
390A4990P0001	SUPPLY,POWER,24VDC,20A,24VDC
390A4991P0001	DIODE
390A4997P0001	BRIDGE, FIXED, TB
390A5390P0001	Heater
390A6183P0001	Connection, Cross
390A6355P0001	TRANSMITTER, PRESSURE
390A6360P0001	TRANSMITTER, PRESSURE
390A6394P0001	Clutch, Over-Running
390A6522P0001	Diffuser Rope Seal
392A5229P0001	FILTER
393A1237P0001	TRANSMITTER
393A1281P0001	Transmitter, pressure
393A1321P0001	16-Slot Rack
393A1329P0001	Transmitter, pressure
393A1367P0001	PUMP, GLO
393A1422P0001	BARRIER, CONTROLLER
393A1711P0001	Low Pressure Return & Case Drain Return Filter
393A1716P0001	FUSE-LINK, 32A 500V
393A1898P0001	HEATER, IMMERSION, 2.77/4.0 KW
393A1929P0001	14" FLOW METER
393A1945P0001	Woodward valve
393A1986P0001	ETHERNET RING SWITCH, 4-10/100

Starfish PPS - Complete Catalog

Part Number	Description
393A1996P0001	HEATER, IMMERSION, 2.5", NPT SS, 2
393A2032P0001	Switch, Ring, Ethernet
393A2033P0002	SIXNET SWITCH, ETHERNET
393A2077P0001	Accelerometer
393A2078P0001	Accelerometer
393A2079P0001	Accelerometer
393A2080P0001	Accelerometer
393A2081P0001	Accelerometer
393A2082P0001	Accelerometer
393A3019P0001	Element, Temp
393A3340P0001	Regualtor
393A3341P0001	Regualtor
393A3347P0001	Transmitter
393A3396P0001	VALVE, SOLENOID
393A3415P0001	Pump, Cooling Water
393A3446P0001	Transmitter, Level
393A3553P0001	EMERGENCY STOP
393A3609P0001	GSOV HT
393A3611P0001	Valve, solenoid
393A3611P0001-OH	Valve, solenoid
393A3643P0001	DETECTOR
393A3678P0001	MOTOR, ELECTRIC
393A3699P0001	CABLE, IGNITION TRANSFORMER
393A3704P0001	Transformer
393A3776P0001	NOZZLE, WATER WASH
393A3794P0001	KIT, CUSTOMER TERMINAL BLOCKS
393A3837P0001	DRIVER, DVP
393A3951P0001	Sensor, Temp
393A4027P0001	Transmitter, pressure
393A4066P0001	RTD
393A4069P0001	RTD
393A4117P0001	Regulator, Water Inj
393A4135P0001	VALVE, BUTTERFLY, 24 INCH
393A4268P0001	Pump assembly
393A4805P0001	Regualtor
393A4908P0001	TRANSMITTER, PRESSURE
393A5044P0001	Pump, Starter
393A5081P001	SLO A/O Separator Part Kit for LMS100 SB 105
393A5082P001	MLO A/O Separator Part Kit for LMS100 SB 105
393A5124P0001	VALVE, BALL, 1-1/2, 600 LB
393A5208P0001	Valve, 3 way
393A5417P0001	Alarm Module (Horn & Strobe Driver) PSW
393A5459P0001	Flame Sensor
393A5534P0001	Bracket, Foot
393A5565P0001	QUAD BOX
393A5614P0001	VALVE, BLOCK, 2-WAY, COAX
393A5647P0001	Element, Vibration
393A5648P0001	Element, Vibration
393A5737P0001	GASKET, LOUVER
393A8832P0330	Filter
395040	Nut-S-L, Double Hex Opt. (IC)
39708466	FILTER

Starfish PPS - Complete Catalog

Part Number	Description
397A1119P0001	VALVE, LSOV
397A1120P001	Transmitter
397A1141P0001	Transmitter, pressure
397A1144P0001	Transmitter, pressure
397A1151P0001	Transmitter, pressure
397A1158P0001	
398000	Hose, Assembly, Kit
398000-50.5	Hose Assembly, Size - 1-1/2", Length - 50.5", Connection Type - 1/2"
398001	Hose, Assembly, Kit, Heat Exchanger, RH
398001-50.5	Hose Assembly, Size - 2", Length - 50.5", Connection Type - 1/2"
398002	Hose, Assembly, Water Wash Kit
398003	Hose, Assembly, Kit, Interconnect 3
398003-69	Hose Assembly, Size - 1-1/2", Length - 69", Connection Type - 1/2"
398004	Hose, Assembly, Kit, Interconnect 5
398004-72	1IN X 72IN OVER ALL LENGTH, 1IN STRAIGHT CODE 61 W/ 37DEG JIC FEMALE SWIVEL (FC195-16), TP/WP 50/33, SUPPLY WITH FF687-16 Flange Kit 1IN SAE Code 61 W/ aeroquip)
398005	Hose, Assembly, Kit, RH, Main Skid, Interconnect 78
398005-69	1-1/2IN X 69IN, INTERCONNECTS 78, TP/WP 50/33, SUPPLY WITH FLANGE KIT REF GHX P/N SFK-24, EA = KIT
398006	Hose, Assembly, Kit, Interconnect 2
398006-81	HOSE
398007	Hose, Assembly, Kit, Aux Skid
398007-56	Hose Assembly, Size - 1-1/2", Length - 56", Connection Type - 1/2"
398008	Hose, Assembly, Kit
398008-56	Hose Assembly, Size - 2", Length - 56", Connection Type - 1/2"
398010	
398010-56	Hose Assembly, Size - 1", Length - 56", Connection Type - 1/2"
398011	Hose, Assembly, Hydraulic
398012	Hose
398013	Hose, Assembly, Oil
398014	HOSE ASSEMBLY, Turbine Hydraulic
398015	Hose, Assembly, Starter Case Drain
398017	Hose, Assembly
398018	Hose, Assembly
398019	Hose, Assembly
398020	Hose, Assembly
398021	Hose, Assembly, Oil Scavenge
398022	Hose, Assembly, ENGINE CONN L3
398024	Hose, Assembly, Exhaust Collector Drain
398025	Hose, Assembly
398026	Hose
398027	Hose, Assembly, Hydro Start Return Main Skid
398028	Hose, Assembly, Starter, Supply
398029	Hose, Assembly
398030	HOSE ASSEMBLY, LIQUID FUEL VALVE
398031	Hose, Primary Header
398032	Hose, Secondary Header
398037	Hose, Assembly, Oil Cooling
398038	Hose, Suction Jacking
398039	Jacking Pump Discharge
398041	Hose, Assembly, GLO, Relief

Starfish PPS - Complete Catalog

Part Number	Description
398041P0001	Hose, Assembly, GLO, Relief
398045	Hose, Assembly
398046	Hose, Assembly
398048	Hose, Cooler to Tank
398049	Hose, Assembly
398050	Hose, Assembly, Hydraulic Start Return
398057	Hose, Assembly, Hydraulic
398058	Hose, Assembly
398070	Hose, Assembly
398071	Hose, Assembly
398074	HOSE, GLO SUPPLY TO GEARBOX
398078	HOSE, RUNDOWN TANK TO GEARBOX
398084	Hose, Water Inject Pump Discharge
398085	Hose
398086	Hose, Assembly
398090	Hose, Aux Skid
398091	Hose, Aux Skid
398092	HOSE, RETURN FILTER OUTLET
398093	Hose, Aux Skid
398094	Hose, Aux Skid
398095	Hose, Assembly
398096	Hose, Aux Skid
398097	Hose, Aux Skid
398098	Hose, Aux Skid
398099	Hose, Aux Skid
398100	Hose, Aux Skid
398101	Hose, Aux Skid
398102	Hose, Aux Skid
398103	Hose, Aux Skid
398104	Hose, Aux Skid
398105	Hose, Aux Skid
398106	Hose, Aux Skid
398107	Hose
398108	Hose, Aux Skid
398109	Hose, Aux Skid
398110	HOSE
398111	HOSE
398113	Hose, Assembly
398114	Hose, Assembly, Hydraulic
398115	Hose, Assembly
398116	Hose, Assembly
398117	HOSE
398131	Hose, Assembly
398134	Hose, Assembly
398135	HOSE, HYD STRT, RETURN FILTER OUTLET
398151	Hose, TLO
398158	Hose, Assembly
398161	Hose; F1 Main fuel supply
398167	Hose, Gen Pump Discharge
398171	HOSE, HYDRAULIC START
398208	

Starfish PPS - Complete Catalog

Part Number	Description
	HOSE, ENGINE CONNECTION D5
398208P0001	
	HOSE, ENGINE CONNECTION D5
398209	Hose, Assembly
398210	Hose, Assembly
398255	Kit, Door Seal Replacement
398A2029P0001	GASKET, EXCITER, SET OF 2
398A2058P0001	Valve, EGMV, 3 in
398A2059P0001	Valve, Fuel, Metering
398A2060P0002	VALVE - EWMV UNPLATED,2IN
398A2119P0001	QUAD-BOX, TERMINAL
398A2145P0001	FILTER, ELEMENT
398A2530P0001	Discharge Pressure Switch
398A2537P0001	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
398A2617P0001	Gen Lube Pump
398A2651P0001	Woodward GS6 valve
398A2651P0001-OH	Woodward GS6 valve
398A2674P0001	BARRIER, CONTROLLER
398A2715P0001	Switch, Float
398A2727P0001	Borescope, Kit
398A2749P0001	TRANSMITTER, PRESSURE
398A2753P0001	Servo, LPC-IGV
398A2753P0001F	KIT: FILTER, SERVO, LPC-IGV
398A2821P0001	Valve, Relief
398A2893P0001	Woodward GS6 valve
398A3394P0001	CO2 MANUAL PULL
398A3585P0003	Air / Oil Separator
398A4365P0001	Transmitter
398A4411P0002	UR319 SUCTION FILTER
398A4497P0001	Fan, Turbine Enclosure
398A4497P0001-OH	OVERHAULED Fan, Turbine Enclosure
398A4497P0002	Fan, Turbine Enclosure
398A4537P0001	Hydraulic Filter
398A4555P0001	VALVE, HIGH PRESSURE
398A4569P0002	HEAT EXCHANGER,COOLING
398A4662P0001	AC
398A4664P0001	AC, Panel
398A4664P0002	AC, Panel
398A4665P0001	AC, CABINET
398A4665P0002	AC, CABINET
398A4667P0001	Switch, Ethernet, 8 Port
398A4705P0001	Valve, Globe
398A4800P0001	Discharge Pressure Switch
398A4891P0001	Fin Fan Xchanger
398A4950P0001	Valve, butterfly
398A5066P0001	METER, SYNCHROSCOPE, 50/60HZ

Starfish PPS - Complete Catalog

Part Number	Description
398A5099P0001	Woodward GS6 valve
398A5136P0001	LINKNET-HT, MODULE
398A5137P0001	LINKNET-HT
398A5138P0001	LINKNET-HT
398A5139P0001	LINKNET-HT
398A5155P0001	LINKNET-HT
398A5198P0001	Cooler, turbine oil, Assy
398A5199P0001	Cooler, Turbine Oil
398A5222P0001	VALVE
398A5226P0001	Gasket flange--2"-600 lbs. Per PB 290
398A5234P0001	Gasket flange--3"-600 lbs. Per PB 290
398A5278P0002	FAN, CENTRIFUGAL, SINGLE INLET, Blower
399A1278P0003	CABLE
399A1278P0008	CABLE
399A1278P0009	CABLE
399A1278P0011	CABLE
399A1281P0001	PUMP, GOULDS
399A1282P0001	Pump Assembly
399A1284MTR	PUMP, GOULDS
399A1440P0001	LQ25T
399A1507P0001	ETHERNET MODULE, 10/100MBITS
399A1507Pus0001	
399A1521P0001	ADAPTER, COUPLING, HALF, 1 1/4 IN FN
399A1524P0001	Pump, Water
399A1535P0001	TRANSMITTER
399A1538P0001	NUT, 6 PT, SILVER PLATED
399A1560P0001	Pump, Lube, DC
399A1583P0001	VERSAMAX PROFINET SCANNER
399A1638P0001	WIRE, 16 AWG, 2 PAIR, SHIELD CABLE
399A1759P0001	ISOLATOR REPEATER
399A1800P0001	MOTOR
399A1858P0001	Pump, VFD
399A1908P0001	ELEMENT, TEMP
399A1928P0001	VALVE, DRAIN
399A1959P0001	
399A2108P0001	Clamp, Coupling
399A2206P0001	Ethernet ring switch
399A2235P0001	Pump assembly
399A2309P0001	METER, FLOW
399A2321P0001	VALVE, SOL, LIQUID FUEL DRAIN
399A2361P0001	
399A2418P0003	TRANSMITTER, TEMPERATURE
399A2446P0001	Clamp, tube
399A2476P0001	Valve, pressure relief
399A2546P0001	Pump Assembly
399A2591P0001	Thermo Valve
399A2605P0001	ASSEMBLY: GAS DETECTOR, 505, METRIC
399A2614P0001	PUMP
399A2700P0002	VALVE, ANTI-ICE
399A2704P001	PUMP, WATER
399A2814P0001	Pump, Sprint
399A2817P0001	Pump Motor Assembly

Starfish PPS - Complete Catalog

Part Number	Description
399A2838P0001	Valve, Globe
399A2857P0001	VALVE CHECK, BALL 1/4
399A2881P0001	BOX, CONDUIT, EABX
399A2955P0001	STRAIGHT SWIVEL HOSE FITTING, 1/2NPT
399A2957P0001	STRAIGHT SWIVEL HOSE FITTING, 1NPT
399A2967P0001	VALVE, CHECK
399A2974P000	RELAY, GENERATOR PROTECTION
399A2J00106967P0001	VALVE, CHECK
399A3042P0001	Element, Filter, MLO
399A3063P0001	Cable, Electrical, Temp
399A3069P0001	Cable
399A3093P1	VALVE
399A3106P0001	Pump/Motor Assembly
399A3180P0001	
399A3225P0001	Filter
399A3320P0001	Driver, Woodward
399A3511P0001	Detector, gas transmitter
399A3567P0001	LAMP, INDICATING
399A3568P0001	LAMP, MINIATURE
399A3609P0001	SET, BALANCED FASTENER
399A3815P0001	Filter, inlet
399A3816P0001	Filter, inlet
399A3873P0001	Base, I/O
399A3909P0001	Pressure switch, carrier
399A3910P0001	Surge Suppressor RJ45
399A3913P0001	Filter
399A4301P0001	Positioner, Valve
399A4395P0001	
399A4663P0007	UNION, ALUMINUM, 1/2"
399A4729P0001	Filter, inlet
3EA-AD25999-01	CELL, CONDUCTIVITY
3M764	TAPE, VINYL
3RG4011-0AB00	Inductive Sensor
3SB30010AA21	ASSEMBLY: LAMP HOLDER, RED
3SB30010AA41	ASSEMBLY: LAMP HOLDER, GREEN
3VX1320	GATES SUPER HC POWERBAND BELT
4-4CBTX-SS	90 DEGREE FITTING
4-F09152-S27	Mounting Kit
4/3VX1320	Belt, 4 wide
4012-00-0101-02-06	GASKET, RING
4012-00-0101-02-08	GASKET, RING
4012-12-1014-04	GASKET
4013-00-0101-01-06	GASKET, RING
4013-00-0101-01-08	GASKET, RING
4013-12-1014-01	GASKET
4018-00-0005-00-08	O-RING
4018-00-0011-00-06	O-RING, BUNA
4018-00-0011-00-08	O-RING
4025088	Drain Valve
4058T39P01	Seal Ring
4058T39P02	Seal Ring
4058T39P04	Seal Ring

Starfish PPS - Complete Catalog

Part Number	Description
405TTFS16837AN W	MOTOR
408D694H6HEASAA	STARTER, COMBINATION ENCLOSED
41095	PUMP
4151-1460	O-RING
41535-4	SEAL
416055325	PIN
416B605P4	NUT
420666E	Sprint Valve
4211C69004	SCREW
424/1.32.0.0.S5	VALVE, SOLENOID
42694-8001	Valve Overhaul Kit
427A3863P0901	
	OBS:
	VLAN Switch, AT8624, EDGE Configuration
427A8353G0003	Switch Assembly
42B Motor Base Plate	Fan Motor Mount
42B725 COVER PLATE	PLATE, COVER, FOR 42B725
42B725-FBG-SS	Fan Belt Guard
42B725-Motor	Motor, Electric, Gen Enclosure Fan
42B725-VABD	Fan, Generator
42B725-VABD-V	Fan, Generator
42D725-VJ-1762-100	Fan, Generator
432B570P0001	Piston
44203	Filter
4452-17	PUMP, LUBE AND SCAVENGE
4452-9	PUMP, LUBE AND SCAVENGE
447628	Coupling
448Z-6	Gauge, Immersion Depth, Igniter
44A724527-001	GE FANUC;BATTERY, Li
450M200	FILTER
4524-3402	Transducer, Displacement
45358-09	Cable, Accel
46143	Fiberoptic Cleaning Wipes
466624	Hose, Liquid Fuel
46994	NUT, ZINC PLATED
47116	BOLT, HEX
473-527-227	Cable Assembly, RTD
473-527-228	Cable assembly, XN25
473-527-229	Cable assembly, EGT
473-527-230	Cable assembly, T2
473-527-231	Cable assembly, CDT
473-527-232	Cable Assembly, PT Speed
4850-005-M1067	Cable, Vibration Sensor
4850-010-M1067	Cable, Vibration Sensor
4900159-23	Diffuser Rope Seal
4900159-38	Diffuser Rope Seal
4900159-48	Diffuser Rope Seal
490AMX-1200	Turbine Enclosure Fan - Direct Drive
490AMX-1200-AR	Turbine Enclosure Fan - Direct Drive - AS REMOVED
490AMX-1200-OH	Turbine Enclosure Fan - Direct Drive - OVERHAULED
490TSL	Fan, Turbine Enclosure
490TSL Direct Drive	Turbine Enclosure Fan - Direct Drive
490TSL Direct Drive-AR	Turbine Enclosure Fan - Direct Drive - AS REMOVED

Starfish PPS - Complete Catalog

Part Number	Description
490TSL Direct Drive-OH	Turbine Enclosure Fan - Direct Drive - OVERHAULED
490TSL SHAFT	U2 TURBINE EXH FAN SHAFT
490TSL-FBG-SS	Guard, Belt, TSL490
490TSL-OH	Fan, Turbine Enclosure, OVERHAULED
494610	Hose, Conn W6A
49TSL Motor	Motor, TCF Aerovent
49TSL Motor-OH	OVERHAULED Motor, TCF Aerovent
4BOCF14002D	VALVE, THERMOSTATIC
4J6588	Mag Chip Detector
4J7316	Mag Chip Detector
5/5VX1030	BELT, GENERATOR EXHAUST FAN
50-PS-120-2430AC/24DC	Power Supply
501239J43P0003	Thermocouple
501644	Flange
50239251	AMBIENT AIR THERMOSTAT EXM
5032M27P04	Strap
505353-1	Harness, TC
505354-1	HARNESS, LOWER, T48
505A3A2A1W	Transmitter, combustable gas
505A3A2B1W	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
505A3C2B1W	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
5069-IF8	CompactLogix 5069
508FX2-A-SC	SWITCH, ETHERNET
509079-1	Lead, Extension
50960G04	Charging Motor ASSY
50CLFXS	NUT, SS
50CLFXZ	NUT, ZINC PLATED
50N150WFES	WASHER, FENDER, 1/2 X 1 1/2, S/S
5106AB A	REPEATER, HART
5106AB B	REPEATER, HART
5106AB2A	REPEATER, HART
5106BB2B	REPEATER, HART
5115005	Starter Motor
5132T-6MP-60	Valve, relief
51372	WASHER
51658	Tempering Air Fan Assembly
51658-SHIMPACK	Shim pack for 51658
516686	Hose, Starter
516698	HOSE, LIQUID FUEL F9
516C-1-25	VALVE, RELIEF
516C-1-50	VALVE, CHECK
51V110	Starter Motor
51V1101RF1N	Starter Motor
521251	Hose, L-2
521252	Hose, L-3
521253	Hose, L-5
521254	Hose, L-6
521255	Hose
521256	Hose, L-9
521257	HOSE, L10
521258	Hose, L-11

Starfish PPS - Complete Catalog

Part Number	Description
521259	Hose, D-1
521260	Hose, D-2
521261	Hose, D-4
521262	Hose, D-5
521263	Hose, D-6
521274	Hose, A-5
521275	Hose, A-9
521280	Hose, A-23
521281	Hose, A-24
521282	Hose, A-25
521284	Hose, P-3
521285	Hose, A-32
521297	Hose, B-10
521298	Hose, B-11
521299	Hose, D-7
521362	Hose, D-8
521367	Hose, A-11, comp disch press (P3)
521368	Hose, A28
521645	HOSE, BALANCE PISTON PRESS VALIDATION
521647	HOSE ASSEMBLY, W2
52200899	QD ANODE/CATHODE, INPRO 6800
522219	Hose, B1/B2
522220	Hose, B-3
522288	Hose, W-3
522428	HOSE, TW1
522431	PIPE, TA4-P
522505	HOSE, B4
527-401	Tooling, ignitor depth gauge
527737	Gasket, Air/Oil
528603	Hose, Liquid Fuel
528604	Hose, Liquid Fuel
529287	KIT, DISK PACK, REXNORD NOX COUPLING
5301HA1S1V3AE00203RAKAM1C1	Transmitter, Level
5301HA1S1V3AE00207RAKAC1R3016	Transmitter
5301HA1S1V3AE00307RAKAM1	TRANSMITTER
5315	RTD Temp Sensor
5316-1	Sensor, T3
531X111PSHAXG2	BOARD, TERMINAL
531X307LTBAKG1	BOARD, TERMINAL, LAN, EX2000
537L308	RTD, Detector, Resistance Immersion
537L317G06	KIT, TUBE, A/O
53932	Seal
53WK35004	Starter
53WK57017	Starter
5402-6	HeliCoil Professional Thread Repair Kit
5416-338	Cable, Woodward
5416-351	Cable, Woodward
5417-027	CABLE, WOODWARD
5417-028	CABLE, WOODWARD
5417-029	CABLE, WOODWARD
5417-031	Cable, Woodward
5417-037	CABLE, WOODWARD

Starfish PPS - Complete Catalog

Part Number	Description
5417-038	CABLE, WOODWARD
5417-039	CABLE, WOODWARD
5417-040	CABLE, WOODWARD
5417-041	CABLE,NETCON LAYOUT LOW DENSITY DISCRETE,GR
5417-042	CABLE, WOODWARD
5417-044	Cable, Woodward
5417-045	CABLE ASSEMBLY, LOW DENS. ANALOG,12FT
5417-045-AR	CABLE, AS REMOVED
5417-1109	CABLE, WOODWARD
5417-1128	CABLE, WOODWARD
5417-117	CABLE, WOODWARD
5417-1281	CABLE, WOODWARD
5417-171	CABLE, WOODWARD
5417-172	CABLE, WOODWARD
5417-173	Cable
5417-173-AR	CABLE, AS REMOVED
5417-174	CABLE, WOODWARD
5417-175	CABLE, WOODWARD
5417-176	CABLE, WOODWARD
5417-177	CABLE-MICRONET HIGH DENSITY
5417-178	CABLE-MICRONET HIGH DENSITY
5417-217	CABLE, WOODWARD
5417-394	CABLE, WOODWARD
5437-281	Module - Analog Field Term
5437-419	MODULE, NETCON, 24 CHANNEL
5437-523	Module - Analog Field Term
5437-524	MODULE - ANALOG FIELD TERMINAL
5437-525	WOODWARD, MODULE, ANALOG FIELD TERM (ACT)
5437-672	Module, Netcon Field Term.
5437-687	Module, Netcon 24 Channel Field
5437-687-AR	MODULE, NETCON, AS REMOVED
5437-845	Notch Filter
5439-629	505 Power Supply
5441-413	32 CHANNEL RELAY INTERFACE
5441-419	MODULE, RELAY, 16 CHANNEL
5441-693	Woodward
5441-695	Module, Simplex FTM
5448-906	SYNCHRONIZING SYSTEM
5450-1095	Cable, DVP
5450-1096	CABLE, ASSEMBLY, DRIVER TO VALVE
5453-278	Cabinet, Woodward, Micronet
5453-750	ETHERNET INTERFACE FTM
5453-754	INTERFACE, ETHERNET, FTM
5453-759	CHASSIS, MICRONET PLUS
5453-829	Cabinet, Woodward, Micronet
5461-644	Module Assembly - DCS II 4-20 Current Out
5461-650	T/C Input
5461-651	Board/Module
5461-975	Power Supply DCS 2 LV
5462-085	Final Driver Module
5462-117	Position Transducer
5462-268	Mother Board for 505

Starfish PPS - Complete Catalog

Part Number	Description
5462-446	Module - DCS II - DPS3/DT
5462-718	Speed Sensor
5462-750	Secondary Power Supply - 501
5462-757	28 Channel Discrete Input Module
5462-758	28 Channel Discrete Output Module
5463-034	Power Aux. N.C.
5463-473	SIO Module - VER4.4 OPSYS
5463-604	Woodward
5463-605	Woodward
5464-213	SIO
5464-213-AR	SIO, AS REMOVED
5464-333	ISOL T/C FH
5464-337	RTD Input Module
5464-338	200 ohm RTD
5464-338-AR	RTD, AS REMOVED
5464-340	RTD
5464-340-AR	RTD, AS REMOVED
5464-553	Woodward module
5464-554	2 Channel Actuator Driver
5464-555	Woodward Module
5464-555-AR	MODULE, AS REMOVED
5464-643	Woodward I/O
5464-643-AR	I/O MODULE, AS REMOVED
5464-644	Woodward module
5464-645	2 Channel Actuator Driver
5464-646	Woodward module
5464-646-AR	MODULE, AS REMOVED
5464-647	2 Channel Actuator Driver
5464-654	Module, D.O.64 Channel w/Watch
5464-654-AR	MODULE, AS REMOVED
5464-658	DIGITAL SPEED SENSOR
5464-658-AR	MODULE, AS REMOVED
5464-658-OH	MODULE, OVERHAULED
5464-660-AR	MODULE, AS REMOVED
5464-697	40 Mhz CPU
5464-780	Remote XCVR
5464-780-AR	XCVR, AS REMOVED
5464-834	MODULE, Speed Sensor
5466-031	MODULE
5466-031-AR	MODULE, AS REMOVED
5466-045	MODULE, PRESSURE XDUCER INTERFACE
5466-045-AR	MODULE, PRESSURE, AS REMOVED
5466-1000	Power Supply, Micronet
5466-1000-AR	CT118090-5466-1000Power Supply, Micronet
5466-1001	Power Supply, Micronet
5466-1035	CPU, MICRONET
5466-1035-AR	CPU, MICRONET, AS REMOVED
5466-1035-OH	CPU, MICRONET, OVERHAULED
5466-1036	WOODWARD, MICRONET+,
5466-1036-AR	MODULE, AS REMOVED
5466-1036-OH	MODULE, MICRONET, OVERHAULED
5466-1045	Module, Micronet plus CPU5200

Starfish PPS - Complete Catalog

Part Number	Description
5466-1046	Module, Micronet plus RTN
5466-1046-AR	MODULE, AS REMOVED
5466-1050	Discrete input Module 48 Channel
5466-1158	Simplex Discrete I/O Module
5466-258	MODULE, I/O
5466-258-AR	MODULE, AS REMOVED
5466-258-OH	MODULE, OVERHAULED
5466-315	Module, High Density Analog I/O
5466-315-AR	MODULE, AS REMOVED
5466-316	Module, Analog Combination
5466-316-AR	MODULE, AS REMOVED
5466-326	Module, Pressure Input
5466-328	Module, Netcon IIIB
5466-332	MODULE, I/O, ANALOG
5466-348	WWARD SIO
5466-353	Module, Main Transceiver
5466-355	Transceiver
5466-358	WWARD SIO
5466-408-AR	MODULE, AS REMOVED
5466-409	Micronet CPU
5466-419	Module, Pentium 233 Mhz CPU
5466-425	Module, Micronet, Analog I/O
5466-425-AR	MODULE, AS REMOVED
5466-425-OH	MODULE, OVERHAULED
5466-5000	Module, speed
5466-5000-AR	MODULE, AS REMOVED
5466-5001	MODULE_CTRL, DIGITAL SPEED SENSOR MODULE (4I
5466-5027	Module, Micronet, Analog I/O
5466-654	Discrete Out
5466-654-AR	MODULE, Discrete OuT
5466-658	Digital Speed
5466-658-AR	MODULE, Digital Speed
546622	HOSE, BLEED AIR, 8TH STAGE
5485C-008	Sensor, Vibration
5485C-959	Sensor, Vibration
55-154607G041	Contact Kit
5500-159	505 Relay Board
5501-1432	Module, Actuator
5501-1432-AR	MODULE, AS REMOVED
5501-367	Module, Micronet Discrete FTM
5501-371	Module, Micronet Simplex MPU & AIO FTM
5501-371-AR	MODULE, MICRONET, AS REMOVED
5501-376	Module, Analog, High Density, Simplex
5501-432	Module, Actuator Netcon CONT.2C
5501-432-AR	MODULE, AS REMOVED
5501-437	Woodward
5501-465	Power Supply
5501-465-AR	POWER SUPPLY, AS REMOVED
5503-279	Board, Micronet HDVIM
5503-279-AR	BOARD, AS REMOVED
5503-282	Module, FTM HDVIM
5503-282-AR	MODULE, AS REMOVED

Starfish PPS - Complete Catalog

Part Number	Description
5503-335	CPU, Motorola 5200, Micronet Plus
554636	HOSE, TLO
554644	Hose
554677	Hose, Primary Manifold Drain
554678	Hose, Exhaust Drain
554687	HOSE, PRIMARY FUEL SUPPLY
554688	Hose, 2nd Manifold Supply
554729563	HEATER; TMSS-18315E2T2T36XX,400V/480V,21.5/31KW,1-3PH,15
5566-258	High Density D. I/O
5566-315	High Density A I/O
570008	HOSE, CDP PURGE CONNECTION
570392	HOSE, CDP PURGE CONNECTION 850
571-217-10	DIGIMATIC DEPTH GAUGE; 0-40"
571065	HOSE, ASSEMBLY, UNIVERSAL MANIFOLD
571219	Exciter
571328G0001	Fan, Turbine Enclosure
571486	HOSE,, HYD STARTE, MANIFOLD BLOCK TO PUMP DIS
571900	Hose, Hydraulic, Manifold
580-544-002F	Cable, VSV feedback
581-SS-40M	BASKET, MESH, Y-STRAINER
584623	HOSE, GLO MECHANICAL PUMP DISCHARGE
584627	HOSE, GLO SYSTEM
584628	HOSE, GLO SYSTEM
584630	HOSE, GLO
584683	Hose, Fuel, F1
584686	Hose, Liquid Fuel Supply
584716	HOSE
584718	CHARGER PUMP OUTLET TO TANK
584719	HOSE, HYD STR COOLER SUPPLY
584722	HOSE
585C1843P0001	RING, THREADED
586A2229P114	VALVE, FUEL GAS STOP RTIO S1-4
586A2268P001	Servo, LPC-IGV
593083	SOCKET, 7 WAY, SOLID PINS
59364-3215568-2	Valve
59501-510028-1	SENSOR, SPEED
5C2B-CC7	PUMP, GLO
5C2GV-CC	PUMP, GLO
5KS143SAA2067	Motor, Electric
5KS447SAA2085W	MOTOR
5VX1000	BELT, TURBINE ENCLOSURE
5VX1030	BELT
5VX1060	BELT
5VX1500	BELT, TURBINE ENCLOSURE
5VX570	BELT, FAN COOLER
5VX710	BELT, VENT/COMB FAN
5VX780	BELT, TURBINE ENCLOSURE
5VX830	BELT, FAN COOLER
6/5VX1500	6 Band Belt
60200501	Heater, Strip
60662	Seal

Starfish PPS - Complete Catalog

Part Number	Description
607208-00	Cable, Accel
607208-04	Cable
608214-03	CABLE, T2/T25 RTD
608214-04	CABLE, T2/T25 RTD
608214-4036	CABLE, T2/T25 RTD
608214-5036	CABLE, T2/T25 RTD
608919-03	CABLE, VBV/VSU-LVDT, RIGHT SIDE
608919-04	CABLE, VBV/VSU-LVDT, RIGHT SIDE
608919-4036	CABLE, VBV/VSU-LVDT, RIGHT SIDE
608920-03	CABLE, VBV/VSU/LVDT
608920-04	CABLE, VBV/VSU/LVDT
608920-4036	CABLE, VBV/VSU/LVDT
608920-5036	CABLE, VBV/VSU/LVDT
608926-03	CABLE, IGV/LVDT, RIGHT
608926-04	CABLE, IGV/LVDT, RIGHT
608926-4036	CABLE, IGV/LVDT, RIGHT
608926-5036	CABLE, IGV/LVDT, RIGHT
608927-03	CABLE, IGV/LVDT/XN2, LEFT
608927-04	CABLE, IGV/LVDT/XN2, RIGHT
608927-4036	CABLE, IGV/LVDT/XN2, LEFT
608927-5036	CABLE, IGV/LVDT/XN2, RIGHT
608928-02	CABLE, VBV/VSU/IGV
608928-03	CABLE, VBV/VSU/IGV
608928-3036	CABLE, VBV/VSU/IGV
608928-4036	CABLE, VBV/VSU/IGV
608929-03	CABLE, MANIFOLD TEMPERATURE
608929-04	CABLE, MANIFOLD TEMPERATURE
608929-4036	CABLE, MANIFOLD TEMPERATURE
608929-5036	CABLE, MANIFOLD TEMPERATURE
608930-04	CABLE, CHIP DETECTOR, A/B
608930-5036	CABLE, CHIP DETECTOR, A/B
608931-02	CABLE, CHIP DETECTOR, C/D/E
608931-03	CABLE, CHIP DETECTOR, C/D/E
608931-3036	CABLE, CHIP DETECTOR, C/D/E
608931-4036	CABLE, CHIP DETECTOR, C/D/E
608932-01	CABLE, TEMP LUBE & SCAVENGE
608932-02	CABLE, TEMP LUBE & SCAVENGE
608932-03	CABLE, TEMP LUBE & SCAVENGE
608932-04	CABLE, TEMP LUBE & SCAVENGE
608932-4036	CABLE, TEMP LUBE & SCAVENGE
608933-02	CABLE, TEMP LUBE RTD, D&E SUMPS
608933-03	CABLE, TEMP LUBE RTD, D&E SUMPS
608933-04	CABLE, TEMP LUBE RTD, D&E SUMPS
608933-4036	CABLE, TEMP LUBE RTD, D&E SUMPS
608934-03	CABLE, XN25 SPEED
608934-04	CABLE, XN25 SPEED
608934-4036	CABLE, XN25 SPEED
608935-02	CABLE, XNSD SPEED
608935-03	CABLE, XNSD SPEED
608935-04	CABLE, XNSD SPEED
608935-3036	CABLE, XNSD SPEED

Starfish PPS - Complete Catalog

Part Number	Description
608935-4036	CABLE, XNSD SPEED
608935-5036	CABLE, XNSD SPEED
608937-02	CABLE, OFF-ENGINE, T/C, T48
608937-03	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
608937-04	CABLE, OFF-ENGINE, T/C, T48
608937-3036	CABLE, OFF-ENGINE, T/C, T48
608937-4036	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
608938-02	CABLE, EGT THERMOCOUPLE, LOWER
608938-03	CABLE, EGT THERMOCOUPLE, LOWER
608938-04	CABLE, EGT THERMOCOUPLE, LOWER
608938-3036	CABLE, EGT THERMOCOUPLE, LOWER
608938-4036	CABLE, EGT THERMOCOUPLE, LOWER
608938-5036	CABLE, EGT THERMOCOUPLE, LOWER
608939-00	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
608942-00	CABLE, TEMP, LIQUID MANIFOLD
608942-01	CABLE, TEMP, LIQUID MANIFOLD
608945-00	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
608946-00	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
608947-00	CABLE, SPEED, GAS GENERATOR
608947-01	CABLE, SPEED, GAS GENERATOR
608952-00	CABLE, ELECTRICAL, VBV/VSV/LVDT
609508-00	CABLE
609527-00	CABLE, LM5000, T4.4
609549-03	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-04	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-05	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-4036	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-5036	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-6036	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609975-09	CABLE, CRF ACCELEROMETER
609975-12	CABLE, ACCELEROMETER
609975-40	CABLE, CRF ACCELEROMETER
609976-40	CABLE, TRF ACCELEROMETER
609976-4036	CABLE, TRF ACCELEROMETER
610146-00	CABLE, CHIP DETECTOR, A/B/COM
610147-00	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
610148-00	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT
611388-00	Cable, T/C, 20ft
61218-UA-2100	HARNESS, ELECTRICAL
62102-1	SWITCH, LIMIT
62102-2	SWITCH, Straight NormallyClosed
62105-3	Right Angle Bodied Switch
62105-5	Switch
62176	Coil, 24VDC
62185	Coil, 120VAC
62212-2	COL, 24 VDC
62213-1	Coil, 115VAC
6221342000	Drain Valve
62215	Coil, 18VDC
62216-2	Coil, 24VDC
62216-8	Coil, 125VDC
6240M46	Accelerometer

Starfish PPS - Complete Catalog

Part Number	Description
6240M49	Accelerometer
6240M52	Accelerometer, LM2500
6240M56	CRF Accelerometer
6240M58	TRF Accelerometer
6333B1B	2-WIRE PROGRAMMABLE TRANSMITTER
6333b1b	2-WIRE PROGRAMMABLE TRANSMITTER
6353-1105-31680	Regulator, Assembly
6354-225	Clamp, Coupling
6354-400	Clamp
635E901P03	Nut
638516	Shaft, Fan, Gen
638A433-001	BUSHING, OVERSPEED
647928	Bearing Thrust Plate
650097-1	Igniter Cable
655R-EDR	Valve, Lube
6601-01-019-C	Clutch
6601-01-019-C-OH	Clutch
6601-01-071-D (S# 05 04 04 06)	Clutch
6601-01-071P3R4	Clutch
6601-01-074-0	Clutch
6601-01-074-0SP	Clutch
6601-01-089-D	Clutch
6601-01-090-D	Clutch
6601-01-098	Clutch / Starter Assembly
6601-01-099-0	Clutch
6601-01-099-0-AR	Clutch; AS REMOVED
6601-01-099-0-OH	CLUTCH
6601-01-109-0	Clutch
6601-01-109-0-AR	CLUTCH; AS REMOVED
6601-01-109-0-OH	Clutch
6601-01-113-0	Clutch
6601-01-152	Clutch (with RTD and speed Probe) with start motor (shell
6601-01-175	Clutch, Over-Running
6601-02-019-D	Clutch
6601-02-175	Clutch, Over-Running
6601-09-009	RTD, Thermowell, Clutch
6601-10-009	Gasket
6601-10-010B	Gasket, Clutch, Hyd Motor
6601-10-023	Gasket
6601-10-10B	Gasket, Clutch, Hyd Motor
6601-3D-081-0	HYDRAULIC STARTER MOTOR
6601-3D-081-0SP	HYDRAULIC STARTER MOTOR
6601-RTD-KIT-100	RTD Kit, Hilliard
6601-RTD-KIT-50	Dual Element RTD Kit, Hilliard
6601RTD030-CBL	CABLE, ENGINE, RTD
6601RTD040-CBL	CABLE, CLUTCH OIL DRAIN RTD
6601RTD050-CBL	Cable
663A90-0049-2	Seal
6667621	Filter, Fuel
678714	HOSE, HYDRAULIC START
682L241G02	Kit, fuel pressurization
682L244G02	8th Stage Bleed Air Kit

Starfish PPS - Complete Catalog

Part Number	Description
682L407G04	Kit, VSV Position LVDT Assembly and Installation
682L565G03	Chip detector
682L879G02	Orifice Plate Kit
68514444190	Coupling
68A7803P5C	LAMP, BULB, ALARM PANEL
6900GZE18	SWITCH, PRESSURE
6900GZEM14-7066	SWITCH, PRESSURE
6900GZEM16-7066	SWITCH, PRESSURE
6900GZEM18-7066	SWITCH, PRESSURE
692201	Hose, L-1
692202	Hose, L-2
692203	Hose, L-3
692204	Hose, L-5
692205	Hose, L-6
692206	Hose
692207	Hose, L-9
692208	HOSE, L10
692209	Hose, L-11
692210	Hose, D-1
692211	Hose, D-2
692212	Hose, D-4
692213	Hose, D-5
692214	Hose, D-6
692220	Hose, B-5
692225	Hose, A-5
692226	Hose, A-9
692231	Hose, A-23
692232	Hose, A-24
692233	Hose, A-25
692236	Hose, A-32
692237	HOSE, BALANCE PISTON PRESS VALIDATION
692248	Hose, B-10
692249	Hose, B-11
692250	Hose, D-7
692259	Hose, D-8
692260	Hose, B-1
692310	Hose, A2-1
692311	Hose, B-2
692312	Hose, A2-2
692320	Hose, A-11, comp disch press (P3)
692321	Hose, A28
692323	Hose, F-73
692324	Hose, W-1
692325	Hose, F-4
692326	Hose, F-5
692327	Hose, P-3
692334	HOSE ASSEMBLY, W2
692340	Hose, W-3
692406	Hose, B1/B2
692408	PIPE, TA4-P
692410	HOSE, TW1
692418	Hose, B-3

Starfish PPS - Complete Catalog

Part Number	Description
692419	HOSE, B4
692B656G02	BRUSH HOLDER
6945-1053	REGULATOR
6945-1053 Rebuild Kit	Rebuild Kit for Fisher 1301F Regulator
698300P0025	ADAPTER
698300P0157	ADAPTER
698300P0158	ADAPTER
698300P0320	Adapter, 90
698300P0340	ADAPTER
698300P0417	Apdapter
699423	HOSE, HYDRAULIC STARTER, CASE DRAIN
6995-1017	VALVE, VENT, FUEL SYSTEM, DLE - 15 PPM
6995-1063	KIT, CUSTOMER TERMINAL BLOCKS
699500	8'-6"X 8'-9.13/16"X 12.5/8"F/F PLENUM-TURBINE ENCL
6ES73217BH010AB0	Digital Input Card
6ES7331-7PF01-0AB0	Analog Input Module
6ES73317TF010AB0	MODULE, INPUT, ANALOG
6ES73328TF010AB0	MODULE, OUTPUT, ANALOG
6ES7414-4HR14-0AB0	Simatic S7 CPU 414-4H PG Processor Module w/ FW: 4.5
6ES7416-5HS06-0AB0	Processor Module
6GK6021-0AS23-0DC0-Z A05+B05+C05+D05+E00+F00+G01+H01+J00+K00	Ethernet Switch
6GK7443-1EX20-0XE0Q	MODULE, SIEMENS ETHERNET
6SL3210-1PE28-8AL0	SINAMICS Power Module
6SL3210-1PE31-1AL0	SINAMICS Power Module
6SL3224-0BE33-7UA0	SINAMICS PM240 Power Module
6SL3243-0BB30-1FA0	SINAMICS Control Unit
6SL3255-0AA00-4JA2	SINAMICS G INTELLIG.OPERAT.PANEL IOP-2
6SL3256-0AP00-0JA0	SINAMICS Door Mounting Kit
70-751-14663	RESISTOR, STARTER
70-ASMD-250	DIODE
700099G0001	Valve, Bypass, Liquid Fuel
700851010081	Pick Up, Magnetic
700DC-PH400DZ24	RELAY, CONTROL
701689G0001	Starter Motor
701691	Boot, inlet, outer
701692	Boot, inlet, inner
701764G0001	GLASS, WIRED
7017M64G03	Valve, Pressure
701849601	Key, T shape 4MM
701849602	Key, T shape 6MM
701PBKKF	SmartPower Module
702039	HOSE
702054	HOSE, COMBUSTOR DRAIN, DLE
702186	GASKET, RD
702186-GAR	GASKET, RD, GARLOCK
702186-GAR-KIT	KIT, GASKET
702236	Hose, Assembly
702237	Hose, Assembly
702238	Hose, Assembly
702239	Hose, Assembly
702248	Hose, Assembly; Water Inj

Part Number	Description
702286	Hose, Assembly
702800	HOSE,ASSEMBLY, INSTRUMENT
702820	HOSE ASSY INLET VOLUTE DRAIN
703033	FABRIC EXPANSION JOINT
704B139P8	Pin Straight Headless
705-510A-310	LEVEL, TRANSMITTERS
705B276P4	Ring, Retaining
705B276P5	Washer
705B276P6	Washer
705B734P13	Washer
705B813P2	NUT
706-512A-110/7AT-1100-A10-20-02	TRANSMITTER, LEVEL
706B788P6	Nut
70A158A06048	Exchanger, Heat
70A163A08060	Cooler, turbine oil
7100G03	FAN, MOTOR COOLING
710605200000	INSERT, JACKING OIL COUPLING
71249	Nut, Engine Mount
71257	NUT, SS, ENGINE MOUNT
713227	HOSE
714016	HOSE, BLEED VALVE/ACCUMULATOR HYD
714213	HOSE, TLO, SUPPLY
714214	HOSE, TLO, RTN
714249	HOSE, HYDRAULIC START
714250	HOSE, STARTER
714437	Hose Assembly
714491	HOSE, TLO SUPPLY INTERCONNECT
714606	FABRIC EXPANSION JOINT
714610	FABRIC EXPANSION JOINT
714620	FABRIC EXPANSION JOINT
714655	HOSE, TLO
714659	HOSE, TLO
714664	HOSE, TLO SUPPLY FILTER INLET L2
714785	LIFT FIXTURE FOR LM2500+G4 DLE
718115-24	Gasket
719110	HOSE, HYDRAULIC START
719375	Hose, Instrument
72043000	VALVE
721006	Piping, Intercooler
721007	Washer
721008	Plate, Slide, Intercooler
721016	Plate, Slide, Intercooler
721018	Plate, Intercooler
721048	HOSE ASSEMBLY,8TH STAGE BLEED AIR,ANTI-ICE HOSE
721049	HOSE ASSEMBLY,8TH STAGE BLEED AIR,ANTI-ICE HOSE
721172	Expansion Joint
721173	Manifold Assembly
721215	HOSE ASSEMBLY
721217	HOSE ASSEMBLY
721235	Mounting Link, Front
721236	Tool, Alignment
721237	Mounting Link, Front

Starfish PPS - Complete Catalog

Part Number	Description
721247	HOSE, VBV
721268	HOSE, VBV
721269	HOSE, VBV, SERVO
721270	HOSE, VBV, HYD SUPPLY
721270P0001	
721293	HOSE, LIQ FUEL
721294	HOSE
721533	ASSEMBLY, HOSE
721873	HOSE
721885	LMS100 VBV Supply Hose
721885P0002	LMS100 VBV Supply Hose
72190040P0001	Cable, Electrical, VIGV
72190140P0001	Cable, Electrical, VIVG
72190245P0001	Cable, Electrical, Vib
72190350P0001	Cable, Electrical, Vib
72190450P0001	Cable, Off-Engine
72190545P0001	CABLE, DRAIN VALVES
72190550P0001	Cable, Electrical, Temp
72190665P0001	Cable, Electrical, Vib
72190755P0001	Cable, Electrical, Act
72190860P0001	Cable, Electrical, VSV
72190955P0001	Cable, Electrical, Act
72191060P0001	Cable, Electrical, VSV
72191165P0001	Cable, Electrical, Temp
72191265P0001	Cable, Electrical, Temp
72191365P0001	Cable, Electrical, Speed
72191475P0001	Cable, Electrical, TEmP
72191565P0001	Cable, Electrical, Temp
72191665P0001	Cable, Electrical, Speed
72191765P0001	Cable, Electrical, Speed
72191865P0001	Cable, Electrical, Temp
72191965P0001	Cable, Electrical, Chip
72192075P0001	Cable, Electrical, Vib
72192175P0001	Cable, Electrical, Speed
72192275P0001	Cable, Electrical, Speed
72192370P0001	Cable, Electrical, Temp
721924P0001	Cable, Off-Engine
72192570P0001	Cable, Electrical, Temp
72192670P0001	Cable, Electrical, T48
721927100P0001	Cable, Electrical, Vib
721928100P0001	Cable, Electrical, speed
721929100P0001	Cable, Electrical, Speed
721930100P0001	Cable, Electrical, Key Phasor
721931A65P0001	CABLE, OFF-ENGINE
721931B40P0001	CABLE, DYNAMIC PRESSURE SENSOR
72193475P0001	Cable, Electrical, Flame
72193560P0001	Cable, Electrical, Temp
721936120P0001	Cable, Electrical, Vib
721937A40P0001	CABLE, TBV
721937B40P0001	CABLE, TBV
72193840P0001	CABLE, 8TH STAGE BLEED VALVE
721938P0001	Cable, DLE CDP Bleed Valve

Part Number	Description
721950	HOSE ASSEMBLY,TURBINE HYDRAULIC,HOSE 6
72198145P0001	CABLE, LIQUID FUEL VALVES
72198245P0001	CABLE, LIQUID FUEL VALVES
72198340P0001	CABLE, MANIFOLD TEMPERATURE
72198345P0001	CABLE, LIQUID FUEL TEMPERATURE
72198350P0001	CABLE, MANIFOLD TEMPERATURE
72198445P0001	CABLE, DRAIN VALVES
72198540P0001	CABLE, DRAIN VALVES
722A688G02	BRUSH, CARBON
723139	Hose discharge, GLO
723212	HOSE
723213	Hose
723214	Hose, Vent
723239	Hose, A9 Vent
723640	HOSE, SUCTION MAIN GLO PUMP BRUSH GENERATOR
723954	Hose
723954P0001	Hose
723955P0001	HOSE
723972	HOSE, ENGINE CONNECTION A9
724007	FABRIC EXPANSION BOOT ONLY
724008	FABRIC EXPANSION JOINT BOOT ONLY
724380	Hose, TLO Supply
724381	Hose, L2
724391	HOSE, TURBINE LUBE OIL, FILTER SUPPLY
724469	Sensor, Speed
724556	Hose, E-SPrint (TW1)
724607	Hose assembly, Hyd Starter Motor Supply
724608	Hose assembly, Hyd Starter Motor Return
724714	FABRIC EXPANSION JOINT
724746	Hose, Water Wash Supply
724748	Hose, Air Supply
724951	HOSE, AUX SKID, LP RETURN FILTER TO PUMP
72650340P0001	CABLE, TEMP COMPRESSOR DISCHARGE, T3
72650430P0001	CABLE, XNSD SPEED
72650440P0001	CABLE, XNSD SPEED
72650540P0001	CABLE, CRF ACCELEROMETER
72650640P0001	CABLE, TRF ACCELEROMETER
72650740P0001	CABLE, TEMP LUBE & SCAVENGE
72650840P0001	CABLE, TEMP LUBE RTD, D&E SUMPS
72650860P0001	CABLE, TEMP COMPRESSOR DISCHARGE, T3
72650940P0001	CABLE, VBV/VSV/IGV
72651040P0001	CABLE, VBV/VSV/LVDT
72651140P0001	CABLE, VBV/VSV-LVDT, RIGHT SIDE
72651230P0001	CABLE, OFF-ENGINE, T/C, T48
72651240P0001	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
72651340P0001	CABLE, IGV/LVDT, RIGHT
72651440P0001	CABLE, IGV/LVDT/XN2, LEFT
72651530P0001	CABLE, EGT THERMOCOUPLE, LOWER
72651540P0001	CABLE, EGT THERMOCOUPLE, LOWER
72651640P0001	CABLE, CHIP DETECTOR, A/B
72651650P0001	CABLE, CHIP DETECTOR, A/B
72651740P0001	CABLE, CHIP DETECTOR, C/D/E

Part Number	Description
72651840P0001	CABLE, T2/T25 RTD
72651850P0001	CABLE, T2/T25 RTD
72651940P0001	CABLE, XN25 SPEED
72652040P0001	CABLE, MANIFOLD TEMPERATURE
726521A40P0001	CABLE, CLUTCH OIL DRAIN RTD
726522A40P0001	CABLE, STAGING VALVES, LEFT
726522B40P0001	CABLE, STAGING VALVES, LEFT
726523A40P0001	CABLE, STAGING VALVES, RIGHT
726523B40P0001	CABLE, STAGING VALVES, RIGHT
72652540P0001	CABLE, STAGING VALVES
72652601P0001	CABLE, PATCH
72652745P0001	Cable, Power
726528A40P0001	CABLE, UV FLAME DETECTOR
726529A040P0001	CABLE, IGNITION TRANSFORMER
72653040P0001	Cable, Staging Valves
72653340P0001	CABLE, STAGING VALVES
72653545P0001	Cable, Valve Feedback
72689040P0001	Cable, VSV
72689045P0001	Cable, VSV Servo Valve
726891100P0001	Cable, Off-Engine, Dual RTD/VSV/LVDT
72689150P0001	Cable, Dual RTD/VSV/LVDT
72690045P0001	Cable, Engine
72690145P0001	CABLE, ELECTRICAL
72693030P0001	CABLE
726932060P0001	CABLE
72693245P0001	CABLE, FLAME DETECTOR
726933100P0001	Cable, C Sump
726934070P0001	Cable
72693560P0001	CABLE, ELEC, NGG1 GG SPEED
72694105P0001	CABLE, OFF-ENGINE, TM2500
728025	MOUNT, Turbine
728026G0001	MOUNT, TURBINE REAR FRAME
728029	Mount, Turbine
728035	BOLT, Engine Mount
728036	BOLT, Engine Mount
728039	FABRIC EXP. JOINT
728066	Hose, MLO ,HOSE 1
728067	Hose, MLO ,HOSE 2
728068	Hose, MLO ,HOSE 3
728069P0001	HOSE FABRICATION DETAIL, MINERAL, LUBE OIL HOS
728102	Hose
728103	Hose
728104	HOSE
728126	HOSE, BOOSTER SCROLL DRAIN
728139	FABRICATION DETAIL,MINERAL LUBE OIL,HOSE 8
728169	Hose, Water Wash
728173	Hose, Water Wash
728174	Hose, Water Wash
728181	HOSE ASSEMBLY SYNTHETIC PUMP SUPPLY LUBE OIL
728183	HOSE, Scavenge Discharge Hose 2
728187	Hose, SLO Hose 4

Part Number	Description
728192	HOSE, TURBINE HYDRAULIC HOSE
728194	Hose, Exhaust Coll Drain
728195A	HOSE, TURBINE HYDRAULIC HOSE 5
728210	FABRIC HPC SCROLL DIAPHRAM
728215	FABRIC BOOSTER SCROLL DIAPHRAM
728245	HOSE, FABRICATION, DETAIL
728246	HOSE ASSY, TURBINE HYDRAULIC HOSE 4
728252	Hose
728290	HOSE ASSY, SYNTHETIC LUBE OIL DEMISTER VENT
728294	HOSE, SUMP SUPPLY PURGE
728304	HOSE, PS3
728305	HOSE, INSTRUMENT
728309	HOSE ASSEMBLY,INSTRUMENT HOSE
728317	Hose SLO – to / from Cooler
728321	HOSE, INSTRUMENT, PS3A AND PS3B
728322	HOSE ASSEMBLY,INSTRUMENT HOSE,P48 AND PTBH1
728511	HOSE ASSY, VBV TURBINE HYDRAULIC RETURN
728729	HOSE 1 ASSEMBLY,INTERCONNECTING PIPING
728730	HOSE ASSY, INTERCONNECT PIPING HOSE 2
728731	HOSE ASSEMBLY,INTERCONNECTING PIPING,HOSE 3
728732	HOSE ASSEMBLY,INTERCONNECTING PIPING,HOSE 4
728740	HOSE ASSY,MINERAL LUBE OIL SYSTEM COMPENSAT
728771	HOSE, HYDRAULIC STARTER OIL
728776	HOSE ASSEMBLY
728870	HOSE, ASSEMBLY, SLO SYSTEM
728888	HOSE ASSEMBLY
728889	HOSE ASSEMBLY,TURBINE HYDRAULIC,FROM FILTER
728898	HOSE
728909	HOSE ASSY, WATER INJECTION HOSE #1
729032	HOSE ASSY, SLO PRE-SEPERATOR CONNECTION, A1, VENT
729033	HOSE, SLO PRE-SEPARATOR CONNECTION, B-C SUMP
729034	HOSE ASSY, SLO PRE-SEPERATOR CONNECTION, D S
729039	HOSE ASSEMBLY,ROOF,SLO A1,A2 SUMP VENT
729041	HOSE ASSEMBLY,ROOF,SLO D SUMP VENT
729042	Hose Assembly, A10 D Sump Vent
729051	HOSE ASSEMBLY,SLO A1,A2 SUMP VENT
729135	HOSE ASSY, GAS FUEL MANIFOLD-F1
729171	HOSE, BOOSTER SCROLL DRAIN RH INTERCOOLER C
729203	HOSE ASSEMBLY,
729204	HOSE ASSEMBLY
729205	HOSE ASSEMBLY,HYDRAULIC STARTER OIL TO START
729317	HOSE ASSY, WATER INJ DUPLEX FROM STRAINER
729975	LIFT FIXTURE
73-13524-A1	Switch, Prox
731092	SEAL
731095	SEAL
731184	HOSE, LOAD CAGE COOLING HOSE 7
731204P0001	ASSY DRAIN HOSE, GV-ACTUATOR
731214P0001	HOSE ASSY, MINERAL LUBE OIL GENERATOR INTERC
731439P0001	HOSE ASSY, MINERAL LUBE OIL HOSE 6
731582	HOSE,PRESSURIZING AIR

Part Number	Description
731630	HOSE
731631	HOSE
731737P0002	HOSE ASSY ROOF, SLO SYSTEM B-C SUMP VENT
731738	HOSE ASSEMBLY,SYNTHETIC LUBE OIL SYSTEM ENGR CONNECTION (A10),D SUMP VENT
731742P0002	HOSE ASSY, SYNTHETIC LUBE OIL SYSTEM, ENGINE C
731871P0001	FOD Screen
731872P0001	FOD Sock
733108	HOSE, ASSEMBLY, JACKING OIL PUMP SUPPLY
733230	152.3/4" X 119" X 12.1/2" F/F PLENUM (PipingTech does NOT ONLY)
733574	HOSE, GAS FUEL DLE CONNECTION F1D
733575	HOSE, GAS FUEL DLE CONNECTION, F1E
736L680G01	Bergen Cables
737-3/4NPT X M25F	ADAPTOR, CONDUIT
737652	HOSE, LIQUID BOOST AUX SKID, PUMP DISCHARGE
737L694G02	KIT: VSV BUSHING
739325	HOSE, DLE GAS FUEL MID MANIFOLD (G RING)
739326	HOSE, DLE GAS FUEL AFT MANIFOLD (B RING)
741041	Hose, Gas
741041P0002	Hose, Gas
741107	HOSE
741189	HOSE, CHARGER OUTLET TO TANK
741190	HOSE, COOLER
741200	8'-6" X 9'-4.11/16" X 12" F/F PLENUM FABRIC EXP. JOINT BACKUP BARS
741220	HOSE, PUMP OUTLET TO DRAIN FILTER
741228P0004	HOSE, ASSEMBLY, LP RETURN MANIFOLD
741232	HOSE, TLO RETURN, L3
741233	HOSE
741234	HOSE, ASSEMBLY, MANIFOLD TO THERMAL
741235	Hose, Filter to Pump Return
744C0258P002	Bearing
744C258-001	Bearing
74712-06-05-03-00	SEISMOPROBE
747714	FABRIC EXPANSION JOINT
747C0078G002	Bearing
747C0778G002	Bearing
748948	HOSE, HYDRAULIC START, AUX SKID PUMP TO TANK
748953	HOSE, HYDRAULIC START CASE DRAIN
748954	HOSE, HYDRAULIC START, AUX SKID, PUMP TO CASE RETURN FILTER
752070P0001	HOSE ASSEMBLY
752124	Hose, Lube, GLO
752163	HOSE, LIQUID FUEL, SECONDARY FUEL SUPPLY, HD-5
752164	HOSE, LIQUID FUEL, PRIMARY FUEL SUPPLY, HD-5, PF
752289P0001	HOSE ASSEMBLY, HYDROLIC
752310P0001	HOSE ASSEMBLY, HYDRAULIC
752332	HOSE, TLO INLET PUMP, L1
752397	Hose, Case Drain Q/D
752397P0001	Hose, Case Drain Q/D
752398	Hose, Hydraulic Start Return
752454	HOSE ASSY LIQUID BOOST AUX SKID

Starfish PPS - Complete Catalog

Part Number	Description
752456P0001	Hose, VBV
752483	Hose, TLO System Return
752483P0002	Hose, TLO System Return
752486	HOSE
752486-QC	QUICK CONNECT, HOSE
752503	HOSE, TLO SYSTEM - B
752515	Hose, Hyd Start Return
752547	HOSE, GAUGE PANEL
752548	Hose, Instrument
752552	HOSE, ASSEMBLY
752553	HOSE
752554	HOSE
752561	HOSE, WATER INJECTION MANIFOLD
752586	HOSE ASSY EXHAUST DRAIN
752587	HOSE ASSY EXHAUST COLLECTOR DRAIN EXTERIOR
752637	HOSE, HYDRAULIC
752700	HOSE, GAS PURGE SYSTEM, HD-5 PROPANE
752702	HOSE, INSTRUMENT AIR SUPPLY
75271560001	ASSEMBLY: GAS DETECTOR, 505, METRIC
752755	HOSE, INLET LUBE SUPPLY L4
752828	Hose, Gas Fuel Supply
752828P0001	Hose, Gas Fuel Supply
752917P0001	GAS FUEL PILOT SUPPLY
752943	HOSE, TLO DISCHARGE, SCAVENGE, L3
752974	HOSE
752983	HOSE, ASSY, FIRE
7539500T03S03P0001	CABLE, TM2500
7539500T04S03P0001	CABLE, TM2500
7539500T05S03P0001	CABLE, TM2500
75406262-G09X	STUD
754554-2-85F	CLAMP
755047P0001	HOSE ASSY, MINERAL LUBE OIL #3J BEARING
755069P0002	
75507500	KIT: FILTER, SERVO, LPC-IGV
75511066	Filter Replacement Kit
755163P0001	HOSE ASSY, MLO, HOSE 7
755196P0001	HOSE ASSY, MINERAL LUBE OIL #3j BEARING
755197P0001	HOSE ASSY, MINERAL LUBE OIL #3 BEARING
755202	Hose, Metal, Water Injection Manifold
755202P003	Hose, Metal, Water Injection Manifold
755362	HOSE, LOAD CAGE COOLING HOSE 3
755421	HTOIC Vent hose
755421P0001	HTOIC Vent hose
755456	Hose, Turbine Hydraulic
755459P0001	Hose, Turbine Hydraulic
758248	HOSE ASSEMBLY
758249	HOSE ASSEMBLY
758928P0001	HOSE
758980P0001	HOSE ASSEMBLY, HYDROLIC START SUP
758981	HOSE ASSEMBLY, HYDRAULIC START RET
759249	HOSE ASSEMBLY
761-SS 2"	Y STRAINER

Part Number	Description
761-SS 3"	Y STRAINER
761-SS-3"-GSKT	GASKET
764-SS 3"	Y-STRAINER
764-SS 4"	Y STRAINER, INLET SCREEN
764-SS 4" GSKT	Y STRAINER GASKET
770081027315	ESys Module (Simplex)
771A0563P001	SWITCH, MICRO
772-298B	VALVE, SERVO
780-SD-32654	TRANSFORMER, CURRENT
780524	Exciter
780I-402-1	TRANSFORMER, CURRENT
781-SS	Y Strainer
781-SS-STRN	Y Strainer, replacement strainer, 100 mesh
782XDXH10	RELAY, 24V
783100X0730	BRACKET, HOLDER, MAG P/U
78432-04	PC Board for Distribution Module
7899	Gas Sniffer
78R25N00A025T34E5	Sensor, Temp
78R25N00A025T38E1	RTD
78R25N00A100T22E1	TRANSMITTER
78R25N00A120T22E6	Model 79 Connection Head
7940D52001	Piston, Igniter
79622-01	Main PC Board
79841	Support, Exhaust
7ML1201-1AC00	Probe, 2 wire
7ML1201-1EF00	Probe, 2 wire
7ML51171BD074BK3	Probe, Level
8 AWG THHN	8 AWG THHN SINGLE STRAND
800-1440	Module, input, fire system
800-1441	Manual Pull Module
800-1442	Module, Alarm
800-1443	MODULE, RELEASE
800-1444	Fault Module
800-1457	NT 420 Digital Gas Module, LFL
800-1760	MODULE, RELAY
800-1785	Module, Blank
800826-6752	Non-Setting Gasket and Jointing Compound
8013-1067	PUMP, LUBE
8013-1071	PUMP, LUBE
8014-1039	Pump, Fuel
8014-1045	Pump, Fuel
803242	DIAPHRAGM, DISK, RUPTURE
803535	HOSE, EQUIP-SPRINT INTERCONNECT
803718	HOSE, GLO PIPING DRAIN
803726	HOSE, COOLER INLET
803727	HOSE, COOLER OUTLET
803734	HOSE, SUPPLY GLO PIPING
806213	HOSE, TLO SUPPLY L1
806214	HOSE
806218	HOSE, TLO SUPPLY, L1
806219	HOSE, ASSEMBLY, TURBINE LUBE
806248	HOSE, TURBINE SKID, HYDRAULIC

Part Number	Description
806249	HOSE, ASSEMBLY, TURBINE SKID TO HYDRO
806372P0001	HOSE ASSEMBLY, TURBIN SKID HYDROLIC
806376	HOSE, TURBINE SKID, HYDRAULIC
806486	HOSE, TLO SUPPLY INTERCONNECT SPOOL 1
806491	HOSE, TURBINE LUBE OIL SUPPLY INTERCONNECT
806495	HOSE ASSEMBLY, HYDRAULIC
806526	HOSE, MEDIUM BTU GAS FUEL MANIFOLD
806586	HOSE, HYDRAULIC START, SAC PLUS SUPPLY/RETURN
806655	HOSE, TLO SUPPLY, FILTER INLET, L2
806659	Hose, TLO Supply Filter (L4)
806895P0001	Inlet Seal
8085182	O Ring
810864G0001	FABRIC EXPANSION JOINT ASSY
81160	RTV SILICONE
8140-0601	Conditioner, Signal, Remote
81546-01	XDCR I/O & Record Terminals & Alarm Relay Outputs
81PS1F68-8	VALVE, RELIEF
81PS1M68-4	VALVE, RELIEF
81PS1S12C16A-8	VALVE, RELIEF
8200-1100	LINKNET-HT
8200-1102	LINKNET-HT
8200-1103	LINKNET-HT, MODULE
8200-1104	LINKNET-HT
8200-1105	LINKNET-HT
8200-1151	LINKNET-HT
8200-1200	LINKNET-HT
8200-1202	LINKNET-HT
8200-1203	LINKNET-HT
8200-1204	LINKNET-HT
8200-1205	LINKNET-HT
8200-1353	FLEX500,LVDC,BACK PANEL
8200-169	Driver
8200-176	Driver, EM, Fuel Valve, DLE, Woodward
8200-176-OH	DRIVER, EM, FUEL VALVE, DLE, WOODWARD
8200-177	Woodward Driver
8200-177-AR	WOODWARD DRIVER
8200-182	Woodward DRIVER
8200-182-AR	WOODWARD DRIVER, AS REMOVED
8200-182-OH	Woodward DRIVER, OVERHAULED
8200-185	DRIVER, DVP
8200-188	Positioner, Valve
8200-226	Controller, Servo Position
8200-314	Woodward Driver
8200-505	Driver, Digital Valve Positioner
8200-507	Driver, Woodward
8200-508	DIGITAL VALVE POSITIONER
8200-510	DVP, 24VDC, IP30, TB Input
821250	Pump, Fuel
8220G21	VALVE, SOLENOID, RED-HAT
8273-1011	Control, Speed / Load Sharing
830A-36889	Cable, Interface
836-P17-ANCH	Switch, Pressure

Part Number	Description
84084240P0001	CABLE,OFF-ENGINE,T2 SENSOR DUAL RTD/VSV LVDT,
841338	HOSE, HYDRAULIC STARTER, LOW PRESSURE LINE, E
841345	HOSE, TLO INTERCONNECT SUPPLY
841430	HOSE, HYDRAULIC START TANK TO PUMP INLET
841431	HOSE, MANIFOLD TO THERMAL BYPASS
841435	HOSE, COOLERS TO TANK
841453	HOSE, TLO, L3, SCAVENGE, DISCHARGE
841594	HOSE, TURBINE LUBE OIL DRAINS
841704	HOSE, INSTRUMENT
8440-2167	MODULE, SYSTEM, SYNCHRONIZING
844555P0005	Hose, Hyd Start, Skid
85.BAA.003035	Pump, GLO
850-E-P5-NN-G5-H-N-N-A-N-N-M-S-S-F-B-SE-N-N-B-N-4	RELAY, PROTECTIVE
8510023-1	Valve, stater pump
851360G0007	FABRICATION DETAIL, COVER
8519500G26S03P0003	CABLE
8519500G27S03P0002	CABLE
8519500G28P03P0001	CABLE
8519500G29P03P0002	CABLE
8519500G30P03P0002	CABLE
851950GS20S03P0001	CABLE, TM2500
851950OG25C21P0001	CABLE, TM2500
851950OG33P03P0001	CABLE
851950OT08P03P0001	CABLE
851950TC15B35P0001	CABLE, TM2500
851950TC16B35P0001	CABLE, TM2500
851950TC17B35P0001	CABLE, TM2500
852009	Hose Assy, Gas Fuel Interconn
852122	HOSE, TANK TO CHARGE PUMP FILTER
852125	HOSE, GAS FUEL SKID PIPING
852127	Hose Assy, Gas Fuel Interconn
852128	Hose, Gas
852128P0002	Hose, Gas
852130	HOSE
852131	HOSE, EXHAUST DRAIN
852132	HOSE, EXHAUST COLLECTOR DRAIN EXTERIOR
852133	HOSE, GAUGE PANEL 2
852140	Hose Assy,
852141	Hose Assy, 2nd Liq Fuel Manifold
852148	HOSE
852155	HOSE, WATER INJECTOR SUPPLY, ASSEMBLY
852156	Hose Assy, Water Inj Manifold
852181	HOSE, TURBINE DRIP PAN DRAIN
852205	Hose Assy
852206	Hose Assy
852209	Hose Assy
852210	Hose Assy
852212	Hose, GLO Pump Discharge
852213	Hose Assy
852214	Hose, GLO Pump Suction
852511	Hose Assy, Water Wash Tank to Pump

Starfish PPS - Complete Catalog

Part Number	Description
852512	Hose Assy, Water Wash Tank to Pump
852513P0001	HOSE ASSEMBLY
852514	Hose Assy
852515	Hose Assy, Ret Filter to Charge Pump
852516	Hose Assy, Tank to Charge Pump
852517	Hose Assy, Fin Fan Outlet
852518	Hose Assy, FIN FAN INLET
852530P0001	HYDRAULIC START TO RETURN FILTER
852530P0002	HYDRAULIC START TO RETURN FILTER
852531	Hose Assy, Manifold to Case Drain
852532	Hose Assy, CHARGE PUMP TO HYDRAULIC START SUP
852533	HOSE, TLO TANK TO L1
852534	Hose, TLO, L2 to SUPPLY
852534-M	Hose, TLO, L2 to SUPPLY
852535	HOSE, ASSEMBLY, TLO FILT TO L4
852535-M	HOSE, ASSEMBLY, TLO FILT TO L4
852536	HOSE, ASSEMBLY, LIQUID, TURBINE, TLO SCAVENGE D
852537	Hose Assy, Water Wash IntCon
852545	Hose Assy, HYDRAULIC START RETURN
852545P0001	Hose Assy, HYDRAULIC START RETURN
852546	Hose Assy, Hyd Start Drain
852547	Hose, Hyd Start Supply
852547P0001	Hose, Hyd Start Supply
852548	HOSE, TLO SUPPLY L1
852549	Hose Assy, TLO Scavenge
852550	Hose Assy, TLO L2
852551	HOSE, TLO HEADER SUPPLY L4
852552	HOSE, WATER WASH DETERGENT MANIFOLD
852710P0001	Seal Ring, Turbine Bellmouth
852821	Manifold, Gas Fuel
8530631001	RELAY, 24VDC COIL DPDT
85435-01	Power Terminal
856-2-12C	Pressure Probe
8570/12-306	CONNECTOR, STAHL
8580-080	Pump
8580-085	PUMP
8580-086	Pump, hyd
86/060-039A-1	Pump Seal Kit
861-SS(1INCH)	Y-STRAINER 1"
861-SS-1-100BSKT	Y-Strainer Replacement Basket
861-SS-1GSKT	Y-Strainer Replacement Gasket
86160RIW039A-1	PUMP, LIQUID
862-7-19C	T/C; T48
86200RIW039A-1	PUMP, LIQUID FUEL
86517-01-01-01-01	Bently Nevada Interface Module
86517-01-01-01-02	Bently Nevada Interface Module
868138P0001	Hose, Water Inj, Pump Suction
868139P0001	Hose, Water Inj, Pump Suction
868140P0001	Hose, Water Inj, Pump Discharge
868141P0001	Hose, Water Inj, Pump Discharge
868142	HOSE, HYDRAULIC START TANK TO PUMP
868143	Hose, Hydraulic Start

Part Number	Description
868256	HOSE, GAS FUEL DLE CONNECTION F4
868257	HOSE, GAS FUEL DLE CONNECTION F2
868258	HOSE, GAS FUEL DLE CONNECTION F3
868259	HOSE, GAS FUEL DLE CONNECTION F5
868260	HOSE, GAS FUEL DLE CONNECTION F1
868515	HOSE, HYDRAULIC START SUPPLY
868669	HOSE, HYDRAULIC START COOLER TO TANK
868735	HOSE
868797G0001	Duct, VBV
868797G0003	Duct, VBV
868797G0003-Boot	
868797G0003-strips	
868843	HOSE, HYDRAULIC START RETURN, FILTER TO PUMP,
868884	Hose Assembly, TLO
868885	HOSE, TLO FILET/COOLER
868886	HOSE ASSEMBLY, AIR SUPPLY
868887	HOSE ASSEMBLY HYDRAULIC START RETURN
868888	HOSE ASSEMBLY, HYDRAULIC START
868889	HOSE, ASSEMBLY, HYDRAULIC STARTER
868890	HOSE WATER INJECTION SUPPLY
868891	HOSE, ASSEMBLY, WATER WASH SUPPLY
871-B32686S7474K561	CAPACITOR .47UF 1200V for VSR100 / VSR175
87461146	ORING, FILTER HOUSING
883-3-14C	Thermocouple T5:4
88593	AFT Mount Bearing
88697	MT BOLT, HOT END
88698	BOLT,ENGINE MOUNT HOT END - LM2500
88702	PIN, MOUNTING
8904-931	GAS VALVE ACTUATOR, 3103 VLV WITH TM-55P
8915-094	Valve, gas
8915-094-OH	Gas Valve
8915-094AR	GAS, VALVE, AS REMOVED
8915-1010	Valve, Fuel
8915-1010-AR	VALVE, FUEL, AS REMOVED
8915-1023	Valve, Water
8915-1023-AR	VALVE, WATER, AS REMOVED
8915-1024	VALVE, FLOW CONTROL, WATER INJ.
8915-1024-AR	AS REMOVED VALVE, WATER
8915-1024-OH	VALVE, WATER
8915-1029	Gas Valve, Woodward
8915-1310	Valve, Fuel
8915-1310-AR	VALVE, FUEL, AS REMOVED
8915-1310-OH	VALVE, FUEL
8915-1311	Valve
8915-1315	Valve, fuel
8915-1317	Valve
8915-1320	Gas Valve, Woodward
8915-1320-AR	Gas Valve, Woodward, AS REMOVED
8915-1320-OH	Gas Valve, Woodward
8915-1322	GAS VALVE, WOODWARD
8915-1323	Gas Valve, Woodward
8915-1323-OH	GAS VALVE, WOODWARD, OVERHAULED

Part Number	Description
8915-1323AR	GAS VALVE, WOODWARD AR
8915-1325	Valve, Woodward
8915-1328	Valve, Woodward
8915-1329	Gas Valve, Woodward
8915-1329-OH	Gas Valve, Woodward
8915-153	Gas Valve, Woodward
8915-371	STIG valve, Woodward
8915-429	Water Valve, Woodward
8915-429-OH	Water Valve
8915-429AR	VALVE, WATER, AS REMOVED
8915-526-AR	VALVE, FUEL, AS REMOVED
8915-652	Gas Valve, Woodward
8915-652-AR	VALVE, GAS, AS REMOVED
8915-877	LIQUID VALVE, WOODWARD
8915-877AR	Liquid Valve, Woodward
8915-886	Gas Valve, Woodward
8915-886-AR	GAS VALVE, WOODWARD AR
8915-887	Fuel Valve
8915-947	Valve, Water
8915-948	VALVE, FLOW CONTROL, WATER INJ.
8915-948-AR	VALVE, FLOW CONTROL, WATER INJ.
8915-948-OH	VALVE, FLOW CONTROL, WATER INJ
8915-955	Gas Valve, Woodward
8915-955AR	VALVE, GAS, AS REMOVED
8915-972	Valve, Woodward
8918-082	GSOV
8918082*WIC	GSOV
894A500P19	BRUSH, MOTOR
895C715G01	Cable, Igniter
898891	HOSE, ASSEMBLY, WATER WASH SUPPLY
8AWG THHN	8 AWG THHN SINGLE STRAND
8EA2AEN1	Cable, PT Speed NPT
8EH15AAA1	CABLE, PATCH
8EH28AAC1	CABLE, IGV/LVDT/XN2, LEFT
8EH28AAD1	CABLE, IGV/LVDT, RIGHT
8EH28AAE1	CABLE, XN25 SPEED
8EH28AAF1	CABLE, VBV/VSV/LVDT
8EH28AAG1	CABLE, CHIP DETECTOR, A/B
8EH28AAH1	CABLE, TEMP LUBE & SCAVENGE
8EH28AAJ	CABLE, TEMP LUBE RTD, D&E SUMPS
8EH28AAK1	CABLE, VBV/VSV-LVDT, RIGHT SIDE
8EH28AAL1	CABLE, CRF ACCELEROMETER
8EH28AAM1	CABLE, TEMP COMPRESSOR DISCHARGE, T3
8EH28AAN1	CABLE, MANIFOLD TEMPERATURE
8EH28AAP1	CABLE, XNSD SPEED
8EH28AAR1	CABLE, TRF ACCELEROMETER
8EH28AAT1	CABLE, OFF-ENGINE, T/C, T48
8EH28AAU1	CABLE, EGT THERMOCOUPLE, LOWER
8EH2AAE1	Cable ASSY; T5:4
8EH2AAF1	Cable ASSY; T5:4
8EH2AAT1	CABLE, LPT, SPEED
8EH2AAT2	CABLE, LPT, SPEED

Part Number	Description
8EH2AAU1	CABLE, LPT, SPEED
8EH2AAU2	CABLE, LPT, SPEED
8EH2ABT1	T4.4 CABLE
8EH2ABW1	CABLE, TBV
8EH2AEB1	Cable, Staging Valve
8EH2AED1	Cable, Staging Valve
8EH2AEE1	Cable, Staging Valve
8EH2AEF1	Cable, Bleed Valve
8EH2AEG1	CABLE, CLUTCH OIL DRAIN RTD
8EH2AEH1	Cable, Chip Detector
8EH2AEJ1	Cable, CRF Accel
8EH2AEK1	CABLE, TRF ACCELEROMETER
8EH2AEL1	CABLE, T/C
8EH2AEM1	Cable, N1 N2 Speed
8EH2AEN1	Cable, PT Speed NPT
8EH2AEP1	Cable, T3
8EH2AER1	Cable, Dynamic Pressure Sensor
8EH2AET1	Cable, Dual RTD/VSV/LVDT
8EH2AEU1	Cable, VSV
8EH2AEV1	Cable - Temp., Fuel Manifold
8EH2AEW1	Cable, Staging Valve
8EH2AHM1	Cable, NGG1 GG Speed
8EH2AKC1	Cable, Staging Valve
8EH2AKD1	Cable, Staging Valve
8EH2AKG1	Cable, Chip Detector
8EH2AKR2	Cable, T48 Upper Thermocouple Harness
8EH2AKT1	Cable, T48 Lower Thermocouple Harness
8EH2ALA1	Cable, TRF Accel
8EH2ARS1	CABLE, TBV
8EH2DEM1	CABLE, ELEC, NGG1 GG SPEED
8EH2DHA1	CABLE, STAGING VALVES, RIGHT
8EH2DHB1	CABLE, STAGING VALVES, LEFT
8EH2DHC1	CABLE, TBV
8EH2DHD1	CABLE, 8TH STAGE BLEED VALVE
8EH2DHF1	CABLE, TEMP COMPRESSOR DISCHARGE, T3
8EH2DHM1	Cable, NGG1 GG Speed
8EH2DHR1	CABLE, DYNAMIC PRESSURE SENSOR
8EH2DHS1	Cable, PT Speed NPT
8EH2DHT1	Cable, T5:4
8EH2DHU1	Cable, T5:4
8EH2DHW1	CABLE, ACCEL, CRF/TRF
8EH2DHY1	Cable, Dual Element (200 ohm RTD)
8EH2DJB1	Cable, VSV 1 Controls
8EH2DJC1	Cable, VSV 2 Controls
8EH2DJD1	Cable, PT Control Harness
8EH2DJE1	Cable, Fuel Solenoids, GG Speed 1
8EH2DJF1	Cable, RTDs, Lube Oils
8EH2DJG1	Cable, Ignition System
8EH2DJH1	Cable, CRF, TRF Accelerometers
8EH2HAA1	Cable, CRF Accel
8EH2HAB1	Cable, TRF Accel
8EH2HAC1	Cable, RTD Transfer

Starfish PPS - Complete Catalog

Part Number	Description
8EH2HAD1	Cable, NGG1 GG Speed
8EH2HAE1	Cable, Liquid Fuel
8EH2HAF1	Cable, PT Speed NPT
8EH2HAG1	Cable, HP Exhaust Temp
8EH2HAH1	Cable, T3 Comp. Discharge
8EH2HAJ1	Cable, Sensor Dual RTD/VSV LVDT
8EH2HAK1	Cable, Chip Detector
8EH2HAL1	Cable, VSV Servo Valve
8EH6AABU1	CABLE, TC
8EH8CAA1	CABLE, FLAME SENSOR
8EH8CAD1	CABLE, UV FLAME DETECTOR
8EH8CAE1	CABLE, UV FLAME DETECTOR
8EH8CAT1	CABLE, UV FLAME DETECTOR
8EH8CHM1	CABLE, SERVO
8EH8CJA1	CABLE, LVDT
8EH8DBK1	CABLE, UV FLAME DETECTOR
8EH8DHK1	CABLE, UV FLAME DETECTOR
8EH8EAB1	CABLE, UV FLAME DETECTOR
8TC19AAE1	Sensor
8TC34ABY1	T48 Thermocouple
8TC34BAG1	T5.4/T4.4 T/C PROBE
8TC37AAR1	T3 Sensor
8TC37AAY1	SENSOR, T3
8TC37ABA1	SENSOR, T3
8TC37ABJ1	Thermocouple T5:4
8TE34ACE2	3 T/C Harness Top Rt
8TE34ACF2	3 T/C Harness Top Left
8TE34ACH2	3 T/C Harness Bottom Right
8TE34ACJ2	2 T/C Harness Bottom Left
8TR1AAB1	THERMOCOUPLE, WHEELSPACE
8TR4AAJ1	Thermocouple
8TR4AAS1	THERMOCOUPLE, WHEELSPACE
8TR4AAT1	THERMOCOUPLE, WHEELSPACE
8TR4ACF1	Thermocouple, Wheel-space
8TR4ACM1	THERMOCOUPLE, WHEELSPACE
8TR4ACP1	Thermocouple, Wheel-space
8TR4ACT1	THERMOCOUPLE, WHEELSPACE
8TR4ACV1	Thermocouple, Wheel-space
8TR4ACW1	Thermocouple, Wheel-space
8TR4AFR1	Thermocouple, Wheel-space
8TR4CAL1	Thermocouple, Exhaust
8TR4CAL1-AR	THERMOCOUPLE, AS REMOVED
8TR4DAA1	Thermocouple, Exhaust
9-90035	Gasket
9-PS-3380	RING, PACKING, PRESSURE BREAKER
900-3011-0000	TELKOOR POWER SUPPLY
900-3011-10-AR	POWER SUPPLY
90016G01	RACKING MECHANISM RETAINER ASSY
90040G01	TOC SWITCH ASSEMBLY
9007M01	VALVE, CHECK
9009M32P01	WASHER, KEY
9009M39P01	Seal

Starfish PPS - Complete Catalog

Part Number	Description
9009M74P01	GASKET
9009M74P03	Gasket
9010M11P06	Bolt, shear
9011M60P01	Gasket
9013M28P01	Gasket, Lube In Seal
9013M28P02	Gasket, Lube In Seal
9013M29P01	Gasket, Lube In Seal
9013M29P02	Gasket, Lube In Seal
9013M30P01	Gasket, Lube In Seal
9013M30P02	Gasket, Lube In Seal
9014M45P49	CLAMP
9014M79P256	COUPLING
9015M15P21	STRAP
9015M63P05	Rod, Actuation Push
9016M30P02	ASSEMBLY: SEAL, RING
9019-51	Valve, Check
9019F-51	Valve, Check
9022M50P01	BOLT
9022M73P06	Washer
9025M29G01	Nut
9032M78P05	SEAL
9032M81P03	Seal
9039M45P09	Pump
9040M58P02	Conditioner, Signal, Remote
9044624-1	Igniter Plug
9048M33P06	Bearing
9048M34P03	BEARING, PLAIN ROD END
9049M91P07	CLEVIS
9051M51G04	Connector, VSV Bridge S1
9051M52G04	Connector, VSV Bridge
9051M53G04	Connector, VSV Bridge
9055M89P03	3 T/C Harness Top Rt
9055M90P05	3 T/C Harness Top Left
9055M90P06	3 T/C Harness Bottom Right
9055M91P03	2 T/C Harness Bottom Left
9057M92P04	Gasket
9057M92P05	Gasket
9057M92P08	Gasket
9057M92P10	Gasket
9057M92P11	Gasket
90585A718-M	Screw, FHCS, 1/2"-13 x 13/4", SS, Modified
90585A724-2.75M	Screw, FHCS, 1/2"-13 x 23/4", SS, Modified
90585A724-M	Screw, FHCS, 1/2"-13 x 3", SS, Modified
9059129-145	Lead, Ignition
9059129-205	Lead, Ignition
9059129-313	Lead, Ignition
9059129-385	Lead, Ignition
9059129-73	Lead, Ignition
9059360-145	Lead, Ignition
9059360-205	Lead, Ignition
9059360-313	Lead, Ignition
9059360-385	Lead, Ignition

Starfish PPS - Complete Catalog

Part Number	Description
9059360-73	Lead, Ignition
9059430-145	Lead, Ignition
9059430-205	Lead, Ignition
9059430-206	Lead, Ignition
9059430-313	Lead, Ignition
9059430-314	Lead, Ignition
9059430-385	Lead, Ignition, Flexible, 32 foot
9059430-386	Lead, Ignition
9059435-145	Lead, Ignition
9059435-205	Lead, Ignition
9059435-206	Lead, Ignition
9059435-313	Lead, Ignition
9059435-314	Lead, Ignition
9059435-385	Lead, Ignition
9059435-386	Lead, Ignition
905G1C4D3	Valve, Check
9079M28G12	SLEEVE
9080M96G10	Bracket
9084M71P02	SEAL
90R075KC5NN80P4S1C29GBA361024	PUMP, START
90R075KC5NN80P4S1C29GBA361024-AR	PUMP, START
910001	TBV Gasket
9101M37P72	Igniter Plug
9102M17P02	Bushing
9102M17P09	Bushing
9103M46P01	PLUG
9103M85G02	PLUG, BORESCOPE
9106M39P04	Bushing
9107M21P06	Bolt
9107M23P01	Gasket
9107M23P02	Gasket
9107M25P04	Washer, Thrust
9107M35G08	STUD, BELLCRANK, WELDED FRAME
9107M99P01	Washer
9108M27P03	Bolt
9109M91P01	BOLT
9115M99P05	Flange
9116M48P03	STRAP, RETAINING
9116M48P05	Strap
9117M17P07	BOLT
9117M47P02	MT BOLT, HOT END
9128M71P02	PACKING
9130M96P02	Screw
9130M96P03	Screw
9130M96P06	Screw
9131M44P02	Bushing, VBV
9131M45P02	Washer, VBV
9134M25P117	STRAP
9134M25P125	Strap, Retaining
9134M25P33	STRAP
9134M25P41	Strap
9134M25P49	Strap, Retaining

Starfish PPS - Complete Catalog

Part Number	Description
9135M62P01	PLUG, HPC
9135M76P03	Bolt
9137M30P01	ROD
9137M95G02	CONNECTING LINK, ACTUATION RING
9137M95G05	LINK
913BDCM01-JE-0900	VALVE, RELIEF
913BDCM01-JE1050SET	VALVE, RELIEF
9146M80P02	Bushing
9146M80P03	Sleeve
9146M80P05	Sleeve
91520520	ELEMENT, THERMOSTATIC
9153M75P02	Transducer, Displacement
9154M98P03	Fuel Filter Assembly
91700	ADAPTER
9174M19P01	Washer
9174M20P01	STRIP
9181M41P02	Connecting Link
9181M41P04	Arm, Level, Stage 3
9181M42P04	LINK
9187M73P128	COUPLING
9187M73P140	Coupling
9187M73P36	Coupling Clamp
9193M69P19	SPACER
9198M35P02	SHIM
9198M65P03	NUT
9206M59P18	Spacer
9206M61P05	SPACER
9206M79P01	Washer
9206M79P02	Washer, Flanged
9206M79P03	washer
9206M79P10	Washer, Flanged
9206M79P11	washer
9206M79P16	Washer, Flanged
9206M79P17	washer
9207M53P06	Spacer
9207M53P09	SPACER
9207M68P01	Bushing
9207M68P02	Bushing,
9207M68P03	BUSHING
9207M68P08	Bushing,
9207M68P13	BUSHING, FLANGED
9207M68P14	Bushing,
9207M68P15	BUSHING
9208M42P01	WASHER
9208M64G02	NUT
9208M77P01	Weight
9208M90P01	BOLT
9208M91P01	BOLT
9208M92P02	Bolt
9211M13P05	BOLT
9211M30P01	BOLT
9211M36P01	NUT

Starfish PPS - Complete Catalog

Part Number	Description
9211M36P02	NUT, SELF LOCKING
9211M38P01	NUT
9211M39G02	BUSHING, SHROUD
9212M79P06	PLUG
9215M47P08	SPACER, RING
9219M19P05	SHIM
92304	STUD
9234M87P01	SEAL, METAL
9257M84P04	Gasket
926010-1680	Pin
9263M70P02	CLEVIS
92655A412-M	Bolt, HH, 1/2"-13 x 2", Grade 8, Modified
92655A416-M	Bolt, HH, 1/2"-13 x 2-1/2", Grade 8, Modified
9283M23P01	Bushing
9293M73P172	Clamp
9294M61P03	GASKET
9294M61P04	Gasket
9294M61P05	GASKET
9294M61P18	Gasket
9299M11P02	GASKET
9299M96G06	Plug, Borescope
9299M96G07	Plug, Borescope
9303M59G01	BRACKET
9303M65P01	Sensor, fan speed
9319100100	RELAY
9319500106	UNDERVOLTAGE RELAY
9324233	Hose
9329M26P01	Bolt, Borescope Plug; stg 10, 12, 13
9331M55P02	Ring, seal, blade retaining
933576Q	FILTER, HYDRAULIC
9349M73P02	Clevis, Actuation Compressor Stator
9354M40P02	Gasket
93552	ELECTRONIC SWITCH
9358M66P117	Strap, Ring
9358M66P29	STRAP, RETAINING
9358M66P33	Strap
9358M66P37	STRAP
936001-1003	GASKET, SPIRAL WOUND
936001-1005	GASKET, SPIRAL WOUND
9365M41P117	Gasket
9365M41P122	Gasket
9365M41P229	Gasket
9365M41P236	Seal
936600-1250	SEAL
936600-1300	Metal Gasket Ring, E Seal
9371M19P04	Seal
9371M19P05	SEAL
9371M19P06	Seal
9371M19P08	Seal
9371M19P10	Seal
9371M19P12	Seal

Starfish PPS - Complete Catalog

Part Number	Description
9378M31P01	Fitting
9379M41G05	SHROUD ASSY
9379M42G04	SHROUD ASSY- STAGE 2 VANE
9379M93P01	Gasket, Thermocouple
9385661	GAUGE, 4-1/2", 100 PSI
939-B1549-04	Valve, Check
9392M95P04	PLUG, IGNITER
9392M95P04SHIM	SHIM, IGNITER
9392M95P07	PLUG, IGNITER
9397M20P02	Adaptor
9397M22P02	Washer, Locking
940281	Starter
94121-001	THERMOSTAT
941NC-4350	CLAMP
942-2-12C	SENSOR, SPEED
9432E-825-T	V-Coupling, Voss
9441M54P02	Offset Wrench
9441M54P03	T Handle
9443141P0165	PIN, , ANCHOR, 3/8" DIA, 1" LTH, FERROUS METAL
9488M18G01	Toolkit, Engine Maintenance
95-115	ELEMENT GLO
95-117	Filter, Element
9504M33P01	Sensor
952438D	BREAKER, CIRCUIT
9559M19P01	Seal, Fuel Nozzle Ring
9559M20G01	ASSEMBLY: SEAL, RING
9559M20G02	ASSEMBLY: SEAL, RING
9566	Expansion Joint
957.09.05.1510	GENERATOR, SIGNAL, PRECISION
9580706	KIT, GASKET, OVERSPEED TRIP
958405-12	Gasket
958405-28	Gasket, Seal-Flange
958406	Gasket, Seal-Flange
9600M37P12	Cable, Power, Electric
9600M37P13	Igniter Cable
9600M37P14	Ignition Lead
9600M37P15	Ignition Lead
9601M54G02	SHIM
9601M73P07	Seal
9602941-57	MAVR ASSEMBLY
9602M39P02	NUT, CHANNEL
9606M45P01	Sleeve Bushing
9607M05P08	PACKING
9607M05P21	O-RING
9607M80P03	Ring, Keyed, Retaining
9608M08G16	Gasket
9608M08G43	Gasket
9608M08G44	Gasket
9608M08G45	Gasket
9608M08G46	Gasket
9608M08G47	Gasket
9608M08G48	Gasket

Starfish PPS - Complete Catalog

Part Number	Description
9608M08G51	GASKET, SQUARE
9608M08G52	GASKET, SQUARE
9608M08G53	Gasket
9608M08G54	Gasket
9608M08G55	Gasket
9608M12P02	Gasket
9608M12P04	Gasket
9608M80P03	RING, KEYED, RETAINING
9609M13P02	GUIDE, VSV
9609M43P01	Washer
9609M43P02	Washer
9609M43P03	Washer
9609M43P05	Washer
9609M88P04	Bushing
9610M50P01	NUT
9610M50P02	NUT, 12 PT
9610M50P03	Nut
9610M50P04	NUT
9610M50P05	Nut
9610M50P20	Nut
9610M50P21	Nut
9610M50P23	Nut
9610M50P27	Nut
961101MFA	VALVE, PRESSURE RELIEF
962609900	C10 Low Speed Detector
9627M01P01	Gasket
9627M01P02	Gasket
9627M62P02	Pin
9628M16P02	Bolt
9629M48P02	Nut, 6 PT
9629M48P03	Nut, 6 PT
9629M48P04	NUT, 6 PT
9629M48P06	Nut, 6 PT
9629M48P10	Nut, 6 PT
9629M62P02	GASKET
9629M79P116	Gasket
9629M79P16	GASKET
9629M83G02	Seal
9632M56P01	CLIP
9634M42P03	SLEEVE
9634M85P01	RING, MATING
9634M85P06	Ring, Seal Mating
9643M56P01	Gasket
9643M56P02	Gasket
9643M84P02	Gasket
9644M72P03	NUT
9646M51P07	SLEEVE, ALIGNING
9649M39P02	Clamp, Coupling
9649M39P04	Clamp, Coupling
9649M39P05	Clamp, Coupling
9649M41P08	Bearing
9654M24P01	Washer

Starfish PPS - Complete Catalog

Part Number	Description
9655M01P04	Seal Ring
9655M01P07	Seal Ring
9655M01P10	Seal Ring
9655M01P12	Seal Ring
9655M01P13	Seal
9658M51P03	BEARING
9658M93P02	Seal
9661M72P02	PACKING
9661M98P01	Pin / Bolt
9662M67P01	Bolt
9662M72P06	BOLT
9663M71P07	Nut
9663M71P13	NUT
9664M68P01	Nut
9665M50P01	Bolt
9665M50P04	BOLT
9665M50P06	BOLT
9665M50P13	Bolt
9665M55P01	Bolt
9670M46P05	Gasket
9673M11P02	BUSHING
9673M11P04	BUSHING, FLANGED
9673M66G15	LEVER
9680M73G03	PLUG, BORESCOPE
9681M48P06	BUSHING
9682M50P06	GUIDE
9682M74P01	REDUCER
9686M65P01	NUT
9686M80P02	Plug, Borescope 9, 10, 11
9687M21P01	NUT, CHANNEL
9687M94P03	STRIP
9688M09P01	STRIP, OUTER
9688M11P01	Washer
9691M29P25	Actuator, VSV
9693M35P04	Seal
9693M35P08	Seal
9693M65P01	Screw
9693M68G04	SPACER, ACTUATION RING
9697M19P01	PLUG
9699M11P02	Bearing
9699M66P01	Bolt
9713M89P03	Cover
9713M89P12	Cover Plate
974A0953P007	Nut
9753CG	Contact Kit
97619A440	Nut
98HH	REGULATOR, FISHER
98HH-KIT	KIT, OVERHAUL
9902-072	Pump
9902-222	VALVE, SERVO
9902-332	CONTROLLER, VSV
9902-363	Actuator

Starfish PPS - Complete Catalog

Part Number	Description
9902-364	HYDRAULIC CONTROL UNIT
9902-364-AR	HYDRAULIC CONTROL UNIT
9902-364-OH	HYDRAULIC CONTROL UNIT
9902-369	Valve, servo
9902-398	PUMP
9902-398-AR	PUMP; AS REMOVED
9902-402	VALVE, SERVO
9902-404	VALVE, SERVO
9902-406	Control
9902-406-OH	CONTROLLER, VSV, OVERHAULED
9902-412	VALVE, SERVO
9902-414	VALVE, SERVO
9902-420	VALVE, STAGING
9902-420-AR	VALVE, STAGING, AS REMOVED
9902-420-OH	VALVE, STAGING
9902-428	PUMP
9902-428-AR	PUMP, AS REMOVED
9902-441	ASSEMBLY: SERVO VALVE & PUMP
9902-458	PUMP, VSV
9902-458-OH	PUMP, OVERHAULED
9902-459	Servo and Pump, VSV
9902-461	ASSEMBLY: SERVO VALVE & PUMP
9902-469	ASSEMBLY: SERVO VALVE & PUMP
9902-471	ASSEMBLY: SERVO VALVE & PUMP
9902-700	ASSEMBLY: PUMP, VSV
9902-701	HYDRAULIC CONTROL UNIT
9904-1351	Actuator
9904-1759	Valve, Gas Fuel Control
9904-1875	Valve, Control
9904-264	HYDRAULIC SERVO VALVE
9904-516	VALVE, LSOV
9904-532	GSOV, Woodward
9904-534	GSOV
9904-549	GSOV, Woodward
9904-549-OH	VALVE, OVERHAULED
9904-549AR	GSOV, Woodward
9904-581	GSOV, Woodward
9904-773	SRV,W/ 6 INCH FSHR VALVE, DUAL LVDT
9904-938	Valve
9905-1548	VALVE, GS6
9905-285	Proportional Actuator
9905-449	GSOV
9905-708	Digital Synchronizer and Load Control
9905-708-OH	DIGITAL SYNCHRONIZER, OVERHAULED
9905-760	RESISTOR, TERMINATING
9905-760-AR	RESISTOR, AS REMOVED
9905-964	Valve, Gas Shut Off
9905-968	Linknet, 6-Ch Analog Input 4-20 mA w/o 24 V Loop Power
9905-968-AR	MODULE, LINKNET, AS REMOVED
9905-969	Linknet 6-Ch Analog Input 4-20 mA w/ 24 V Loop Power
9905-969-AR	MODULE, LINKNET, AS REMOVED
9905-970	Linknet Module, 6 CHannel, 100 ohm RTD

Starfish PPS - Complete Catalog

Part Number	Description
9905-970-AR	MODULE, LINKNET, AS REMOVED
9905-971	Linknet 16-Ch Discrete Input 24 Vdc
9905-971-AR	MODULE, LINKNET, AS REMOVED
9905-972	Linknet, 6-Ch Analog Output 4â€“20 mA
9905-972-AR	MODULE, LINKNET, AS REMOVED
9905-973	LINKNET, MODULE, DISCRETE OUT
9905-973-AR	MODULE, LINKNET, AS REMOVED
9907-1142	Valve, EGMV, 3 in
9907-1143	Valve, Fuel, Metering
9907-1144	Valve, Metering
9907-1145	Water Injection Metering Valve. EWMV,2IN,RF900#,SS-CF8M,20.8CV,NA-EU,-40TO250F,125VDC,SPRING,O,REM
9907-1187	Woodward valve
9907-1196	MANIFOLD - 1000 PS
9907-1207	GSOV
9907-1231	VALVE - EWMV UNPLATED,2IN
9907-1233	Valve
9907-1264	Valve, USOV, 3 inch
9907-135	DRIVER
9907-1456	Gas Fuel Metering (Primary) - VALVE - EGMV,3IN,RF600#,SS-CF8M,2.5ACD,NA-EU,-40TO380F,125VDC,SPRING,0,REM
9907-1457	Valve, Fuel, Metering
9907-1460	Water Injection Metering Valve. EWMV UNPLATED,2IN,RF900#,SS-CF8M,20.8CV,NA-EU,-40TO250F,125VDC,SPRING,O,REM
9907-186	Driver - GS10 Gas Valve UL/CSA
9907-331	Transducer, DLE
9907-487	GSOV, Woodward
9907-487-OH	GSOV, WOODWARD, OVERHAULED
9907-487AR	GSOV, WOODWARD
9907-502	Gas Fuel Metering (Primary) - EGMV,3IN,RF600#,SS-CF8M,2.5ACD,NA-EU,-40TO380F,125VDC,SPRING,0,REM
9907-503	Valve, Fuel, Metering
9907-504	Valve, Fuel, Liquid
9907-506	Water Injection Metering Valve. EWMV,2IN,RF900#,SS-CF8M,20.8CV,NA-EU,-40TO250F,125VDC,SPRING,O,REM
9907-526	Valve, Fuel, 2"
9907-526-AR	VALVE, FUEL, AS REMOVED
9907-528	Woodward valve
9907-559	Woodward GS6 valve
9907-561	Valve, GS16
9907-572	Valve
9907-652	Valve, Control
9907-696	Valve, Control, LQ25
9907-861	GSOV HT
9907-862	EM/TM Resolver
9907-869	Valve
9907-870	Valve
9907-896	Valve,
9907-954	Woodward GS6 valve
9907-960	Actuator
9907-962	TRANSMITTER, PRESSURE, 12-800 PSIA
9907-963	Transmitter
9907-994	Valve, Control, LQ25
9907-995	Valve, Control, LQ25

Starfish PPS - Complete Catalog

Part Number	Description
9907-995-AR	Valve, Liquid Fuel
9907-996	Valve, LQ25
9908-1501	Fuel Valve
9908-1502	VALVE, FUEL
9908-1532	Valve, Fuel
9908-1534	Valve
9908-1548	Woodward GS6 valve
9908-1548-AR	Woodward GS6 valve
9908-1548-OH	WOODWARD GS6 VALVE, OVERHAULED
9908-1549	Woodward GS6 valve
9908-1549-OH	Woodward GS6 valve
9908-1556	Woodward GS6 valve
9908-1581	VALVE, FUEL
9908-1603	
	Gas
	Metering Valve
9908-1607	
	VALVE,GS50,2"/RF600#/SST/2.0ACD,125V,N0S
9908-1642	Gas Metering Valve
9908-200	LQ25T
9908-201	Valve, Bypass, Liquid Fuel
9908-211	Valve
9908-216	Valve, Control, LQ25
9908-222	VALVE, Fuel
9908-224	VALVE, FUEL
9908-233	LQ25T
9908-234	VALVE-LQ25, 0.3 SQ INCH, PIV/SOV/24 VDC
9908-265	Valve, Fuel Metering
9908-354	Valve, Shutoff
9973	NOZZLE, FOG, AMMONIA
99807-0438	CLAMP
998367-17	Metal Gasket Ring, E Seal
998367-24	Gasket, Liquid Fuel Mix Block
9F60BHH001	FUSE 15.5 KV
9F60CMJ905	Fuse
9F60FMH050	FUSE, 15.5KV
9RD0216	Flow Divider
9T51B0171	TRANSFORMER
9T58B0055	TRANSFORMER, 60HZ
A	Transmitter
A-0745	O-Ring
A-1127	VALVE, PRESSURE MODULATION
A-18682	INDICATOR, CYCLE
A-3507	O-Ring
A-5374	Sight Glass
A0124	DISC, RUPTURE
A1013353	Diaphragm Assembly
A1013357	Diaphragm Assembly
A1013359	Kit, Guide Cage Assembly
A1013368	Kit, Guide & Springs for Diaphragm Assemblies
A1013370	Kit, Guide Cage Assembly
A1013372	Kit, Diaphragm Cove w/ Cover & Fitting
A1013376	Kit, Diaphragm Cove Includes Cover

Starfish PPS - Complete Catalog

Part Number	Description
A1013386	Kit, O-Ring Replacement
A146826	
A4J35	FUSE, 35A
A4J6	FUSE, 6A
A4J70	FUSE, 70A
A50TF201	Anti-Seize, Graphite Paste
A5Y10-2	FUSE, 10A
A5Y15-2	FUSE, 15A
A5Y2-2	FUSE, 2A
A5Y20-2	FUSE, 20A
A5Y5-2	FUSE, 5A
A7601350-A79A5679	Blower Wheel + Retainer
A804	FITTING, FIXTURE, END CAP, STEEL
AA4VG125EP2D1/32R-NSF52F001PX-ES	PUMP, VG
AA6VM107HA1	Hyd Start Motor
AA6VM107HA1/63W-VSD527A	Starter Motor
AA9227-1640D2A-BOWL	Filter Bowl
AA9500D102	Screw, Socket head, special fuel system
ABSBDCM01-JEO800	VALVE, RELIEF
AC-B244F-2440	Filter Element
AC-B244F-2440Y1	VG Filter
AC9227F1640	FILTER, ELEMENT
ACB24424D2Y	Filter Bowl
ACB244F2440	Filter Element
ACB244F2440Y1	VG Filter
ACE038N3NVBP-A101	Oil Pump
ACE038N3NVBP-A413	Gen Lube Pump
ACE038N3NVBP-A413-OH	Oil Pump
ACE382NC101	Pump
ACETONE	
ACG045N7NVBP	Lube Pump
ACG045N7NVBP A101	Lube Pump, Counterclockwise
ACG045N7NVBP-OH	Lube Pump
ACS-3BF-13.63" X 4"	Element, Filter
AD-B244-24	FILTER ASSEMBLY
AD-B244-24-AR	FILTER ASSEMBLY - AS REMOVED
AE-229-110	ELEMENT, FILTER, Exhaust
AE5312957	PreFilter Panel
AF1530PW4V-140	Valve
AF24-SR	Belimo
AHPB22443H	Bearing
AI-PM3-3KT-L-SS	MONITOR, PRESSURE, 3000PSI
AIP015-0015-10	CONTROLLER
AIP100-0039-10	RESISTOR, .057 OHMS
AIP302-0004-10	DIODE, REDUNDANCY MDL
AIP490-0010-10	RELAY, 24VDC
AIP490-0037-10	RELAY, OVERLOAD
AL1269	Fuse 4 A
AL1308	Micro Fuse 31 mA
AL1310	Micro Fuse 100 mA
AL1328	Micro Fuse 2 A
AL1335	Micro Fuse 50 mA

Starfish PPS - Complete Catalog

Part Number	Description
AL8001440	Module, input, fire system
AL8001440D	Module, input, fire system
AL8001440DEV38	AL8001440DEV:38 DEVIATED MODULE
AL8001441	Manual Pull Module
AL8001442	Module, Alarm
AL8001442D36	Alarm Module (Horn & Strobe Driver) PSW
AL8001443-D	Digital Release Module
AL8001444	Fault Module
AL8001444D46	Fault Module (RU)
AL8001457	4-20 mA Gas Module
AL8001530-M	Master input mod. 2 Channel
AL8001530-S	Slave input mod. 2 Channel
AL8001537	Remote Relay Module
AL800169016	16-Slot Rack
AL8001760	MODULE, RELAY
AL8001800	Status Module
AL8001820	Release Module
AL8002800	Cycle release module
ALH_5747.2	ADAPTER, TERMINAL BLOCK
ALPA1-D-3-TR	Pump, Jacking
AN122705	PIN
AN122766	Pin
AN123469	RIVET
AN123470	RIVET, FLAT HEAD
AN123480	RIVET, FLAT HEAD
AN123620	RIVET, SOLID
AN123622	RIVET
AN123631	RIVET
AN316C4R	NUT
AN6230-3	Ring
AN763-24	Gasket
AN919-13	Fitting
AN960	TC harness, Top right LM5000
AN960C10	Washer
AN960C10L	Washer
AN960C1216	Washer
AN960C416	Washer; 1/4
AN960C416L	Washer; 1/4
AN960C516	Washer; 5/16
AN960C516L	Washer; 5/16
AN960C616	Washer
AN960C616L	Washer; 3/8
AN960C816	Washer; 1/2
AN960C816L	Washer; 1/2
APD170148	Magnehelic Pressure Gage
APEX8000X81247A0T	ACTUATOR, WITH NT3000 TRANSDUCER
AR 000N6	TUBE
ARC-178681	O-Ring
ARC-180246	O-Ring
ARC-180654	Sight Glass
ARC-185746	Seal
ARC-204278	Gasket, Cylinder Cover

Starfish PPS - Complete Catalog

Part Number	Description
AS1001632	Fan Motor Mount & Adjustment Bolt Assembly, SERVICEABLE SURPLUS
AS151702	RTD, Casing
AS1895/1-150	Clamp, Coupling
AS1895/1-200	Clamp, Coupling
AS1895/1-225	Clamp, Coupling
AS1895/1-250	Clamp, Coupling
AS1895/1-300	Clamp
AS1895/1-350	Clamp, Coupling
AS1895/1-400	Clamp
AS1895/1-450	Clamp
AS1895/1-600	Clamp, Coupling
AS1895/23-125	Seal
AS1895/4-125	Clamp
AS1895/4-350	CLAMP
AS1895/7-150	E seal
AS1895/7-225	E seal
AS1895/7-250	SEAL
AS1895/7-300	Seal
AS1895/7-350	Metal Gasket Ring, E Seal
AS1895/7-400	Metal Gasket Ring, E Seal
AS1895/7-600	Metal Gasket Ring, E Seal
AS3209-026	O Ring
AS3209-210	O Ring
AS3209-219	O Ring
AS3209-228	O Ring
AS3209-278	O-RING
AS3237-08	BOLT
AS3237-10	Bolt
AS3237-22	BOLT
AS3238-15	Bolt, machine, DBL hex .3125-24 by 1.375
AS3251-16	BOLT
AS3481-04	NUT
AS3485-09	Nut
AS3485-10	Nut
AS3485-11	Nut, 12 PT
AS3486-10	NUT
AS3510-0224K	Bergen Cable; 24"
AS3580-4-34	BOLT
AS4370J04	Nut, Swivel
AS5355/3-15B	Clamp, Coupling
AS5355/3-22B	Clamp
AS568-178	O-RING
AS568-267	O-RING
ASC-3BX4	FILTER
ATL-IRR-460-N3-BRKR-STD	Breaker - Starter
ATMR1-1/2	FUSE, 1 1/2A
ATMR2	FUSE, 2A
ATMR3	FUSE, 3A
AWK-4121-EU-T	ROUTER
B1548-03-16	VALVE
B1548-04-10	Valve, Check

Starfish PPS - Complete Catalog

Part Number	Description
B1548-04-12	Valve, Check
B200S10L	Pneumatic Actuator
B43584S9338M2	CAPACITOR 3300UF 400V VSR100 / VSR175
B461BXNH30#	SWITCH, PRESSURE
B52555RK099K001	Filter Replacement Kit
B700A09H20C	VALVE, ., BOILER, TURBINE, 3-1/2"DIA, W/7-15/16" LG ST NON-ASBESTOS
B750CJ850F1B20	Thermocouple,
B984C302AP012	FILTER, HYDRAULIC
BA01B3T28E312	Accumulator
BA01B3T28E470	ACCUMULATOR, HYDRAULIC
BA01B3T28E470-AR	Accumulator, Hydraulic
BA01B3T28E470-OH	Accumulator, Hydraulic
BA01B3T28X312	Accumulator
BB10	Brush, Carbon
BDAX 7-290ERJT	BRUSH HOLDER AND CLAMP
BE12WH02	Cable, Mark VI
BFA1281-13	SENSOR, FLAME, UV
BFL58GC-3	REPAIRED PCB FOR 75 MVA TRANSFORMER
BLP-100-3	Lift Fixture Sling Set, 2 per set, 3'
BLP082219PJH	Jacking Pump Discharge
BLP7290ERJT	Generator Inspection Kit
BM327	Safety Cable Terminator
BRAYCO 599	BRAYCO PRESERVATIVE
BRGIP215L	Bearing
BRGIP215LE	Bearing
BSP601	GENERATOR ENCLOSE FAN GUARD
BSP605	Turbine Enclosure Fan Guard
BTL7-E500-M0100-K-K05	Magnetostrictive linear position sensor
BTW71P 71-Segment TRI-COLOR Circular Array	GAUGE, RPM
BUVTRXXXY4M	GAUGE, RPM
BZ2R244P1	Honeywell Switch
C-29592	Fan, Turbine Enclosure
C-4779	BRUSH, CARBON
C159462	Position Indicator Switch
C173255-5	Pressure Transducer
C324890	GASKET
C324892	FLANGE, SPECIAL, CDP
C325021	FLANGE, SPECIAL, CDP
C325022	FLANGE, SPECIAL, CDP
C325032-1	SWITCH, CDP VALVE
C325032-2	SWITCH, CDP VALVE
C326381	Bellows Assembly
C327335	Valve, CDP
C327335-OH	VALVE, CDP
C327345	Valve, CDP
C327345-OH	VALVE, CDP
C327405	Valve, CDP
C327405-OH	VALVE, CDP
C327875	VALVE, STAGING
C327875-AR	VALVE, AS REMOVED
C327875-OH	VALVE, STAGING, OVERHAULED

Starfish PPS - Complete Catalog

Part Number	Description
C329635-C102	Valve, Fuel Metering
C3X01S	VALVE, 3-WAY
C423095-1	Valve
C423105-1	Valve, Relief, 3-Inch - 24 VDC - Gas blowoff Valve
C423105-1-AR	Valve, Relief, 3-Inch - 24 VDC - Gas blowoff Valve - AS RE
C423115-2-AR	VALVE, AS REMOVED
C423115-4	VALVE, VENT
C423115-4-AR	VALVE, AS REMOVED
C423115-4-OH	VALVE, OVERHAULED
C423155-1	Valve, Drain, Manifold
C423675-1	Valve
C424035-7	Valve, Bleed Air
C424035-8	Valve, Bleed Air
C424045-4	VALVE, BLEED AIR
C424045-4-AR	VALVE, BLEED AIR, AS REMOVED
C424045-4-OH	VALVE, BLEED AIR, OVERHAULED
C424065-7	Valve, Bleed Air
C520325-1	Valve, solenoid
C520325-1-OH	Valve, solenoid
C604165	Gasket, Fuel Nozzle, SEAL RING
C66070-001-OH	PUMP, SMEC, OVERHAULED
CA21000-11-05-00-085-03-02	Vibration Element
CC-DCN-DCDC-005	DECON with Solvancer, 5 gallon pail
CD5.241-L1	DC/DC CONVERTER, 92 W
CDP PURGE VALVE FLANGE KIT	CDP PURGE VALVE FLANGE KIT
CEP20820	Expansion Joint
CEP9566G001	Expansion Joint
CG-1J	Gasket, Flange, 3-150 #RF
CGI-3D	TBV Gasket
CGI-6G	Spiral Wound 2" 600
CGS4332316NE3B171L14D024	Valve
CGSS1A6C2R1X	SENSOR, GAS
CGSS1A6V2R1X	SENSOR, GAS
CGSS1C6C2R1X	SENSOR, GAS
CGSS1C6V2R1X	SENSOR, GAS
CH31963	Igniter, plug
CH31966-1	Igniter, HT
CH38039	Ignitor
CL-75M	MALL, IRON, CL, 3/4"
CLA3240A-X01	Coolant Heating System
CM-MPN-525	ABB Protection Relay
CMF025M313N2B2EZZZ	CORIOIS METER, 1/4 INCH
CONTAINER	CAN, TRANSPORT, LM2500, UNIVERSAL
CPD PURGE VALVE FLANGE KIT	CDP PURGE VALVE FLANGE KIT
CPIN2.375"-EQ	Connecting Pin, 3/8" D, 23/8"L, 321SS
CPIN2.75"-EQ	Connecting Pin, 3/8" D, 23/4"L, 321SS
CPIN3.375"-EQ	Connecting Pin, 3/8" D, 33/8"L, 321SS
CPIN3.625"-EQ	Connecting Pin, 3/8" D, 35/8"L, 321SS
CPT5-95-5-SDO7032	TRANSFORMER, CONTROL POWER
CR05-2104	Filter Element
CR104PSG34B91A	Switch, 3 position, maintain
CR104PXC1	Contact Block

Starfish PPS - Complete Catalog

Part Number	Description
CR104PXG49	INDICATING LAMP
CR104PXL07R	Lens, Indicator Light
CR120E01102	GENERAL PURPOSE INDUSTRIAL RELAY
CR123C184A	HEATER, PANEL MOUNTED OVERLOAD RELAY, NEMA 3
CR123F118C	HEATER, MOTOR STARTER, GE, NEMA SIZE 4
CR2L-200	FUSE, SUPER RAPID, 200A
CR2L-325	FUSE, SUPER RAPID, 325A
CR305E002AALH	CONTACTOR, CHILLER FAN MOTOR
CR305X100D	Aux Contact Kit
CR324CXCS	Overload Relay
CR324F310F	SIZE 4 3PH OVERLOAD RELAY NC
CR360L40302AAAA	CONTACTOR
CR463L20ANA	Contactors
CR487E6F2MJ4AAAAA	Breaker - Starter
CRN1S	PUMPSET, AMMONIA
CRN3-7	Pump/Motor Assembly
CS/006165F	Filter, Panel
CS51-100	CELL, CONDUCTIVITY
CS604LGH13	Filter Element
CSFR37K812R75B009	RESISTOR
CSG-3321-316-ME-S-XDBT4-D024	VALVE, SOLENOID
CSG-3321-316-ME-U-XDBT4-D024	VALVE, SOLENOID
CSK206(X)	Bearing
CT0093CE3D40000	Final Filter, Composite Cartridge
CT109804	Filter, Generator
CT112361-1	Hose Flex Duct 5.0-50
CT112508	Transducer, Pressure
CT112509	Transducer, Pressure
CT112510	Transducer, Pressure,12-18 PSIA
CT112558	Sensor
CT112599	DETECTOR, CHIP
CT112599-SP1	O Ring
CT112599-SP2	Valve
CT112763-0800	Gasket
CT112841-4610	Stud
CT112841-4650	Stud
CT112841-4650-3	Stud
CT113003	VALVE, CHECK
CT113009	Transducer, Pressure, 0-1500 PS1G
CT113015	Valve, Check, Steam, & Gas Fuel
CT113069	Valve, relief
CT113805	FILTER, HYDRAULIC PUMP
CT113863	VALVE, SOLENOID
CT114357	Transducer, Pressure, 0-100 PSIG
CT114358	Transducer, Pressure, 0-750 PSIG
CT114359	Transducer, Pressure, 0-1000PSIG
CT114361	Transducer, Pressure,0-200 PSIG
CT115328-1	VALVE, PRESSURE SAFETY
CT115567-2	Transducer, Pressure, 0-50 PSIA
CT115594-SP1	FILTER, OIL MIST
CT115594-SP2	O RING, FILTER
CT116171	RTD, Dual

Starfish PPS - Complete Catalog

Part Number	Description
CT116295	Transducer, Pressure 0-10 PSID
CT116346-1	Starter
CT116346-SP23	Seal, Starter Shaft
CT116346-SP24	Gasket, Plate Seal
CT116346-SP3	HOSE, CASE DRAIN
CT116529	RTD
CT116529-1	RTD
CT116560-1	Sensor
CT116567	Transducer, Pressure
CT116610-1	Pump, Vacuum, Assembly
CT116624-02	LS TC Harness
CT116624-03	RS TC Harness
CT116819-14	Transducer, Proximity
CT1169-46-1	O Ring
CT116911	Pump, Lube
CT116914	Pump, Lube
CT116937-5437-523	Module - Analog Field Term
CT116937-5437-672	Module, Netcon Field Term.
CT116937-5437-687	Module, Netcon 24 Channel Field
CT116937-5464-643	Module, Discrete Input
CT116937-5464-654	Module, D.O.64 Channel w/Watch
CT116937-5464-658	DIGITAL SPEED SENSOR
CT116937-5466-031	MODULE
CT116937-5466-258	MODULE, I/O
CT116937-5466-315	Module, High Density Analog I/O
CT116937-5466-316	Module, Analog Combination
CT116937-5466-353	Module, Main Transceiver
CT116937-5466-355	Transceiver
CT116937-5466-409	Micronet CPU
CT116937-5466-654	Discrete Out
CT116937-5466-658	Digital Speed
CT116937-5501-367	Module, Micronet Discrete FTM
CT116937-5501-371	Module, Micronet Simplex MPU & AIO FTM
CT116937-5501-376	Module, Analog, High Density, Simplex
CT116937-5501-432	Module, Actuator Netcon CONT.2C
CT116937-5501-465	Power Supply
CT116937-5503-267	Module, Netcon SIO
CT116937-5503-279	Board, Micronet HDVIM
CT116937-5503-282	Module, FTM HDVIM
CT116937-5566-258	High Density D. I/O
CT116937-5566-315	High Density A I/O
CT116937-9905-760	RESISTOR, TERMINATING
CT116937-9905-969	Linknet 6-Ch Analog Input 4-20 mA w/ 24 V Loop Power
CT116937-9905-970	Linknet Module, 6 CHannel, 100 ohm RTD
CT116937-9905-971	Linknet 16-Ch Discrete Input 24 Vdc
CT116938-1	Filter, Fuel
CT116939-5437-845	Notch Filter
CT116946-1	O Ring
CT116946-2	Packing, Preformed
CT116946-3	Filter, Relieving
CT116946-4	Packing, Preformed
CT116999-1	Fuse

Starfish PPS - Complete Catalog

Part Number	Description
CT117004-28	Filter
CT117004-29	Filter
CT117004-35	Coupling, Hub
CT117004-36	Coupling, Element
CT117004-37	Coupling, Element
CT117004-44	FILTER
CT117004-45	FILTER
CT117007-02	RS EGT Harness
CT117007-03	LS EGT Harness
CT117015-215	Gasket (set of 2)
CT117062-3	Filter Element
CT117088-1	WASHER
CT117101-16	Power Supply
CT117101-4	Transducer
CT117101-5	Transducer
CT117104	Clutch
CT117111	Harness, FT8, Engine, Left
CT117156	Valve, Gas Shut Off
CT117190-1	DETECTOR, CHIP
CT117190-4	DETECTOR, CHIP
CT117293	HYDRAULIC SERVO VALVE
CT117358	Valve, fuel
CT117358-1	Valve, fuel
CT117358-2	Valve, fuel
CT117369	Switch, Overspeed
CT117393	Actuator, TBalance
CT117419-2	Filter Element
CT117444-1	GSOV, Woodward
CT117444-2	Ring, Spacer, valve
CT117444-3	Gasket
CT117444-4	Kit, Conversion
CT117445	Valve, Control
CT117452	Woodward Driver
CT117452-AR	WOODWARD DRIVER
CT117453	Woodward Driver
CT117462	Exchanger, heat
CT117542	Valve, Fuel
CT117688-1	Valve, Dump, Fuel
CT117718-1	POWER SUPPLY, IGNITER
CT117728-35	Panel, Fire
CT117728-50-1	Panel, Fire
CT117915-1	Transducer, DIFF, Pressure, Lube System
CT117915-2	Transducer, DIFF, Pressure, FLT HSE
CT118017-1-23	Sensor
CT118017-2-10	Sensor
CT118017-2-20	Sensor
CT118025-11	Sensor
CT118025-12	Sensor
CT118025-17	Sensor
CT118032-1	Transmitter, Press
CT118032-12	Switch, Pressure
CT118032-19	Valve, Lube

Starfish PPS - Complete Catalog

Part Number	Description
CT118032-2	Gauge, Differential Pressure
CT118032-20	Valve, check
CT118032-26	Pump, L.O., DC Motor Driven
CT118032-28	Filter, L.O. Duplex
CT118032-29	Valve, Temp
CT118032-41	Element, L.O. Duplex Filter
CT118032-42	Element, Oil Mist
CT118032-43	Element, Oil Mist
CT118032-44	Valve
CT118032-45	Heater
CT118032-47	Oil Mist Eliminator
CT118032-5	Transmitter, Press
CT118032-50	Element
CT118032-6	Indicator, Temperature
CT118032-8	Switch, Level Alarm
CT118032-9	Switch, Level trip
CT118044-1	Transmitter, Pressure
CT118090-5466-1000	Power Supply, Micronet
CT118090-5466-1035	CPU, MICRONET
CT118090-5466-1036	WOODWARD, MICRONET+,
CT118090-5503-335	CPU, Motorola 5200, Micronet Plus
CT118117-8	Filter
CT118161	Valve, Control, LQ25
CT118162	Valve, Shutoff
CT118164-1	Motor
CT119176-01	Harness, FT8, EGT, Left
CT119176-02	Harness, FT8, EGT, Right
CT119176-03	Harness, FT8, EGT, Left
CT119176-04	EGT Kit, Bracket, Adapter
CT119176-05	EGT KIT, CABLE
CTL500L-58	LUG, COMPRESSION, COPPER
CTX10A3N2T	Combustible Gas Transmitter
CVHG12Y11S	Valve, Check
CVHG12Y31S	VALVE, CHECK
CVHG16Y41S	Valve, Check
CVHG6Y41S	VALVE, CHECK, GAS PURGE
CVHG6Y71S	valve, check
CXF230P231	Screwplug Heater 240V 3000W
CXH-A-05-43-32-40-20-EP	Heater
Conntect 6000	Turbine Cleaner, 55 Gallon Drum
D1VW020BVYCF	Valve, Control
D3W030BVYC51XB826	VALVE, SOLENOID
D40240802R322TC	Sol Valve, GSR
D40250802R322TC	Sol Valve, GSR
D5217771G005	Fuel Nozzle Tip
DBV10-E10-F0320	PRV, MLO
DC-3T-60K3-0000	WATLOW POWER CONTROLLER
DCM373T075CD2B	Capacitor
DCT24-25-A643	BATTERY CHARGER
DF 0320	HOUSING, FILTER
DF-0320-MK	Filter Assembly

Part Number	Description
DISCARD	DISCARD
DM639-00-C	Element
DM830-00-C	Filter
DM839-00-C	Filter, Element
DMSCK-85	GAS, CALIBRATION
DOLLY PARTS	MISC DOLLY PARTS, LM2500
DPI 611	Pressure Calibrator
DPI610E-SPC	Druck Calibrator
DPST-NC	RELAY, FINDER, MODULAR CONTACTOR
DPST-NO	RELAY, FINDER, MODULAR CONTACTOR
DS200ACNAG1A	CARD, ARCNET
DS200BDAAG1A	BOARD, SNUBBER
DS200CDBAG1B	BOARD, CONTACTOR DRIVER
DS200CPCAG1A	CARD, PILOT CONTRACTOR, CPCA
DS200DTBAG1A	BOARD, DIGITAL, CONTACT INPUT, TEAM
DS200DTBBG1A	BOARD, TERMINAL, DTBB INPUT, DIGITAL INPUT
DS200DTBCG1A	BOARD, TERMINAL, DTBC, RELAY SOLENOID
DS200DTBDG1A	BOARD, TERMINAL, DTBD, RELAY SOLENOID
DS200EXPSG1A	CARD, POWER SUPPLY, EXPS
DS200GDPAG1A	BOARD
DS200LPPAG1A	CARD, LINE PROTECTION, LPPA
DS200PCCAG1A	CARD, DC2000 POWER CONNECTOR
DS200PCCAG6A	CARD, DC2000 POWER CONNECTOR, PCCA
DS200PTBAG1A	CARD, TERMINAL, PTBA MODULE
DS200PTBAG1B	BOARD, TERMINAL, PTBA MODULE
DS200PTCTG1A	BOARD, SIGNAL CONDITION, EX2000, PTCT
DS200QTBAG1A	BOARD, TERMINAL, QTBA MODULE
DS200RTBAG1A	CARD, RELAY, RTBA
DS200SDCCG1A	CARD, DRIVE CONTROL, SDCC
DS200SHVMG1A	CARD, SCR HIGH VOLTAGE, SHVM
DS200SLCCG1A	CARD, LAN COMM., SLCC
DS200SNPAH1A	MODULE
DS200TBCAG1A	BOARD, TERMINAL, TBCA, ANALOG SIGNAL
DS200TBQAG1A	BOARD, TERMINAL, TBQA, RST, TC, S16
DS200TBQBG1A	BOARD, TERMINAL, TB0Q, RST ANALOG, SI
DS200TBQCG1A	BOARD, TERMINAL, TB0B, RST, ANALOG SI
DS200TBQCG2A	Analog I/O Terminal Board
DS200TCCAG1B	MKV, Common Analog Card
DS200TCCBG3B	CARD, EXPANSION ANALOG, I/O, TC2000, TCCB
DS200TCDAG1B	BOARD, DIGITAL I/O
DS200TCDAG1B	BOARD, DIGITAL I/O, COAT, TCDA
DS200TCEAG1B	BOARD, EMERGENCY OVERSPEED
DS200TCEAG2B	Emergency Overspeed Card
DS200TCEBG1B	BOARD, COMMON CIRCUITS EOS, TCEB
DS200TCPDG1B	MODULE, POWER DISTRIBUTION, TCPD
DS200TCPSG1A	MKV, DC Input Power Supply Card
DS200TCQBG1B	BOARD, RST, EXTENDED ANALOG, TCQB
DS200TCQCG1B	BOARD, RST, OVERFLOW, TCQC
DS200TCRAG1A	BOARD, RELAY OUTPUT, TCRA
DS200TCTSG1A	BOARD, ST/TRM/SIMPLEX TRIP MODULE
DS200XDSAG1A	GP SENSOR, I/O FUEL CONTROL
DS2020DACAG2	Power Module

Starfish PPS - Complete Catalog

Part Number	Description
DS215DMCBG1A	CARD, DMCBG1A AND FW
DS215DMCBG1AZZ03A	CARD, DMCBG1A AND FW
DS215KLDCG1A	CARD, KLDCG1 AND FW
DS215KLDCG1AZZ03A	CARD, KLDCG1 AND FW
DS303A2A01FX1010	CONTACTOR,DC, 50A, FOR LM6000
DS303A2A01FXA003XF	CONTACTOR, DC
DS303A2A01FXA010	CONTACTOR, DC, 50A, 600V
DS3800NDAC	Analog Output Card
DS3800NGDC	MODULE, GROUND DETECTOR, EX2000, OSCILSCOPE
DS3800NGDD	MODULE, FIELD GROUND DETECTOR, EX2000
DS3820ACSA	AC Source Selector
DS3820ACSA/RM	AC Source Selector
DSIV1-250	Kit, Door Seal Replacement
DSOV1-250	Kit, Door Seal Replacement
DTE, Light, Mobil	Hydraulic Oil
DY025-DBLBA1-2D/KF2/SCT	FLOW METER,VORTEX
DY025-DBMBA1-2D/FF1/SCT	Meter, Flow
DY025-DBMBA1-2D/KF2/SCT	DIGITAL VORTEX FLOW METER, 25MM/1"
DYC-1-4F	CABLE, YOKOGAWA
Dolly, LM2500	LM2500 Air Ride Dolly
Dolly, LM6000	Air Ride Dolly for LM600
E-800128-400	Metal Gasket Ring, E Seal
E-A-PS-USB/DB9	Cable, Adapter. Serial to USB
E-BM-AS-PS-01H	Hydraulic Starter Driver
E-C-PS-DB9/RJ45	Cable
E024-150-4DG30	BATTERY CHARGER, 24VDC, 150 AMP, 230
E604Y200	Filter, Element
EA3-B0-26-620-1DA-EB	Breaker
EBZ-241601-400	Brush, Carbon
ECD15	DRAIN, CONDUIT BREATHER
EDSC2130	SWITCH, SNAP, 3 WAY, 3/4"
EFHT8210G34	VALVE, SOLENOID, RED-HAT
EG1033AA01	AMPLIFIER, FLAME
EG1033AC01	Flame Detector
EG133AA010	AMPLIFIER, FLAME
EG9599	Brush, Carbon
EJA310-DAS4B-92NC/HAC	Pressure transmitter
EJA310A-DAS4B-92NN/FF1/HAC/D1	TRANSMITTER, INLET PRESSURE
EJX310A-JAS4G-912ND/FF1/D1	Pressure Transmitter
EKLN25	Pump, Fog
EL900-A-C-1-A	CONVERTER, MEDIA, ETHERNET COPPER TO FIBER
EMG1	GUARD, SMALL, EM SERIES
EMI15	FIXTURE, INCANDESCENT, EMI SERIES
EN0027	AT10 Auxilary Relay Alarm Board
EN13190	Stami Temperature Guage
EN5012-00	Hindlepower
ENHCPASSY	Core Processor
EQ2253DCUEX	Detector, gas transmitter
EQ3016DNNW	Controller

Starfish PPS - Complete Catalog

Part Number	Description
EQ3730DW	MODULE, EDIO
ERC384S2DA-1	Filter Element
ESG3180A03	SPARK ARRESTOR
ET-9MS-2SC	Switch, Ethernet, 8 Port
EZX2	ASSEMBLY, CEILING MOUNT, 3/4"
F1000	Fiberoptic Cleaning Wipes
F13000016Z-0263	HOSE
F13000016Z-0320	HOSE
F13000108-1230	HOSE, LUBE
F13000210-0485	HOSE
F130102E0726-180	HOSE
F1319276	Seal Kit
F16-50-BN	Element Kit, Filter
F18000104-0220	HOSE
F1JSSFS.125SS	VALVE, CHECK
F3RG-03-B1-22	VALVE, SEQUENCE, CONTROL
FA1763-1	Woodward
FA230IG	Filter, Ingersoll Rand
FB-A008X	FILLER, BREATHING ASSEMBLY
FD45-1064-12-12	COUPLING, QUICK DISCO
FE150-CS-UIR	Check valve
FF14GG50V32P	FUSE-LINK, 32A 500V
FF6672	Arrester, Flame
FKKW12V1-AHABTT-AE	Pressure Transmitter
FKPW04V1AHABY0Y	Pressure Transmitter
FLT93S	SWITCH, FLOW
FR22GG69V32P	FUSE, FAST ACTING, 22X58MM, 690V, 32A
FS-67CFR-239	REGULATOR
FS1301F-3/B2/T4/SC2	REGULATOR
FS1301F-3/B2/T4/SC2 Rebuild Kit	Rebuild Kit for Fisher 1301F Regulator
FS15B150P-001	Valve, Transfer
FS19573	FILTER, WATER SEPERATOR
FS19838	FILTER, WATER SEPERATOR
FS20B150P-002	Valve, Transfer
FS20E150T-001	Valve, Transfer
FS21770-320-99	EM Filter
FSA-127-1.1	Thermometer - panel mound, hydac
FT-060E-150P-03	Transfer Valve
FT-12NEXW-LEG-5	Flow Meter
FT-16NEXB-LEA5X	METER, FLOW
FT-16NEXWRLEG5X	METER, FLOW
FT20C3XBLEA-5005	Flow Meter - Fuel
FT24C3XWRLEG5	Flow Meter - Nox Water
FW05501D	Seal
G043.006331.010.009.010	Solenoid Valve
G24-R0001	GLOBE, LIGHT FIXTURE, 200 WATT
G251	GLOBE, GLASS
G3194-001	KIT: FILTER, SERVO, LPC-IGV
G3DHS-187	Pump
G408-0001	Slim Pak
G408-5004	SLIM PAK

Starfish PPS - Complete Catalog

Part Number	Description
G771K615A	VALVE
GCA3830K03V	ELEMENT, FILTER, COALESCER
GDC-3.15A	Fuse
GE-600-2	LUG
GE-CTF-349	Toolkit, Engine Maintenance
GEA120321SP-FF03	
GEJOTO13MM	Hose
GEJOTO16FM	Hose
GEJOTO26	Hose
GP460	Anti-Seize, Graphite Paste
GS169539	Cable, Accel
GSER501375P0027	Sensor, CASE EXPANSION TRANSDUCER - DC LVDT
GSOV-HT-Kit	Kit, Conversion
GT30-N	DETECTOR, FLAME
GTHW07077	SPARE PART FOR GTG CONTROL PANEL, IHI PACKAGE
Gasket, Enclosure	Kit, Door Seal Replacement
H1	Hose
H2	Hose
H201Ti-CE-X1-V1-VC0-H1-L1-F0	Gas Monitor
H8650SKZ	Seal Kit
H8940SKZ	Seal Kit
H9600SKZ	Seal Kit
HAND SANITIZER	
HAT-800S	Transformer, Current - VSR100 / VSR175
HC2288FAS8Z	Filter, Element, Sprint
HC2288FCS8Z	Filter, Element, Sprint
HC2288FMS8Z	Filter, Element, Sprint
HC2288FRS8Z	Filter, Element, Sprint
HC2289FAS28Z	Filter, Element
HC2289FMS28Z	Filter, Element
HC645-01-C	Filter
HC8300FCS39Z	Filter
HC8300FKS39Z	Filter
HC8300FMT30ZYGE	Filter
HC8900FAN39Z	GLO Filter
HC8900FCN39Z	GLO Filter
HC8900FKN26Z	Filter Element
HC8900FKN39Z	GLO Filter
HC8900FRN26Z	Filter Element
HC8900FRN39Z	GLO FILTER
HC8904FAN13Z	Filter
HC8904FAS13Z	Filter, Element
HC8904FCS13Z	Filter, Element
HC8904FKN13Z	Filter
HC8904FKS13Z	Filter, Element
HC8904FRN13Z	Filter Element
HC8904FRS13Z	Filter, Element
HC9020FCT4Z	FILTER, HYDRAULIC PUMP
HC9600FAN13Z	Filter, Element
HC9600FCN13Z	Filter, Element
HC9600FKD13Z	FILTER
HC9600FKN13Z	Filter, Element

Starfish PPS - Complete Catalog

Part Number	Description
HC9600FRN13Z	Filter, Element
HC9600FRN8Z	Filter Element
HC9600FTP8Z	Oil Filter
HC9600FTS8Z	Filter Element
HC9601FCP16Z	Filter
HC9604FAN13Z	FILTER
HC9604FKN13Z	FILTER
HC9604FKS13Z	FILTER
HC9604FRN13Z	FILTER
HC9604FRS13Z	Filter Element
HC9606FHS8Z	ELEMENT, FILTER
HC9801FAT8Z	FILTER, PALL
HD-2338-13	ORING
HE670RLY168C	Relay Output Module
HE693THM166	Horner Electric TC card
HF1016414	Fan Assembly
HF9-24-8-G	FILTER, AIR
HFU660UY100J	Filter Element
HG1262921	Filter, Oil Cooler
HG1262993	Starter Skid Filter Element
HG6439HSCV	Fuel Filter
HGA11J70	Aux Relay
HGA17C61	Auxiliary Relay
HMC735-1	O Ring
HMI	Innova HMI LM 6000 MARK VI
HMK25-04	Filter, Element
HOKE 316	FITTINGS
HP102L18-12MB	Mineral Oil Filter
HP89L39-6MV	GLO Filter
HPK0300B0802NX	FILTER HOUSING
HPQ210076SL14-25MV	Filter
HU02600148	FILTER
HU09157956	FILTER
HV272241001	Valve, Solenoid
HV2722411	Valve, Solenoid
HZ3142J04KNXWPTYN95	Filter Housing
HZ8640SK	Kit, Seal
HZ8670	Seal Kit
IC200ACC200	VERSAMAX, EMPTY FILLER MODULE
IC200ALG240	Analog Input
IC200ALG264	ANALOG INPUT 15 CHANNELS
IC200ALG331	Versamax
IC200ALG430	ANALOG, MIXED, 12 BIT
IC200ALG620	Analog Input
IC200CBL002A	F/W Upgrade Cable
IC200CBL110C	CABLE, FANUC
IC200CHS002	CARRIER, I/O, BOX STYLE
IC200CHS003	I/O CARRIER
IC200CHS022	Compact I/O Carrier
IC200CHS022L	CARRIER, I/O
IC200CPUE05	CPU, Versa Max

Part Number	Description
IC200GBI001	Genius Network Interface
IC200MDL650	DISCRETE INPUT MODULE, VERSAMAX 32 POINT, 24V
IC200MDL741	DISCRETE OUTPUT MODULE 16 CHANNEL 24VDC
IC200MDL741J	OUTPUT, 24V, POS LOGIC GROUPED
IC200MDL750	Versamax
IC200MDL940	VersaMax, Module
IC200PNS001	VERSAMAX PROFINET SCANNER
IC200PWB001	CARRIER, POWER SUPPLY BOOSTER
IC200PWR002	Power Supply
IC200PWR01	POWER SUPPLY, ISOLATED, 24 VDC, 11 W
IC200PWR012	POWER SUPPLY, ISOLATED, 24V, 11W
IC200TBM002	CARRIER, I/O
IC3600KVSA1E	CARD, ZERO SPEED
IC3600LINA1D1B	IC Card
IC3600LRDH1	Relay Driver Board
IC3600LRDJ1	Relay Driver Board
IC3600SFKA1B	Card, Fuel Splitter
IC3600SSLD1	Setpoint Control
IC3600SSZA1	Card, Droop
IC3600STDC1	Time Delay Card
IC3600STKH1A	Temperature Control Card
IC610CPU105C	CPU Module
IC660BBA020	GE FANUC; I/O ANALOG
IC660BBA021	GE FANUC; RTD, 6 CHANNEL
IC660BBA023	GE FANUC; THERMOCOUPLE BLOCK
IC660BBA026	GE FANUC; INPUT BLOCK, SRC
IC660BBD022	GE FANUC; 16 PT SOURCE BLOCK
IC660BBD024	GE FANUC; 32 PT SOURCE BLOCK
IC670ALG230	Analog Input, Current, 8 Channel, Grouped
IC670ALG240	Analog Input, Current, 16 Channel
IC670ALG330	Analog Output, Current, 8 Channel
IC670ALG620	RTD Module
IC670ALG621	RTD Module
IC670CHS002E	I/O Term Block, 2 Tier
IC670CHS102	I/O Term Block, 2 Tier
IC670CHS102A	I/O Term Block, 2 Tier
IC670GBI002	Interface Module Bus Field Control
IC670MDL644	Logic Fast Input, 16 Point, Grouped
IC670MDL740	Logic Output, 16 Point, Grouped
IC670TBM002C	AUX. TERMINAL
IC693ACC302	MODULE, AUXILIARY BATTERY, OUTPUT 3VDC 15AH
IC693CBL316	Communication Cable for RX3i CPE305
IC693CMM311	GE FANUC COMM CONTROL MODULE
IC693CPU374	GE Fanuc CPU
IC693DNM200	PLC Device Net Controller Card
IC693MDL241	GE FANUC INUPUT

Part Number	Description
IC693MDL645	DISCRETE INPUT MODULE TO FREQUENCY CONVERT
IC693MDL646	Input Module
IC693MDL740	Output Module
IC693PWR322	POWER SUPPLY IC 693 PWR 322 TO FREQUENCY COM
IC693PWR330	POWER SUPPLY, 120/240VAC 30W
IC694ACC310	MODULE, RX3i, BLANK SLOT FILLER, BLUE
IC694ALG223	MODULE, RX3i PACSYSTEM
IC694ALG392	MODULE, ANALOG OUTPUT
IC694MDL240	MODULE, DISCRETE INPUT
IC694MDL645	MODULE, DISCRETE INPUT
IC694MDL655	RX3i PacSystem
IC694MDL660	MODULE, DIGITAL INPUT
IC694MDL930	MODULE, RELAY OUTPUT
IC694MDL940	MODULE, RELAY
IC695ACC302	BATTERY, LITHIUM SMART
IC695ALG508	MODULE, ISOLATED RTD INPUT for RX3i PacSystem
IC695ALG600	MODULE, ANALOG INPUT, UNIVERSAL
IC695ALG708	MODULE, ANALOG OUTPUT, 8CH
IC695ALG808	MODULE, ANALOG OUT; 8 CH
IC695CHS012	PLC RACK, RX3i, 12 SLOT
IC695CHS016	BACKPLANE, UNIVERSAL, RX3i, 16-SLOT
IC695CMM002	SERIAL COMMUNICATION MODULE, RX3i, 2 PORTS
IC695CPE305	RX3i PacSystem - CPU
IC695CPE310	RX3i PacSystem
IC695CPE330	RX3i PacSystem
IC695CPU310	RX3i PacSystem
IC695CRU320	CPU, RX3i, 1000MHz CELERON-M REDUNDANCY CPU
IC695ETM001	ETHERNET MODULE, 10/100MBITS
IC695MDL664	RX3i PacSystem
IC695NIU001	GE RX3i NIU with two serial ports
IC695PNC001	PROFINET CONTROLLER
IC695PSA140	POWER SUPPLY, RX3i 40W, 120 to 240VAC/125VDC, 47
IC695PSD040	RX3i PacSystem
IC695RMX128	REDUNDANCY MEMORY XHCNAGE, 128MB, RX3i
IC697ACC701A	GE FANUC;BATTERY, Li
IC697ALG230	GE FANUC; INPUT, ANALOG, 8PT
IC697ALG320	GE FANUC; OUTPUT, ANALOG, 4 PT
IC697BEM731	GE FANUC; Genius Bus Controller
IC697CMM742	GE FANUC; Ethernet Interface Module
IC697CPX935	GE FANUC; CPU, CPX935 W/ 1 MEG MEMORY
IC697HSC700	GE FANUC; COUNTER, HIGH SPEED
IC697MDL653	MODULE, FANUC, 24VDC INPUT 32 PT
IC697PCM711	GE FANUC; PCM711 CO PROCESSOR
IC697PWR711	POWER SUPPLY, SERIES 90-70
IC697PWR724	GE FANUC; POWER SUPPLY, 24VDC
IC698CPE040	CPU W/ ETHERNET, RX7i 1.8GHz, 10/100
ICC020801001	GASKET, SPIRAL WOUND
INR-S-00320-API-GF25-V	Filter Element

Starfish PPS - Complete Catalog

Part Number	Description
INR-S-00663-API-PF-10-V	Water Injection Pump Discharge Filter
INR-S-00663-API-PF10-V	Indufil INR-S-00663-API-PF10-V filter cartridge
INR-S-00860-D-XPG-F	Filter Cartridge
INR-S-0710-XHT-GF003-V	FILTER, ELEMENT
INR-S-0860-D-UPG-F-REP	Filter Element
INR-S-620-CC10V	Filter, Element
INR-Z-00320-API-PF-10-V	Filter HP
IPC24371-1	Fuel Hose
IPD20188-1	Hose 1 1/4 Teflon Tube
IPD21306-24-2	Hose 3/8 Teflon Tube 24
IPD21306-28-2	Hose 3/8 Teflon Tube 28
IPD21306-29	Hose 3/8 Teflon Tube 29
IPD21306-39-3	Hose 3/8 Teflon Tube 39
IPD21306-41	Hose 3/8 Teflon Tube 41
IPD21306-45-2	Hose 3/8 Teflon Tube 45
IPD21306-49	Hose 3/8 Teflon Tube 49
IPD21306-50-2	Hose 3/8 Teflon Tube 50
IPD21308-12	Hose 1/2 Teflon Tube12
IPD21308-28	Hose 1/2 Teflon Tube 28
IPD21310-20	Hose 5/8 Teflon Tube 20
IPD21324-24-1	Hose 1 1/2 Teflon Tube
IPD21324-27	Hose 1 1/2 Teflon Tube
IPD21324-30	Hose 1 1/2 Teflon Tube
IPD21324-48-1	Hose 1 1/2 Teflon Tube
IPD21324-55-1	Hose 1 1/2 Teflon Tube
IPD21324-55-2	Hose 1 1/2 Teflon Tube
IPD21406-116-1	Hose 3/8 Elastomer Tube
IPD21406-47	Hose 3/8 Elastomer Tube
IPD21406-55-1	Hose 3/8 Elastomer Tube
IPD21410-26	Hose 5/8 Elastomer Tube
IPD21412-20	Hose 3/4 Elastomer Tube
IPD21412-26	Hose 3/4 Elastomer Tube
IPD21412-58-1	Hose 3/4 Elastomer Tube
IPD21416-53-1	Hose 1 Elastomer Tube 5
IPD21506-20-1	Hose 3/8 Teflon Tube 20
IPD21506-32-2	Hose 3/8 Teflon Tube 32
IPD21506-32-4	Hose 3/8 Teflon Tube 32
IPD21506-50-1	Hose 3/8 Teflon Tube 50
IPD22323-3	Hose Flex 2.0 9.50L
IPD22323-4	Hose Flex 2.0 44.00L
IPD22334-19-1	Hose 3/8 Stainless Steel
IPD22334-24-1	Hose 3/8 Stainless Steel
IPD22334-41-1	Hose 3/8 Stainless Steel
IPD22334-50-1	Hose 3/8 Stainless Steel
IPD22334-78-1	Hose 3/8 Stainless Steel
IPD22335-20-1	Hose 3/8 Stainless Steel
IPD22335-24-1	Hose 3/8 Stainless Steel
IPD22617	HOSE
IPD22872-1	Hose 2 Metal Tube
IPD23356-1	Hose 1 GGLO PMP DISCH
IPD23357-1	Hose 1 GGLO Filter OutL
IPD23361-1	Hose HYDR. Start Return

Starfish PPS - Complete Catalog

Part Number	Description
IPD23363-1	Hose HYDR. Start Drain 7
IPD23365-1	HOSE
IPD23365-2	HOSE
IPD23367-1	Hose 1 1/2 SSBuffer Air
IPD23369-2	Hose 2 SS Buffer Air 13
IPD23373	Hose, Buffer Air
IPD23379-1	Hose 2 Vent
IPD23441-26-1	Hose 3/8 Teflon 26
IPD23441-58-1	Hose 3/8 Teflon 58
IPD23498-75-1	Hose 1 Teflon 75
IPD23499-2	Hose 1,5 Elastomer GGLO S
IPD23781-1	Hose 1-1/2 Teflon
IPD23782-1	Hose 1-1/4 Teflon
IPD23783-1	Hose 1-1/2 SS WI Supply
IPD23784-1	Hose 2-1/2 GG Breather
IPD23930-1	Hose 1-1/2 SS Vent
IPD24347-1	Hose SS BUFER Air 61.0
IPD24414-1	Hose GT Lube Oil Tank V
IPE24605-1	Hose 1 1/4 Teflon Tube FL P
IRM047279061	Gen Lube Pump
IRQ110580262	Transmitter
IS200BCAAH1A	Mark VI, Board
IS200BCABH1A	Mark VI, Board
IS200DPWAG1A	BOARD, EXCITATION POWER
IS200DSPXH1D	CARD, CONTROL, DRIVE DSP, EX2100
IS200EAUDH1A	EX2100e High Speed Contactor Board
IS200EAUXH1A	BOARD
IS200EAUXH2A	Board
IS200EBACG2A	EX2100E BRDG AC FDBK, 650V
IS200EBRGH1A	BOARD, INTERFACE, EXCITER BRIDGE, EX2100e
IS200ECTBG2A	ECTB / EPCT CARD ASSY
IS200EDFFH1A	BOARD, FAB, MARK VIe
IS200EDFFH3A	EX2100e, Fanned DC Feedback Card
IS200EDSLH1A	PCB,Selector Board,EX2100e DualRegulator
IS200EMIOH1A	EX2100, MAIN I/O Card
IS200EPCTG1A	ECTB / EPCT CARD ASSY
IS200EPDMG1B	Mark VIe, EXCITER PWR DIST MODULE
IS200EPSMG2A	REGULATOR POWER SUPPLY MODULE
IS200ERAXH1A	BOARD,, AUXILIARY, REGULATOR, CONTROL, EXCITAT I/O
IS200ERDDH1A	
IS200ERGTH1A	Card, Detector, REG, GND, EX2100
IS200ERIOH1A	EXCITER MAIN I_O
IS200EROCH1A	EXCITER REGULA. OPTION CARD
IS200ERSCG1A	BOARD
IS200ERSDG1A	EX REG CONVERTER
IS200ESYSH1A	CARD, EXCITER
IS200ESYSH2A	EX2100e, System I/O Dual Card
IS200ESYSH3A	ESys Module (Simplex)
IS200EXHSG2A	EX2100, H.S. Relay Driver Card
IS200HSLAH1A	Module
IS200HSLAH2A	BOARD, INTERFACE, LINK, SERIAL

Part Number	Description
IS200HSLAH2A-OH	BOARD, INTERFACE, OVERHAULED
IS200JGNDG1A	MARK VIe, TERMINAL
IS200JPDBG1A	CARD, AC POWER DISTRIBUTION, MARK VIe
IS200JPDCG1A	CARD, POWER DISTRIBUTION
IS200JPDDG3A	MKVIe, DC Power Distrubution Module
IS200JPDFG1A	CARD, DC POWER DISTRIBUTION, MARK VIe
IS200JPDGH1A	BOARD, TERM, DC POWER DIST
IS200JPDHG1A	PACK, POWER, DIN RAIL MODULE
IS200JPDMG1A	CARD, 28V, DC POWER DISTRIBUTION, MARK VIe
IS200JPDSG1A	BOARD, TERM
IS200JPDVG1A	Board, Power, Distribution
IS200LSTBH1A	LS2100e, Terminal Board
IS200MVRCH1A	module
IS200MVRPH1A	Card, Power Supply, Core Power Distribution, Mark VI
IS200PSCDG1A	BOARD, POWER SUPPLY, PSCD
IS200SCLSH1A	CORE ANALOG TB
IS200SCSAS1A	MKVleS, I/O Expansion Terminal Board, DIN
IS200SHRAH2A	Mark* VIe, 10/2 HART ANALOG INPUT TB
IS200SPIDG1A	Mark* VIe, MKVIe Profibus-DP Master Comm Board
IS200SRLYH2A	MKVI, DO Plug Box Type TB
IS200SRTDH1A	Board, Term, RTD
IS200SRTDH2A	RTD, INPUT, PCB
IS200SSCAH2A	BOARD, TERM, COMM
IS200STAIH2A	BOARD, TERM, ANALOG I/O
IS200STAOH2A	MARK VI, ANALOG OUT
IS200STCIH2A	MARK VIe, I/O
IS200STTCH2A	BOARD, TERM, THERMOCOUPLE
IS200TBAIH1C	BOARD, TERM, ANALOG I/O
IS200TBAIH2C	MODULE, INPUT
IS200TBAIS1C	MKVIES ANALOG I/O - SIL
IS200TBAOH1C	BOARD, TERMINAL, ANALOG
IS200TBCIH2C	BOARD, TERM
IS200TBCIH3C	MARK VIe, INPUT
IS200TBCIS2C	BOARD, TERM, DISCRETE INPUT
IS200TBQDH2A	Terminal Board,MMV, AIO, Fixed, Opt
IS200TBTCH1B	MKVle, Thermocouple Input
IS200TBTCH1C	BOARD, THERMOCOUPLE TERMINALNEW
IS200TDBTH2A	BOARD, TERM, OBS, DISCRETE
IS200TEFVH1A	MARK VI BOARD
IS200TPROH1C	BOARD, TERMINAL
IS200TREA1A	MKVle, TRIP/Protection
IS200TREAS1A	CARD, TRIP RELAY, EMERGENCY
IS200TREGH1B	BOARD, TRIP TERMINAL, 125V
IS200TREGH2B	MKVle, Emergency Trip TB, 24 VDC
IS200TRESH1A	BOARD, TERMINAL, RTD
IS200TRLYH1B	BOARD, TERM
IS200TRLYH2E	BOARD, TERM
IS200TRLYH3E	MKVle, Relay Output PCB
IS200TRPAH1A	BOARD, TERM
IS200TRPGH2B	BOARD, TERMINAL, TRIP PRIMARY
IS200TRPSH1A	BOARD, TERMINAL, TRIP PRIMARY
IS200TRTDH1D	MKVle, RTD Terminal Board, Simplex

Part Number	Description
IS200TSVCH1A	BOARD, TERMINAL, SERVO, MARK VIe
IS200TSVCH2A	Mark VIe; Module, Servo
IS200TTPWH1A	BOARD, MKVI, 28V POWER DISTRIBUTION
IS200TTURH1C	BOARD, TERMINATION
IS200TTURS1C	MKVIES, TURBINE CONTROL TB, SIL
IS200TVBAH2A	CARD, MAIN, VIBRATION
IS200TVIBH2B	BOARD, TERM, VIBRATION
IS200VAICH1C	Card
IS200VAOCH1C	CARD, ANALOG, VME OUTPUT
IS200VCCCH1B	MKVI, Contact IN/ Relay OUT Card
IS200VRTDH1D	CARD, VME RTD, MARK VIe
IS200VSVOH1B	CARD, SERVO, VME
IS200VTCCH1C	Card
IS200VTURH1B	Card
IS200VVIBH1C	CARD, INPUT, VIBRATION
IS200WDIIH1A	DAUGHTER BOARD, WETTING, SDII
IS200WDIIH1A-AR	PCB, Board
IS200WNPSH1A	CARD, POWER
IS200WREAS1A	
IS200WROBH1A	Mark VI, Power card
IS2020DRLYH1A	CARD, ASSY, DRLY, PLA
IS2020RKPSG2A	POWER SUPPLY, MARK VI, 335V
IS210DTAIH1A	TERMINAL BOARD, DTAI, MARK VI
IS210DTTCH1A	TERMINAL BOARD, DTTC, MARK VI
IS210JPDHG1A	PACK, POWER, DIN RAIL MODULE
IS210MVRAH1A	Module, MVRA, Mark VI, Control
IS210MVRBH1A	Interface Board, MMV, ADIO (Opt)
IS210MVRCH1A	Module, MVRC, Mark VI, Control
IS210MVRFH1A	Module, MURF, Mark VI
IS210SAMBH1A	Terminal Board Assy, Analog Processor
IS210SCLSH1A	CORE ANALOG TB
IS210SCLTH1A	SIMPLEX TERMBD CORE ANALOG with ASSEMBLY
IS210SCSAS1A	MKVleS, I/O Expansion Terminal Board, DIN
IS210SCSAS1A-AR	MKVleS, I/O Expansion Terminal Board, DIN
IS210TREA1A	RELAY,TRIP,EMERGENCY
IS210TREAS1A	AERO TRIP TB/W DBRD, SIL
IS210WSVOH1A	MODULE, SERVO
IS210WSVOH1A-AR	MODULE, AS REMOVED
IS215ACLEH1A	EX2100, 266 MHz Processor Card
IS215ACLEH1B	Card, EX2100
IS215ACLEH1C	CARD, EX2100
IS215PMVDH1A	MODULE, DIGITAL I/O (TCDA), MARK VIe
IS215PMVPH1A	Module, Processor, Bop W/MVR Protection, Input/Output
IS215UCCAM03A	MKVle, CPCI 650MHz Controller Card
IS215UCCCM04A	MKVle, CPCI Controller Card
IS215UCCCM04A-AR	MKVle, CPCI Controller Card
IS215UCVEH2A	MKVI, VME CPU Card
IS215UCVEM01A-OH	VME CONTROLLER CARD
IS215UCVEM03A	CARD, VME CPU
IS215UCVEM04A	CARD, VME
IS215UCVGH1A	Card
IS215VCMIH1B	BOARD,PRINTED CIRCUIT, CARD, MARK VI INTERFACE

Part Number	Description
IS215VCMIH2C	COMMUNICATIONS ASM.
IS215VPROH1B	CARD, I/O-NET VME COMM
IS215VPROH2B	MKVI, VME PROTECTION MODULE (HIGH CAPACITY)
IS220PAICH1A	MODULE, PROTECTION, LOW POWER
IS220PAICH1A-AR	PACK, I/O, ANALOG, BASIC
IS220PAICH1A-OH	PACK, I/O, AS REMOVED
IS220PAICH1B	PACK, I/O, OVERHAULED
IS220PAICH2A	PACK, I/O, ANALOG, BASIC
IS220PAICH2B	PACK, I/O, ANALOG, 200mA
IS220PAOCH1A	PACK, I/O, ANALOG, 200mA
IS220PAOCH1B	PACK, I/O, ANALOG OUTPUT
IS220PCNOH1B	PACK, I/O, ANALOG OUTPUT
IS220PDIAH1A	PACK, I/O, CANOPEN GATEWAY
IS220PDIAH1A-AR	PACK, I/O, DISCRETE INPUT
IS220PDIAH1A-OH	PACK, I/O, AS REMOVED
IS220PDIAH1B	PACK, I/O, OVERHAULED
IS220PDIOH1A	PACK, I/O, DISCRETE, CONTACT IN
IS220PDIOH1B	PACK, I/O, DISCRETE
IS220PDOAH1A	PACK, I/O, DISCRETE
IS220PDOAH1A-AR	PACK, I/O, DISCRETE OUTPUT
IS220PDOAH1A-OH	PACK, I/O, AS REMOVED
IS220PDOAH1B	PACK, I/O, OVERHAULED
IS220PDOAH1B-OH	PACK, I/O, CONTACT OUT
IS220PEFVH1A	PACK, I/O, OVERHAULED
IS220PHRAH1B	PACK, I/O, ELECTRIC FUEL VALVE GATEWAY
IS220PPDAH1A	PACK, I/O, ANALOG, HART ENABLED
IS220PPDAH1A-AR	PACK, I/O, PDM DIAGNOSTICS
IS220PPDAH1A-OH	PACK, I/O, AS REMOVED
IS220PPDAH1B	PACK, I/O, OVERHAULED
IS220PPRAS1B	PACK, I/O, PDM DIAGNOSTICS
IS220PPRFH1B	PACK, I/O, EMERGENCY TURBINE PROTECTION
IS220PPROH1A	PACK, I/O, PROFIBUS MASTER GATEWAY
IS220PPROS1B	PACK, I/O, BACKUP TURBINE PROTECTION
IS220PRTDH1A	PACK, I/O, BACKUP TURBINE PROTECTION
IS220PRTDH1A-AR	PACK, RTD I/O
IS220PRTDH1B	PACK, I/O, AS REMOVED
IS220PSCAH1A	PACK, RTD I/O
IS220PSCAH1B	PACK, I/O, SERIAL COMMUNICATION
IS220PSVOH1A	PACK, I/O, SERIAL COMMUNICATION
IS220PSVOH1A-AR	PACK, I/O, SERVO CONTROL
IS220PSVOH1A-OH	PACK, I/O, AS REMOVED
IS220PSVOH1B	PACK, I/O, OVERHAULED
IS220PTCCH1A	PACK, I/O, SERVO CONTROL
IS220PTCCH1A-AR	PACK, I/O, THERMOCOUPLE INPUT
IS220PTCCH1A-OH	PACK, I/O, AS REMOVED
IS220PTCCH1B	PACK, I/O, OVERHAULED
IS220PTCCH2B	PACK, I/O, THERMOCOUPLE INPUT
IS220PTURH1A	PACK, I/O, THERMOCOUPLE INPUT
IS220PTURH1A-AR	PACK, I/O, PRIMARY TURBINE PROTECTION
IS220PTURH1A-OH	PACK, I/O, AS REMOVED
IS220PTURH1B	PACK, I/O, OVERHAULED
	PACK, I/O, PRIMARY TURBINE PROTECTION

Part Number	Description
IS220PVIBH1A	PACK, I/O, VIBRATION MONITOR
IS220TPROH1C	BOARD, TERMINAL, PROTECTION
IS220UCSAH1A	PACK, I/O, PMVE CONTROL
IS220YDIAS1A	PACK, I/O, DISCRETE INPUT
IS220YDOAS1A	PACK, I/O, DISCRETE OUTPUT
IS220YPROS1A	MKVIES, IO Pack, Protection, SIL
IS230JPDGH1B	ASSEMBLY: I/O PACK, PDM DIAGNOSTICS, MKVle
IS230JPDGH2B	ASSEMBLY: I/O PACK, PDM DIAGNOSTICS, MKVle
IS230JPDMG1B	ASSEMBLY: I/O PACK, PDM DIAGNOSTICS
IS230JPDS1AG01	ASSEMBLY: POWER DISTRIBUTION, 28VDC, MKVle
IS230JPDSG1B	ASSEMBLY: POWER DISTRIBUTION, DIN MOUNT, MKVle
IS230PCAAH1A	ASSEMBLY: CORE I/O, ANALOG
IS230SNAIH4A	ASSEMBLY: BASIC ANALOG I/O, SIMPLEX, MKVle
IS230SNAOH2A	ASSEMBLY: ANALOG OUT, BASIC, SIMPLEX,(BPPC), MKVle
IS230SNCIH2A	ASSEMBLY: INPUT, MKVle
IS230SNPRH1A	ASSEMBLY: PROTECTION, SIMPLEX,(BPPC), MKVle
IS230SNPRH2A	ASSEMBLY: PROTECTION, SIMPLEX,(BPPC), MKVle
IS230SNRLH2A	ASSEMBLY: OUTPUT, MKVle
IS230SNRTH2A	ASSEMBLY: RTD INPUT, SIMPLEX, MKVle
IS230SNSCH2A	ASSEMBLY: SERIAL COMMUNICATIONS, MKVle
IS230SNSCH2A-C	CHASSIS, MARK VIe
IS230SNTCH4A	ASSEMBLY: THERMOCOUPLE INPUT, SIMPLEX,(BPPC), MKVle
IS230SNTRH2A	TURB PRI PRO DIN RAIL MODULE W/PTURH1B
IS230SRLYH2A	ASSEMBLY: OUTPUT, MKVle
IS230SRTD2ASRTD2AG01	ASSEMBLY: I/O MODULE, S, RTD, TWIN, MKVle
IS230SRTD2ASRTD2AG11	ASSEMBLY: I/O MODULE, S-TYPE, RTD, TWIN, MKVle
IS230SRTD2ASRTD2AG21	ASSEMBLY: I/O MODULE, S-TYPE, RTD, TWIN, MKVle
IS230SRTDH2A	ASSEMBLY: RTD INPUT, SIMPLEX, MKVle
IS230SSCA2AG01	ASSEMBLY: I/O MODULE, S RTD, SINGLE, MKVle
IS230SSCA2ASSCA2AG01	ASSEMBLY: I/O MODULE, S, RTD, TWIN, MKVle
IS230STAI2ASTAI2AG01	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVle
IS230STAI2ASTAI2AG11	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVle
IS230STAI2ASTAI2AG21	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVle
IS230STAIH4A	ASSEMBLY: BASIC ANALOG I/O, SIMPLEX
IS230STAO2ASTAO2AG21	ASSEMBLY: ANALOG OUT, MKVle
IS230STCI2ASTCI2AG01	ASSEMBLY: I/O MODULE, MKVle
IS230STTC2ASTTC2AG01	ASSEMBLY: MODULE, I/O, S-TYPE, MKVle
IS230TBAI1CG01	ASSEMBLY: I/O, T-TYPE, TMR, MKVle
IS230TBAI2CG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVle
IS230TBCI2CG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVle
IS230TBCIH5C	ASSEMBLY: CONTACT INPUT, TMR,(BPPB), MKVle
IS230TEFV1AG01	ASSEMBLY: I/O, FUEL CONTROL, T-TYPE, MKVle
IS230TNAIH2C	ASSEMBLY: INPUT, MKVle
IS230TNAIH4C	ASSEMBLY: ANALOG I/O
IS230TNAOH1C	ASSEMBLY: ANALOG OUTPUT, MKVle
IS230TNAOH2C	ASSEMBLY: ANALOG OUTPUT
IS230TNCIH3C	ASSEMBLY: CONTACT INPUT DIN RAIL
IS230TNCIH4C	ASSEMBLY: CONTACT INPUT, DISCRETE, TMR,(BPPC), MKVle
IS230TNCIH5C	ASSEMBLY: INPUT, MKVle
IS230TNCIH5C-C	CHASSIS, MARK VIe
IS230TNCIH6C	ASSEMBLY: INPUT, MKVle
IS230TNCIH6C-C	Chassis and IS200TBCIH3C

Part Number	Description
IS230TNDTH2A	ASSEMBLY: DISCRETE TMR DIN RAIL, MKVle
IS230TNEAH1A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVle
IS230TNEAH2A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVle
IS230TNEAH3A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVle
IS230TNEAH4A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVle
IS230TNEAH5A	ASSEMBLY: SPEED PROTECTION, TMR,(BPPC), MKVle
IS230TNPAH1A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVle
IS230TNRLH1B	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVle
IS230TNRLH1E	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVle
IS230TNRLH1F	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVle
IS230TNRLH2E	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVle
IS230TNRLH2F	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVle
IS230TNRLH3E	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVle
IS230TNRTH3D	ASSEMBLY: RTD INPUT, DUAL,(BPPC), MKVle
IS230TNRTH4D	ASSEMBLY: RTD INPUT, DUAL,(BPPC), MKVle
IS230TNSVH3A	ASSEMBLY: SERVO CONTROL, MKVle
IS230TNSVH4A	ASSEMBLY: SERVO CONTROL, MKVle
IS230TNTCH1B	ASSEMBLY: THERMOCOUPLE INPUT, MKVle
IS230TNTCH2C	ASSEMBLY: THERMOCOUPLE INPUT, MKVle
IS230TPROH3C	ASSEMBLY: BACKUP TURBINE PROTECTION, MKVle
IS230TRLSH2B	ASSEMBLY: DISCRETE OUTPUT
IS230TRLY1BG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVle
IS230TRLY2EG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVle
IS230TRLY3EG01	ASSEMBLY: I/O, T-TYPE, TMR, MKVle
IS230TRLYH2E	ASSEMBLY: RELAY OUTPUT, TMR, MKVle
IS230TRPA1AG01	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPB), MKVle
IS230TSVC2AG01	ASSEMBLY: SERVO CONTROL, MKVle
IS230TSVC2AG01-OH	ASSEMBLY: MODULE, OVERHAULED
IS400JPDDG1A	MKVle, 125VDC/28VDC PDM, ROHS
IS400JPDGH1A	BOARD, TERM, DC POWER DIST
IS400JPDHG1A	HIGH DENSITY PWR DISTR
IS400JPDMG1A	CARD, 28V, DC POWER DISTRIBUTION, MARK Vle
IS400TDBTH2A	BOARD, TERM, OBS, DISCRETE
IS400TDBTH6A	MKVle, Discrete Terminal Board
IS400TRLYS1B	BOARD, TERM, 125V RELAY
IS400TVBAH2B	Vibration Term (MKVle Turbine Control - Operational)
IS400WNPSH1A	CARD, POWER
IS400WNPSS1A	POWER SUPPLY, +28 TO -28
IS410JPDDG4A	DC PDM DIN RAIL ASSY
IS410SCSAS1A	MKVle, YSIL I/O Expansion Card
IS420ESWAH1A	SWITCH, ETHERNET, 8 PORT, 1 FIBER
IS420ESWAH2A	Switch
IS420ESWAH3A	SWITCH ETHERNET, 8 PORT, ESWX INDUSTRIAL
IS420ESWBH1A	SWITCH, ETHERNET
IS420ESWBH2A	Switch, Ethernet, ESWB, W/Fiber
IS420ESWBH3A	SWITCH, ETHERNET
IS420PPNGH1A	MODULE, PROFINET GATEWAY
IS420PVIBH1B	PACK, I/O, VIBRATION MONITOR
IS420UCSBH1A	GE MARK Vle CONTROLLER
IS420UCSBH3A	UCSB CONTROLLER
IS420UCSBH4A	MODULE, UCSB H1A CONTROLLER
IS420UCSBS1A	UCSB Controller

Starfish PPS - Complete Catalog

Part Number	Description
IS420UCSCH1B	Mark VIe Controller 1.6GHz
IS420UCSCH2A	Controller
IS420UCSCS2A	Mark VIe, UCSC-SIL CONTROLLER,DUALCORE,1.6GHZ
IS420YAICS1B	PACK, I/O, ANALOG
IS420YDIAS1B	PACK, I/O, DISCRETE INPUT
IS420YDOAS1B	PACK, I/O, DISCRETE OUTPUT
IS430SNUAH1A	ASSEMBLY: UNIVERSAL I/O, MKVIe
ISM101332545	T3 sensor
ISM990970856	RING
J-4620	KIT, Calibration
J-4666-5	COMPOUND, SEALING, CHICO
J-4691	Compound, Sealing
J00008	VALVE, CHECK
J00021	Valve, relief
J00022	Valve, relief
J00044	VALVE, CHECK
J00068	Ametek Pressure Transmitter
J00091	Valve, Solenoid
J00092	Valve, Solenoid
J00093	VALVE, SOL
J00094	Yokogawa Flow Meter
J00095	Circle Seal Valve
J00097	Valve, Drain
J00098	Valve, Solenoid
J00100	VALVE, SOL
J00101	RTD
J00105	Valve, Check
J00106	VALVE, CHECK
J00107	VALVE, SOL
J00120	VALVE, CHECK 4 INCH
J00121	VALVE, CHECK, MANUAL, 4IN, 316SS BODY
J00125	Yokagawa flow meter 3
J00142	SWITCH, FLOW
J00146	Valve, Solenoid
J00162	RTD, Dual
J00176	Valve, Them Control
J00180	Valve, Check
J00286	BOLT, HEX
J00290	BOLT, HEX
J00300	BOLT, HEX
J00356	Screw Seal S/T, 1/4-20 C x 1 PL
J00361	Screw
J00417	Coupling
J00457	Temp Sensor Assy
J00458	Valve, check
J00463	Filter, Element
J00464	Thermo Valve
J00464KIT	Thermo Valve, OVERHAUL KIT
J00465	Valve, Drain
J00495	Coupling
J00535	Glass, Wired
J00547	NUT, HEAVY HEX

Starfish PPS - Complete Catalog

Part Number	Description
J00550	NUT, 6 PT
J00590	STUD
J00622	Flat washer
J00662	BOLT, HEX
J00744	Gasket
J00748	WASHER, FLAT, SAE
J00749	BOLT, HEX
J00755	NUT, HEX
J00792	BOLT, HEX
J00793	BOLT, HEX
J00825	Valve, Check
J00829	Heater
J00833	Coupling, Water Injection
J00838	VALVE, CHECK
J00841	Nat Gas vent valve
J00972	GAUGE, PRESSURE
J01068	Temp sensor, GLO
J01310	Sensor, temp
J01649	BOLT, HEX
J01653	BOLT, HEX
J01654	WASHER, LOCK, 3/8, HELICAL, 316SS
J01657	BOLT, HEX
J01658	WASHER, LOCK
J01659	WASHER, FLAT, NARROW, TYPE B
J01660	NUT, HEAVY HEX
J01683	BOLT, HEX
J01689	NUT, LOCK
J01718	WASHER, LOCK
J01720	WASHER, FLAT, NARROW SERIES, TYPE B
J01752	NUT, HEAVY HEX
J01796	BOLT, HEX
J01798	BOLT, HEX
J01804	BOLT, HEX
J01881	NUT, HEAVY HEX
J01912	BOLT, HEX
J02088	BOLT, HEX
J02486	FOD Sock
J02705	KIT, INSULATION BLANKET, DIFFUSER
J02979	VALVE, CHECK
J03490	Pressure transmitter
J03562	VALVE, FLOW REGULATING, 1 INCH FNPT
J03600	TBV Gasket
J03601	TBV Gasket
J03697	Reg
J03744	Meter, Flow
J04081	NUT, HEAVY HEX
J04082	WASHER, FLAT, WIDE, STANDARD
J04083	WASHER, LOCK
J04182	RTD, Dual Platinum
J04448	Joint, Expansion
J04460	GLO Pressure Transmitter
J04462	Sensor, Temp

Starfish PPS - Complete Catalog

Part Number	Description
J04467	Transmitter, pressure
J04498	
J04504	VALVE, BALL, MANUAL, 1 1/2 IN, FNPT, SS
J04545	Meter, Flow
J04683	Pump, Starter, SOV actuated
J04698	Coupling, water inj
J04699	Pump, Low Pressure
J04725	GEARBOX, ROTOJET
J04726	Pump, High Press
J04800	TRANSMITTER, PRESSURE 0-1000 PSIG
J04839	VALVE, RELIEF
J04844	Valve, Check
J04919	Switch, Level
J04920	Switch, Level
J04938	CABLE, UV FLAME DETECTOR
J04983	WASHER, FLAT, NARROW, TYPE B
J04989	Cable, TRF Accel
J05000	PUMP, START
J05000-AR	PUMP, START
J05003	VALVE, CHECK
J05015	valve, check
J05021	Drain Strainer
J05022	VALVE,CHECK
J05061	Pump, Start
J05080	Coupling, start pump
J05120	SWITCH, PRESSURE
J05122	Switch, pressure
J05124	SWITCH, TEMPERATURE, ADJUSTABLE
J05144	Switch, Pressure, Adj (Neo-Dyn)
J05146	Switch, Press., Adj., Diff.
J05147	Switch, Pressure, Adj.
J05150	SWITCH, PRESSURE
J05272	STUD
J05287	Pump, GLO / Gearbox Lube Oil
J05301	SWITCH, TEMPERATURE
J05305	VALVE, SOL
J05344	LAMP
J05525	COUPLING
J05585	Nozzle
J1092P03	Nut
J1092P04	Nut
J1092P05	Nut
J1092P06	Nut
J1128P03	Seal Ring
J1128P05	SEAL
J1128P08	Metal Gasket Ring, E Seal
J1128P10	Metal Gasket Ring, E Seal
J1128P12	Metal Gasket Ring, E Seal
J1128P13	GASKET, METAL
J1128P18	E seal
J1128P19	SEAL
J1128P24	Metal Gasket Ring, E Seal

Starfish PPS - Complete Catalog

Part Number	Description
J1128P28	Metal Gasket Ring, E Seal
J1153G08	CLAMP
J1212P06	NUT
J1215P13	Gasket, Seal
J1215P16	GASKET
J1215P17	Metal Gasket Ring, E Seal
J1215P24	Gasket, Liquid Fuel Mix Block
J1220G03	Clamp, Loop
J1220G04	Clamp, Loop
J1220G05	Clamp, Loop
J1220G06	Clamp, Loop
J1220G07	Clamp, Loop
J1220G08	Clamp, Loop
J1220G09	Clamp, Loop
J1220G10	Clamp, Loop
J1220G11	Clamp
J1220G12	Clamp, Loop
J1220G13	CLAMP
J1220G14	CLAMP
J1220G15	CLAMP
J1220G16	CLAMP
J1220G20	CLAMP
J1220G24	CLAMP
J1220G28	Clamp, Loop
J1220P09	Clamp, Loop
J1221G03	CLAMP
J1221G04	Clamp
J1221G05	Clamp
J1221G06	Clamp
J1221G07	Clamp
J1221G08	Clamp
J1221G10	Clamp
J1221G12	Clamp
J1221G14	Clamp
J1221G15	CLAMP
J1221G16	Clamp
J1221G24	Clamp
J1227P06	STRAP
J1274G0184DAB	Hose, Teflon
J1274G0211DAB	HOSE
J1274H0260DAB	HOSE ASSEMBLY
J1276F0185DAB	HOSE
J1276F0750DAB	HOSE
J1276G0250DAB	Hose, Oil
J1276G0990CAB	HOSE
J1276G0990DAB	HOSE, TEFLON
J1276G1250DAB	HOSE, TEFLON
J1276H0110DAB	Tube
J1276H0256DAB	HOSE
J1280E1245DA064	HOSE
J1311P03	E seal
J1311P05	E seal

Starfish PPS - Complete Catalog

Part Number	Description
J1311P05A	SEAL, RING, METAL
J1311P06	E seal
J1311P11	E seal
J1311P13	Metal Gasket Ring, E Seal
J1317P10B	Nut, Swivel
J1411P04	NUT
J1431P04	Clamp
J1431P05	Clamp
J1431P06	Clamp
J1431P07	Clamp
J1431P08	Clamp
J1431P10	CLAMP
J1431P12	Clamp
J1431P15	Clamp
J1435P79	SPACER
J158P013A	Stud
J180F0480G090	TUBE, OIL - VSV
J180G0440G090	TUBE, OIL - VSV
J180H0420G090	HOSE
J193H0360A090	TUBE, OIL - VBV
J193H0360C090	HOSE
J198P01	Nut
J198P02	Nut
J198P02A	Nut
J198P02B	Nut
J198P02C	Nut
J198P02D	Nut
J198P04	Nut
J200P02	Nut
J200P03	Nut
J201P01	NUT
J201P03	NUT, 12 PT
J201P04	NUT
J201P04A	NUT
J219P02	Gasket, Seal-Flange
J219P03	Gasket
J219P04	Gasket
J219P05	Gasket, Seal-Flange
J219P05A	GASKET
J219P06	Gasket
J219P07	Gasket
J219P08	Gasket
J219P09	Gasket, Seal-Flange
J221P006	O Ring
J221P008	O Ring
J221P009	O Ring
J221P010	O-Ring
J221P012	O Ring
J221P013	O-RING
J221P014	O-RING
J221P015	O Ring
J221P016	O Ring

Starfish PPS - Complete Catalog

Part Number	Description
J221P017	O-RING
J221P018	O RING
J221P019	O Ring
J221P020	O Ring
J221P021	O Ring
J221P022	O Ring
J221P023	O Ring
J221P026	O Ring
J221P028	O Ring
J221P035	O Ring
J221P036	O Ring
J221P037	O Ring
J221P042	O Ring
J221P044	O-Ring
J221P110	PACKING
J221P112	PACKING
J221P113	O-RING
J221P114	O-RING
J221P115	O Ring
J221P117	O Ring
J221P121	O Ring
J221P122	O Ring
J221P123	O-Ring
J221P124	O-RING
J221P125	O Ring
J221P126	O Ring
J221P129	O Ring
J221P130	O Ring
J221P131	O-RING
J221P132	O-RING
J221P134	O Ring
J221P135	O-RING
J221P138	O Ring
J221P139	O Ring
J221P140	O Ring
J221P145	O Ring
J221P148	O Ring
J221P150	PACKING
J221P1501	PACKING
J221P152	O-RING
J221P153	O-RING
J221P160	O Ring
J221P161	O Ring
J221P163	O Ring
J221P166	O Ring
J221P175	O Ring
J221P210	O Ring
J221P213	O Ring
J221P214	O Ring
J221P216	O Ring
J221P218	O Ring
J221P219	O Ring

Starfish PPS - Complete Catalog

Part Number	Description
J221P220	O Ring
J221P222	O Ring
J221P224	O Ring
J221P225	O Ring
J221P226	O Ring
J221P228	O Ring
J221P229	O Ring
J221P230	O Ring
J221P231	O-RING
J221P234	O Ring
J221P236	O-RING
J221P238	O Ring
J221P240	O Ring
J221P240HT	O-RING
J221P241	O Ring
J221P242	O-RING
J221P243	O-RING
J221P244	O RING
J221P245	O Ring
J221P247	O Ring
J221P252	O Ring
J221P255	O Ring
J221P260	O Ring
J221P262	O Ring
J221P263	O Ring
J221P264	O Ring
J221P265	O Ring
J221P266	O Ring
J221P270	O Ring, V1000-270
J221P278	O-RING
J221P324	O Ring
J221P341	O Ring
J221P344	O-RING
J221P390	O Ring
J221P429	O Ring
J221P433	O Ring
J221P437	O Ring
J221P444	O-RING
J221P460	O-RING
J221P902	O-RING
J221P903	O Ring
J221P904	O-RING
J221P905	O-RING
J221P906	O Ring
J221P908	O-RING
J221P910	O Ring
J221P912	O Ring
J221P914	O Ring
J221P916	O Ring
J221P920	O Ring
J221P975	O Ring
J224P042	O Ring

Starfish PPS - Complete Catalog

Part Number	Description
J224P044	O-Ring
J224P123	O-Ring
J224P139	O Ring
J224P150	PACKING
J334P16B	Bolt
J334P21A	BOLT
J335P10A	BOLT
J336P28B	BOLT
J414P034A	Bolt
J414P052A	Bolt
J415P123A	Bolt
J423P045A	Bolt, Shear
J424P008A	Bolt, Shear
J431P124A	Bolt
J4620	KIT, Calibration
J490P05	NUT
J511P106	Nipple
J511P108	Fitting
J511P110	FITTING
J515P04	CONNECTOR, ELBOW
J534P04	NIPPLE
J534P06	FITTING
J534P08	INSERT
J534P10	INSERT
J534P12	Fitting
J574P02	Nut
J626P04	NUT
J626P09	NUT
J627P05	NUT
J643P04B	Bolt
J643P05D	BOLT
J643P06B	BOLT, MACHINE
J643P07A	BOLT
J643P08B	BOLT
J643P09A	BOLT, MACHINE
J643P12A	BOLT
J644P04F	Bolt
J644P05D	Bolt
J644P06A	BOLT
J644P06B	Bolt
J644P06D	Bolt
J644P07D	Bolt
J644P08A	BOLT
J644P08D	Bolt
J644P09A	Bolt
J644P09D	Bolt
J644P09F	Bolt
J644P10A	Bolt
J644P10D	Bolt
J644P11A	Bolt
J644P12A	BOLT
J644P12B	BOLT

Starfish PPS - Complete Catalog

Part Number	Description
J644P13A	Bolt
J644P13B	Bolt
J644P14B	BOLT
J644P14BQQ	BOLT
J644P14E	POINT
J644P15A	BOLT
J644P16A	BOLT
J644P16F	Bolt
J644P17A	bolt
J644P18A	BOLT, MACHINE, DBL HEX HD, 0.250-28 BY 1.312
J644P19F	Bolt
J644P21A	Bolt
J644P23A	BOLT
J644P25B	Bolt
J644P26A	Bolt
J644P26C	Bolt
J645P10A	BOLT
J645P10D	BOLT
J645P11A	Bolt
J645P12A	BOLT
J645P12F	BOLT
J645P13D	Bolt
J645P14A	Bolt
J645P15A	BOLT
J645P17A	Bolt
J645P17D	BOLT
J645P18A	Bolt
J645P19D	BOLT
J645P20A	Bolt
J645P21A	BOLT
J645P23D	Bolt
J645P25A	BOLT
J645P26A	BOLT
J645P27D	Bolt
J645P30A	Bolt
J645P33	Bolt, Machine DBL Hex
J645P33A	Bolt
J646P06F	BOLT
J646P12B	Bolt
J646P14A	BOLT
J646P17D	Bolt
J646P18A	BOLT
J646P19A	Bolt
J646P19D	Bolt
J646P20A	Bolt
J646P21E	Bolt
J646P22A	Bolt
J646P23A	BOLT, MACHINE
J646P24A	BOLT, DBL HEX HEAD
J6G3R	Rectifier
J714P051A	Bolt
J813P010A	BOLT

Starfish PPS - Complete Catalog

Part Number	Description
J815P029A	BOLT
J815P040A	BOLT, SHEAR-HEX
J815P052A	Bolt
J816P052A	Bolt
J816P072C	Bolt
J904P07A	BOLT
J94129	O-RING
J951P07A	SCREW, MACHINE, FLATHEAD
J952P07C	SCREW
J952P20A	BOLT
JPMG-336-CE-R	FILTER, ELEMENT
K/13220-1406	KIT, REPAIR, CIRCLE SEAL VALVE
K/32840-1650	Kit, Overhaul, Valve
K30B18	Bergen Cables
K30B24	Bergen Cable; 24"
K333P20	Blade HPC S3
K415P12	Blade, HPC STG 4
KAL26200	Breaker
KCX006703320	Gasket
KCX013609020	Gasket
KD485	CONVERTER
KDE2412PMS1-6A	FAN
KEYSWITCH	SWITCH, HORN
KFZ213400604	Gasket
KFZ335060704	Gasket
KHA047203501	O-Ring
KHS-17D11-24	RELAY
KLM10	FUSE, 10 AMP
KLM15	FUSE, 15 AMP
KLM2	FUSE, 2A
KLM20	FUSE, 20A
KLM30	FUSE, 30A
KPB150LMTZ2	HOUSING, BALLAST, MERCMASTER 3
KPWB75	HOOD, WALL MOUNTING, 3/4" NPT, MERCMASTER 3
KR9P35RH1	Pushbutton
KSC328324V-1	Bearing, Torque Arm, Rear
KSF-ST-T-1.00-V-S-P	Sight Flow Indicator, Vilton Seals
L14517P01	GASKET
L14520P01	Spacer
L14542P01	Nut
L150	Spider
L15500P01	SPRING
L16562G03	PROBE
L21060G01	BRACKET
L21103P01	RTD, Detector, Resistance Immersion
L21131P02	Sensor, Speed
L21225P02	Sensor
L21273G01	PLATE
L21325	Strap, sub bracket
L21325G05	Strap
L21348G02	Strap
L21384G01	Tube

Starfish PPS - Complete Catalog

Part Number	Description
L21393G05	Adapter Assy, Starter
L21432P01	SHIM, RADIAL
L21454P04	Exciter, Ignition
L21454P05	Exciter, Ignition
L21524G03	Bracket
L21564G01-AR	TUBE, MANIFOLD, OIL
L21617P01	GASKET
L21618P06	Gasket
L21618P07	RETAINER
L21656P04	TRANSDUCER MOTIONAL PICKUP
L21658P01	65924 Cable & Conduit Assy
L21674P12	VALVE
L21674P13	Valve, Check
L21674P14	Valve, Check
L21693P02	Cable, VSV feedback
L21696P09	Solenoid Valve
L21742P01	66090 Cable & Conduit Assy
L21785P06	Valve, Check
L21803P02	GASKET
L21849P24	PLATE
L21860P01	Bracket
L22046P07	BEARING
L22047P02	FWD Mount Bearing
L22047P03	Bearing
L22069G02	FOD SOCK
L22077P02	SPACER
L22128P02	SEAL, INLET
L22159P06	Transducer, Pressure
L22161P21	Transducer, Pressure
L22161P22	Transducer, Pressure
L22276G01	TUBE
L22425P01	ARRESTOR
L22441P01	BRACKET
L22444G01	STRAP
L24065P02	Spacer
L24337P01	RTD, Detector, Resistance Immersion
L24407P02	PUMP, LUBE AND SCAVENGE
L24434P02	Support
L24435P01	BOLT
L24922P03	Pump, VG
L24922P03-OH	PUMP, VG
L24932P02	Ignition Lead
L24983G05	BEARING
L24983G06	BEARING
L25105P08	Starter
L25806P02	Ignition Exciter
L25806P04	Ignition Exciter
L25892P02	Starter
L28004P01	GASKET SEAL
L28023P02	Cable, XN2 SP
L28066P01	THERMOCOUPLE
L28124P01	GASKET, RING

Starfish PPS - Complete Catalog

Part Number	Description
L28124P02	GASKET, RING
L28124P03	GASKET, RING
L28266P02	Pump, hyd
L28266P03	Pump
L28339P01	T3 sensor
L28343P01	Thermocouple
L28361P10	RING, COVER, IGNITER PLUG
L28361P14	RING
L28490P01	FLAME SENSOR, UV
L28490P05	Flame Sensor UV
L28497P01	Hose, fuel
L28497P02	Hose, fuel
L31177P02	Retainer
L31266P10AR	SPACER, METERING, AS REMOVED
L31289P01	Igniter Cover
L31302G01	ROD
L31302G02	Rod End Bearing
L31303G01	Link
L31413P01	Cooling Air Tube
L31476P57-AR	NOZZLE, DUAL FUEL
L31476P59	NOZZLE, DUAL FUEL
L31476P61	NOZZLE, DUAL FUEL
L31476P61-AR	NOZZLE, DUAL FUEL, AS REMOVED
L31476P61-OH	NOZZLE, DUAL FUEL, OVERHAULED
L31476P62	NOZZLE, DUAL FUEL
L31476P62-OH	NOZZLE, DUAL FUEL, OVERHAULED
L31476P65	Fuel Nozzle
L31476P65-OH	Fuel Nozzle, Overhauled
L31476P67	Fuel Nozzle
L31476P67-OH	Fuel Nozzle - Overhauled
L31707G01	BOLT
L31711P01	RETAINER
L31805G09	NOZZLE, GAS / STEAM
L31805G09-AR	Fuel Nozzle, GAS / STEAM
L31809P02	NOZZLE, FUEL
L31809P08	Nozzle, fuel
L31809P11	NOZZLE, FUEL
L31809P11-AR	Nozzle, Fuel
L31809P11-OH	NOZZLE, FUEL
L31809P12	Fuel Nozzle
L31809P12-AR	FUEL NOZZLE, DUAL FUEL, LM2500
L31809P12OH	Nozzle, Dual Fuel, LM2500
L31809P13	NOZZLE, FUEL
L31809P13-OH	NOZZLE, FUEL, Overhauled
L31918P04	Conditioner, Signal
L31918P05	Detector, Flame
L31947P04	SENSOR T2/P2
L31967P18	CRF Accelerometer
L31967P21	TRF Accelerometer
L31967P22	Accelerometer
L31967P25	Accelerometer
L31967P27	CRF Accelerometer

Starfish PPS - Complete Catalog

Part Number	Description
L31967P29	TRF Accelerometer
L34036G01	BRACKET
L34128P01	Bracket
L34134P01	BRACKET
L34143G01	Probe
L34151P02	Accelerometer
L34152P04	Accelerometer
L34214P05	Amplifier
L34235G01	Bracket, Accelerometer
L34246P04	Accelerometer, LM2500
L34283P01	FILTER ASSEMBLY
L34283P01-AR	FILTER ASSEMBLY - AS REMOVED
L34283P01-BOWL	Filter Bowl
L34283P03	Filter Bowl
L34283P03-Bowl	Filter Bowl
L34319P01	SENSOR
L34356P01	VALVE, SERVO
L34358P06	Actuator
L34379P03	CONTROLLER, VSV
L34379P04	Control
L34379P04-OH	CONTROLLER, VSV, OVERHAULED
L34447G01	BRACKET
L34448G01	Hinged Bracket
L34448G02	BRACKET
L34492P001A	Bracket
L34518P01	Orifice, Plate
L34518P02	Orifice, Plate
L34518P03	Orifice, Plate
L34518P04	Orifice, Plate
L34518P05	Orifice, Plate
L34518P06	Orifice, Plate
L34518P07	Orifice, Plate
L34518P08	Orifice, Plate
L34518P09	Orifice, Plate
L34518P10	Orifice, Plate
L34518P11	Orifice, Plate
L34518P12	Orifice, Plate
L34518P13	Orifice, Plate
L34518P14	Orifice, Plate
L34518P15	Orifice, Plate
L34518P16	Orifice, Plate
L34518P17	Orifice, Plate
L34518P18	Orifice, Plate
L34582P001A	BRACKET
L34596G01	BRACKET
L34597G01	BRACKET
L34648P06	SEAL, FITTING
L34847P01	RTD, Detector, Resistance Immersion
L34848G01	BRACKET
L34975P005	BOLT, FINISHED
L34975P007	BOLT, FINISHED
L34976P069	Bolt

Starfish PPS - Complete Catalog

Part Number	Description
L35054P01	600266 Cable and conduit
L35055P01	600267 Cable and conduit
L35056P03	Accelerometer
L35056P04	ACCELEROMETER
L35166P01	RTD, Detector, Resistance Immersion
L35166P02	RTD, Detector, Resistance Immersion
L35167P01	Thermocouple Harness Top Right
L35169P01	TC harness, Btm right LM5000
L35171P01	TC harness, Top Left LM5000
L35173P01	TC harness, Btm Left LM5000
L35228P18	Gasket
L35228P19	Gasket
L35246P01	GASKET
L35246P02	Gasket, Seal
L35248P01	Gasket, Seal
L35248P10	Gasket, Seal
L35350P04	GASKET
L35579P01	Gasket
L35579P02	Gasket
L35579P04	Gasket
L36000G02	Sight, Flame
L37239G02	VBV Door
L37239G02-AR	VBV DOOR
L37239G02-OH	VBV DOOR
L37241G01	Hinge
L38030G02	BAFFLE, ACOUSTIC, COMBUSTOR
L38060P02	HP Sprint Nozzle
L38060P04	HP Sprint Nozzle
L38060P13	HP Sprint Nozzle
L38060P15	LP Inlet Sprint Nozzle
L38060P16	HP Sprint Nozzle
L38060P18	LP Inlet Sprint Nozzle
L38166P04	NOZZLE, FUEL, DLE, PREMIXER, 3-CUP
L38238P01	Gasket, Fuel nozzle
L38238P01SR	Gasket, Fuel Nozzle, SEAL RING
L38631P01	Nozzle, Fuel
L38631P01-AR	AS REMOVED, Nozzle, Fuel
L38631P01-OH	Overhauled Fuel Nozzle
L38756P03	FUEL NOZZLE
L38756P03-OH	FUEL NOZZLE, OVERHAULED
L3MF 100/200-AC	ASSEMBLY: PUMP & AC MOTOR
L3MF 80/132DC	ASSEMBLY: PUMP & DC MOTOR
L41143P02	Chip Detector
L42062P01	Bracket
L42070G01	Exhaust Wedge
L42092P04	TUBE
L42602P01	Seal
L42603P01	SEAL
L42604P01	Seal
L42635G01	Bracket
L42757P001A	BRACKET
L428120P02	CABLE

Starfish PPS - Complete Catalog

Part Number	Description
L42816G01	Bracket
L42818G01	Bracket
L42819G01	Bracket
L42821P01	Seal
L42835G01	ACOUSTIC BAFFLE
L42837P01	Seal
L42990P01	HOSE
L43014P03	Cable, T25
L43014P04	CABLE, T2/T25 RTD
L43014P05	CABLE, T2/T25 RTD
L43014P09	Cable, T25
L43014P10	CABLE, T2/T25 RTD
L43014P11	CABLE, T2/T25 RTD
L43019P03	Cable, T3
L43020P02	CABLE, T44
L43020P08	Thermocouple Harness
L43031P01	Sensor, T21
L43064P07	NOZZLE, FUEL, LIQUID / WATER;
L43064P08	NOZZLE, FUEL, LIQUID / WATER;
L43064P09	NOZZLE, FUEL, LIQUID / WATER;
L43064P10	NOZZLE, FUEL, LIQUID / WATER;
L43073P01	Gasket, Flame Detector
L43324G03	Bell Crank
L43326G02	Bell crank
L43339P01	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
L43339P02	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
L43340P01	Cable, Electrical, IGV, LVDT, XM
L43341P02	Cable
L43342P01	CABLE, TEMP, LIQUID MANIFOLD
L43342P02	CABLE, TEMP, LIQUID MANIFOLD
L43342P03	CABLE, TEMP, LIQUID MANIFOLD
L43342P04	CABLE, TEMP, LIQUID MANIFOLD
L43345P01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
L43345P02	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
L43346P01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
L43346P02	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
L43347P01	CABLE, SPEED, GAS GENERATOR
L43347P02	CABLE, SPEED, GAS GENERATOR
L43347P03	CABLE, SPEED, GAS GENERATOR
L43347P04	CABLE, SPEED, GAS GENERATOR
L43348P02	CABLE, ELECTRICAL
L43352P01	CABLE, ELECTRICAL, VBV/VSV/LVDT
L43352P02	CABLE, ELECTRICAL, VBV/VSV/LVDT
L43356P04	CABLE, IGV/LVDT, RIGHT
L43356P05	CABLE, IGV/LVDT, RIGHT
L43356P10	CABLE, IGV/LVDT, RIGHT
L43356P11	CABLE, IGV/LVDT, RIGHT
L43357P04	CABLE, IGV/LVDT/XN2, LEFT
L43357P05	CABLE, IGV/LVDT/XN2, RIGHT
L43357P10	CABLE, IGV/LVDT/XN2, LEFT
L43357P11	CABLE, IGV/LVDT/XN2, RIGHT

Part Number	Description
L43358P03	CABLE, VBV/VSU/IGV
L43358P04	CABLE, VBV/VSU/IGV
L43358P09	CABLE, VBV/VSU/IGV
L43358P10	CABLE, VBV/VSU/IGV
L43359P04	CABLE, MANIFOLD TEMPERATURE
L43359P05	CABLE, MANIFOLD TEMPERATURE
L43359P10	CABLE, MANIFOLD TEMPERATURE
L43359P11	CABLE, MANIFOLD TEMPERATURE
L43360P04	CABLE, CHIP DETECTOR, A/B
L43360P05	CABLE, CHIP DETECTOR, A/B
L43360P10	CABLE, CHIP DETECTOR, A/B
L43360P11	CABLE, CHIP DETECTOR, A/B
L43361P03	CABLE, CHIP DETECTOR, C/D/E
L43361P04	CABLE, CHIP DETECTOR, C/D/E
L43361P09	CABLE, CHIP DETECTOR, C/D/E
L43361P10	CABLE, CHIP DETECTOR, C/D/E
L43362P02	CABLE, TEMP LUBE & SCAVENGE
L43362P03	CABLE, TEMP LUBE & SCAVENGE
L43362P04	CABLE, TEMP LUBE & SCAVENGE
L43362P05	CABLE, TEMP LUBE & SCAVENGE
L43362P08	CABLE, TEMP LUBE & SCAVENGE
L43362P09	CABLE, TEMP LUBE & SCAVENGE
L43362P10	CABLE, TEMP LUBE & SCAVENGE
L43362P11	CABLE, TEMP LUBE & SCAVENGE
L43363P03	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P04	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P05	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P09	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P10	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P11	CABLE, TEMP LUBE RTD, D&E SUMPS
L43364P04	CABLE, XN25 SPEED
L43364P05	CABLE, XN25 SPEED
L43364P10	CABLE, XN25 SPEED
L43364P11	CABLE, XN25 SPEED
L43365P03	CABLE, XNSD SPEED
L43365P04	CABLE, XNSD SPEED
L43365P05	CABLE, XNSD SPEED
L43365P09	CABLE, XNSD SPEED
L43365P10	CABLE, XNSD SPEED
L43365P11	CABLE, XNSD SPEED
L43367P03	CABLE, OFF-ENGINE, T/C, T48
L43367P04	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
L43367P05	CABLE, OFF-ENGINE, T/C, T48
L43367P09	CABLE, OFF-ENGINE, T/C, T48
L43367P10	CABLE, OFF-ENGINE, T/C, T48 (1 P04 & 4 P11'S)
L43367P11	CABLE, OFF-ENGINE, T/C, T48
L43368P03	CABLE, EGT THERMOCOUPLE, LOWER
L43368P04	CABLE, EGT THERMOCOUPLE, LOWER
L43368P05	CABLE, EGT THERMOCOUPLE, LOWER
L43368P09	CABLE, EGT THERMOCOUPLE, LOWER
L43368P10	CABLE, EGT THERMOCOUPLE, LOWER
L43368P11	CABLE, EGT THERMOCOUPLE, LOWER

Part Number	Description
L43369P04	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43369P05	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43369P10	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43369P11	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43370P04	CABLE, VBV/VSV/LVDT
L43370P05	CABLE, VBV/VSV/LVDT
L43370P10	CABLE, VBV/VSV/LVDT
L43370P11	CABLE, VBV/VSV/LVDT
L43371P04	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P05	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P06	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P10	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P11	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P12	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43379P04	BEARING
L43395P02	Clevis
L43416P02	T3 Sensor
L43418P02	ACTUATOR, VSV
L43418P02-OH	VSV Actuator
L43418P03	Actuator
L43418P03-OH	ACTUATOR, OVERHAULED
L43418P06	Actuator
L43418P07	Actuator
L43419P04	Actuator
L43419P07	Actuator
L43420P04	Actuator
L43420P07	Actuator
L43434P06	TRUNION
L43450P01	Igniter Plug
L43563P01	Mag Chip Detector
L43616P01	BOLT
L43778P01	Accumulator
L43885P01	ACCUMULATOR, HYDRAULIC
L44500P09	PUMP, LUBE AND SCAVENGE
L44500P13	L&S Pump
L44500P15	PUMP
L44500P17	PUMP, LUBE AND SCAVENGE
L44538P01	VALVE, STAGING
L44538P01-AR	VALVE, AS REMOVED
L44538P01-OH	VALVE, STAGING, OVERHAULED
L44543P03	Cable ASSY; T5:4
L44544P03	Cable ASSY; T5:4
L44550P01	Sensor, Dynamic
L44569P11	ASSEMBLY: PUMP, VSV
L44569P13	PUMP
L44569P13-AR	PUMP; AS REMOVED
L44569P16	VALVE, SERVO
L44569P18	VALVE, SERVO
L44569P22	VALVE, SERVO
L44569P24	VALVE, SERVO
L44569P25	PUMP
L44569P25-AR	PUMP, AS REMOVED

Part Number	Description
L44569P31	ASSEMBLY: SERVO VALVE & PUMP
L44569P32	PUMP, VSV
L44569P32-OH	PUMP, OVERHAULED
L44569P35	ASSEMBLY: SERVO VALVE & PUMP
L44569P36	ASSEMBLY: SERVO VALVE & PUMP
L44569P38	ASSEMBLY: SERVO VALVE & PUMP
L44571P01	HYDRAULIC CONTROL UNIT
L44571P01-AR	HYDRAULIC CONTROL UNIT
L44571P01-OH	HYDRAULIC CONTROL UNIT
L44571P02	HYDRAULIC CONTROL UNIT
L44579P05	CABLE, ELECTRICAL, VSV LVDT RIGHT/LEFT
L44579P07	Cable, VSV/LVDT Electrical
L44630P01	SENSOR, DUAL PT, SPEED
L44655P01	O-RING
L44680P01	Valve
L44684P01	SENSOR, SPEED
L44705P04	CABLE, STAGING VALVES, LEFT
L44705P06	CABLE, STAGING VALVES, LEFT
L44705P10	CABLE, STAGING VALVES, LEFT
L44705P12	CABLE, STAGING VALVES, LEFT
L44706P04	CABLE, STAGING VALVES, RIGHT
L44706P06	CABLE, STAGING VALVES, RIGHT
L44706P10	CABLE, STAGING VALVES, RIGHT
L44706P12	CABLE, STAGING VALVES, RIGHT
L44707P01	Harness
L44707P03	Harness
L44709P01	Harness
L44709P03	Harness
L44715P02	Cable, Electrical IGV Left Side
L44716P02	Cable, Electrical IGV RT Side
L44721P01	Cable, T5:4
L44722P01	Cable, T5:4
L44722P02	T4.4 CABLE
L44723P01	SENSOR, ACOUSTIC
L44723P03	SENSOR, ACOUSTIC
L44723P04	SENSOR, ACOUSTIC
L44735P01	CABLE, LPT, SPEED
L44735P02	CABLE, LPT, SPEED
L44735P03	CABLE, LPT, SPEED
L44735P04	CABLE, LPT, SPEED
L44735P05	CABLE, LPT, SPEED
L44735P06	CABLE, LPT, SPEED
L44736P05	Cable, T48 Upper Thermocouple Harness
L44737P04	Cable, T48 Lower Thermocouple Harness
L44741P16	Bearing, Torque Arm, Rear
L44745P01	SENSOR
L44745P02	Sensor, T25
L44745P04	Sensor, T25
L44747P01	CABLE, FLAME SENSOR
L44755P01	ACTUATOR, VARIABLE
L44756P01	Speed Sensor
L44777G01	link

Starfish PPS - Complete Catalog

Part Number	Description
L44777G02	Connecting Link
L44777G03	VSV Link
L44777G04	Connecting Link
L44777G05	VSV Link
L44777G06	VSV Link
L44777G07	VSV Link
L44777G08	VSV Link
L44780P01	Sensor, speed
L44785P01	SENSOR
L44793P01	Mag Chip Detector
L44819P01	Flame Sensor
L44820P17	CABLE, UV FLAME DETECTOR
L44821P01	CAN, COOLING
L44830P01	T5.4/T4.4 T/C PROBE
L44830P02	Thermocouple T5:4
L44830P03	Thermocouple T5:4
L44860P01	HOUSING
L44860P02	HOUSING
L44861P01	HPC Bushing Stg 3/4
L44861P07	HPC Bushing Stg 5
L44862P02	HPC Bushing Stg 3/4
L44862P03	HPC Bushing Stg 5
L44867P01	HOUSING
L44867P02	HOUSING
L44867P03	HOUSING
L44867P04	HOUSING
L44920P01	Speed Sensor, Transducer
L44921P01	speed sensor, dual
L44921P02	SPEED SENSOR, DUAL
L44951P01	BOOT SEAL
L44979P02	Bolt, CLV-TRQ Tube
L44982P01	EHSV, VSV ACTUATOR
L44983P01	Wiring Harness
L44984P01	P23/T23 SEN B - ES204 Harness
L44988P01	Harness, XNSD Speed
L44991P01	ACCUMULATOR, HYDRAULIC
L44991P01-AR	Accumulator, Hydraulic
L44991P01-OH	Accumulator, Hydraulic
L45045P01	BOLT
L45063P13	Ring
L45066P01	RING
L45130G01	Bearing
L45135P04	Bushing
L45137P01	Washer
L45525G01	TUBE, ASSY
L45529G01	Tube, Air
L45554G01	TUBE
L45555G01	TUBE
L45556G01	TUBE
L45633G01	MANIFOLD
L45730G02	Manifold, Fuel - Primary, Left Side
L45731G02	Manifold, Fuel - Primary, Right Side

Starfish PPS - Complete Catalog

Part Number	Description
L45732G02	MANIFOLD, FUEL, SECONDARY, LEFT SIDE, FOR NOX INJECTION (REPAIRED)
L45733G02	MANIFOLD, FUEL, SECONDARY, RIGHT SIDE, FOR NOX INJECTION (REPAIRED)
L45816P01	Hose
L45816P04	Hose
L45817P04	HOSE, STEAM
L45841G02	MANIFOLD, OIL - LUBE AND SCAVENGE
L45842G03	MANIFOLD, OIL
L45843P01	MANIFOLD, OIL
L45859G01	Bracket
L45881P01	Fuel Primary Hose
L45881P04	Fuel Primary Hose
L45882P04	Fuel Secondary Hose
L45921P01	GASKET, GAS MANIFOLD
L45921P10	GASKET, GAS MANIFOLD
L45924G01	Tube, Air
L45944G02	Bracket
L45946P001A	Bracket
L45970G01	Fuel Tube
L45972G01	Fuel Tube
L45972G01-AM	Fuel Tube, Aftermarket
L45983P03	HOSE
L46017G03	Bracket
L46032P01	GASKET
L46055G05	BRACKET, ELECTRICAL
L46101G02	TUBE, OIL - VSV
L46109G02	MANIFOLD, OIL
L46110G01	MANIFOLD, OIL, SUPPLY
L46114P01	COVER, FLANGE
L46116P01	Cover
L46131G02	TUBE, OIL - VSV
L46133G02	TUBE, OIL - VBV
L46152G01	TUBE
L46192P001A	BRACKET, ULTRA VIOLET SENSOR
L46198G01	BRACKET
L46201G01	BRACKET
L46202G01	Bracket
L46203G01	Bracket
L46205G01	Bracket
L46219P01	PLATE
L46226G01	Bracket
L46408P03	HOSE
L46459G01	Manifold, Steam/Fuel
L46459G02	Manifold, Steam/Fuel
L46466G01	TUBE
L47022P02	BRACKET
L47045P16	CABLE, CRF ACCELEROMETER
L47045P19	CABLE, ACCELEROMETER
L47045P22	CABLE, CRF ACCELEROMETER
L47045P25	CABLE, ACCELEROMETER
L47045P26	CABLE, CRF ACCELEROMETER
L47046P04	CABLE, TRF ACCELEROMETER

Starfish PPS - Complete Catalog

Part Number	Description
L47046P10	CABLE, TRF ACCELEROMETER
L47046P16	CABLE, TRF ACCELEROMETER
L47046P22	CABLE, TRF ACCELEROMETER
L47046P25	CABLE
L47046P26	CABLE, TRF ACCELEROMETER
L47072P01	CABLE, CHIP DETECTOR, A/B/COM
L47072P02	CABLE, CHIP DETECTOR, A/B/COM
L47073P01	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
L47073P02	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
L47074P01	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT
L47074P02	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT
L471-02	SWITCH, FLOAT, LINC
L471-03	SWITCH, FLOAT, LINC
L47138P01	PIN
L47314P03	SENSOR, T3
L47314P04	SENSOR, T3
L47319P04	CABLE, TBV
L47319P05	CABLE, TBV
L47319P10	CABLE, TBV
L47319P11	CABLE, TBV
L47320P05	CABLE, 8TH STAGE BLEED VALVE
L47328P02-AR	VALVE, BLEED AIR, AS REMOVED
L47328P02-OH	VALVE, BLEED AIR, OVERHAULED
L47329P05	Valve, Bleed Air
L47329P05-OH	VALVE, BLEED AIR
L47330P04	Valve, Bleed Air
L47330P04-AR	Valve, Bleed Air
L47330P04-OH	VALVE, BLEED AIR
L47373P01	Thrust Balance Valve
L47400P02	Bushing
L47419P01	Spacer
L47419P02	Spacer
L47443P03	Thermocouple T5:4
L47444P03	Sensor, Temp
L47444P04	Sensor, Temp
L47444P05	Sensor, Temp
L47494P01	Seal
L47494P02	Seal, Retaining plate
L47494P03	Seal
L47618P01	ASSEMBLY: SEAL RING
L47618P02	PLATE, RETAINER
L47618P03	RING, SEAL
L47834P01	Seal
L47865P03	SPACER
L47865P04	SPACER
L47865P05	SPACER
L47865P06	SPACER
L47865P07	SPACER
L47865P08	SPACER
L47865P09	SPACER
L47865P10	SPACER
L47865P11	SPACER

Starfish PPS - Complete Catalog

Part Number	Description
L47865P12	SPACER
L47896P01	Bracket
L47914P01	Seal
L47914P03	Seal
L47932G01	ADAPTER, STRUT END
L47941G01	SPACER
L47963P01	PIN
L48119P01	Temperature Electrical Harness
L48120P02	CABLE
L48153P01	Hose
L49070P01	REDUCER TUBE
L49222P03	TUBE AND HOSE
L49237P03	TUBE AND HOSE
L49273P01	Hose
L49273P03	Hose
L49274P01	Fuel Secondary Hose
L49274P03	Fuel Secondary Hose
L49438P01	Orifice, Plate
L49438P02	Orifice, Plate
L49438P03	Orifice, Plate
L49438P04	Orifice, Plate
L49438P05	Orifice, Plate
L49438P06	Orifice, Plate
L49438P07	Orifice, Plate
L49438P08	Orifice, Plate
L49438P09	Orifice, Plate
L49438P10	Orifice, Plate
L49438P11	Orifice, Plate
L49438P12	Orifice, Plate
L49438P13	Orifice, Plate
L49438P14	Orifice, Plate
L49438P15	Orifice, Plate
L50030P01	SENSOR, P2/T2
L50521G07	Bracket, shaft, fwd
L50552G05	Bracket
L50554G01	Bracket
L50621P01	Strip
L50621P03	Strip
L50621P04	Strip
L50621P07	Strip
L50622P01	Bracket, Bearing
L50643G01	Washer, thrust
L50655P03	Sleeve
L50661P04	Bushing, Sleeve
L50666G07	BRACKET
L50667G04	Bracket, Bearing
L51151G02	Tube
L51230G01	HOSE, AIR / OIL
L51268P03	TUBE & HOSE, CONVOLUTED
L51269P03	Hose, Convaluted
L51270P03	Hose, Convaluted
L51328P06	Clamp, Bracket

Starfish PPS - Complete Catalog

Part Number	Description
L51392G01	Bracket
L51399P01	COUPLING
L52030G01	TUBE, WATER
L52032G01	air tube
L52044G01	Tube, Bleed Air
L52046P01	PLATE, ORIFICE
L52049P001	Plate, Orifice
L52114P01	BOLT, MACHINE DBL HEX
L52143G01	VALVE
L52150G01	Tee
L52173G01	Bracket
L52174G01	Bracket
L52175G01	Bracket
L52176G01	Tube
L52177P01	Orifice, Plate
L52177P02	Orifice, Plate
L52177P03	Orifice, Plate
L52177P04	Orifice, Plate
L52177P05	Orifice, Plate
L52177P06	Orifice, Plate
L52177P07	Orifice, Plate
L52177P08	Orifice, Plate
L52177P09	Orifice, Plate
L52177P10	Orifice, Plate
L52177P11	Orifice, Plate
L52177P12	Orifice, Plate
L52177P13	Orifice, Plate
L52177P14	Orifice, Plate
L52177P15	Orifice, Plate
L52216G01	Bracket
L52241G01	BRACKET
L52242G01	BRACKET
L52619P01	ORIFICE
L52619P02	ORIFICE
L52619P03	ORIFICE
L52619P04	ORIFICE
L52619P05	ORIFICE
L52619P06	ORIFICE
L52619P07	ORIFICE
L52619P08	ORIFICE
L52619P09	ORIFICE
L52804G01	TUBE, OIL SCAVENGE
L52806P01	Adapter
L52809P001A	Bracket
L52814G01	MANIFOLD
L52815G01	Manifold
L52840P01	ADAPTER, STRUT END
L53644P04	Washer
L54129P01	Hose, Fuel
L54129P02	Hose, Fuel
L54157P02	HOSE
L54659P01	Gasket

Starfish PPS - Complete Catalog

Part Number	Description
L56830G02	TURBINE REAR FRAME - THRUST CONE
L56833P01	BRACKET
L56926P02	SEAL,AIR,STRUT
L56941P01	Seal
L57187P01	GASKET
L57365P01	Chip Detector Harness
L57366P01	Wiring Harness
L57367P01	Wiring Harness
L57368P01	Wiring Harness
L57369P01	Wiring Harness
L57371P01	Wiring Harness
L57372P01	Wiring Harness
L57375P01	Harness, XNSD Speed
L57375P02	Harness, XNSD Speed
L57377P01	Wiring Harness
L57378P01	Wiring Harness
L57378P02	Wiring Harness
L57382P01	Wiring Harness
L57384P01	Probe, Pressure
L57386P01	T23/P23 SENSOR
L57386P03	T23/P23 SENSOR
L57387P02	Sensor, T3
L57389P01	Sensor, XNSD SP
L57390P06	Speed Sensor
L57390P07	Sensor, Speed
L57390P08	Sensor, Speed
L57391P01	Speed Sensor, XN25
L57392P01	Sensor, speed
L57395P01	PUMP, LUBE AND SCAVENGE
L57395P01-AR	PUMP, LUBE AND SCAVENGE, AS REMOVED
L57395P01-OH	PUMP, LUBE AND SCAVENGE, OVERHAULED
L57611P01	Speed Sensor
L57620P01	C Seal
L57907P01	Joint, Elastic
L57924P01	HOSE
L59002G01	Connector Bridge
L59016P01	HARNESS, ELECTRICAL
L59017P01	HARNESS, ELECTRICAL
L59017P02	CABLE
L59029P01	Bearing
L59031P01	Wiring Harness
L59032P01	Wiring Harness
L59033P01	HARNESS, LOWER, T48
L59034P01	Harness, TC
L59035	THERMOCOUPLE, T48
L59035P01	THERMOCOUPLE, T48
L59037P01	Gasket
L59039P01	P25/T25 Sensor Harness
L59039P02	P25/T25 Sensor Harness
L59041P01	P25/T25 Sensor Harness
L59041P02	P25/T25 Sensor Harness
L59053P01	Sensor, Speed

Starfish PPS - Complete Catalog

Part Number	Description
L59086P01	T3 Sensor
L59090P02	VALVE, BLEED AIR
L59090P02-AR	VALVE, BLEED AIR, AS REMOVED
L59090P02-OH	VALVE, BLEED AIR, OVERHAULED
L59091P04	Valve, Bleed Air
L59091P05	Valve, Bleed Air
L59092P03	Valve, Bleed Air
L59095P01	SENSOR, SPEED
L59096P03	Cable, Speed, Right
L59096P04	Cable, Speed, Left
L59341G01	Retainer, spring
L61119P01	Wiring Harness
L61120P01	Wiring Harness
L61140G01	TUBE
L61209P01	Wiring Harness
L61210P01	Wiring Harness
L61450P01	T23/P23 SENSOR
L61450P02	T23/P23 SENSOR
L61566G01	Tube, air
L61813G01	BAFFLE
L61839P02	Speed Sensor
L61842G02	VALVE, CHECK
L61843G01	TUBE
L61883P01	Spacer
L61917P01	Gasket
L61951P01	Pin
L62163P01	NOZZLE, FUEL, LIQUID / WATER
L62322G01	TUBE
L62381P01	Gasket
L62451G01	TUBE, D SUMP, IPT FRAME STRUT 9
L62629P01	SLV, SFT-FWD BRG
L62630P01	Bushing
L62631P01	BEARING, PLAIN, AFT MOUNT
L62634G01	BRACKET, BEARING TORQUE SHAFT, AFT
L62745G01	8th Stage Tube
L62762P01	GASKET
L62770P01	Shim
L62774P01	Check Valve
L62868P01	HOUSING, DRIVE SHAFT
L63392P01	HOSE, FUEL, GAS
L63397P01	SEAL RING
L63585P01	Exciter, Ignition
L63592P01	DAMPER
L63592P02	DAMPER
L63593P01	DAMPER
L63671P01	NOZZLE, FUEL 3-CUP DLE+
L63754P01	VALVE, STAGING
L63754P01-AR	VALVE, STAGING, AS REMOVED
L63754P01-OH	VALVE, STAGING
L63875P01	Clamp
L63957G01	BRACKET
L63965G06	ARM

Starfish PPS - Complete Catalog

Part Number	Description
L63985G01	BRACKET, HINGE
L63985G02	BRACKET, HINGE
L63985G03	Bracket
L65081P01	CLAMP
L70999P01	Support Assembly
LA-5-C-MA-FCFP	Flow Meter, linear link
LF16015	FILTER, WATER SEPERATOR
LG1093AA24	Scanner, Flame
LG1093AA25	Scanner, Flame
LG1093AA26	Scanner, Flame
LG1093AA36	Scanner, Flame
LG1093AA44	Flame Scanner
LG1093AA45	Flame Scanner
LG1093AA46	Scanner, Flame
LG1093AB01	FLAME SENSOR, UV
LG1093AC01	SENSOR, FLAME
LG1093AC05	Flame Sensor UV
LG1237CD04	PRESSURE TRANSDUCER
LIT777-P2	3 PHASE OLR/200-480V/2-800 FLA+
LITRS485MS-2W	COMMUNICATIONS MODULE
LM-5000-1200	FOD Sock
LM6000-NMO1200	FOD Sock
LN-5-C-MA-FCFP	METER, FLOW, LINEAR LINK
LPIN	Locking Pin, 1/8", 321SS
LR47190	Pump, Lube and Scavenge
LS1900-2-SP-CE	SWITCH, LEVEL
LU240	Probe, Level
LV471-03-05	Switch, Level
LW18440	Sensor, Speed RB211
LW19356	Probe, OH Temp
M029.AD-V-1-1-29-04	ADAPTER GLAND, 1/2 INCH MNPT-20MM FEMALE
M12X50MM	Pin
M13000208-0185	HOSE
M13000212-0110	Tube
M161-BT-CA1	Pump
M16X80MM	Pin
M18000104-0380	Hose Assembly
M19-67	Plug, Borescope
M22759/16-12	GROUND CABLE
M22759/16-12-9	GROUND CABLE
M22759/16-14	GROUND CABLE
M22759/16-4-5	GROUND CABLE
M22759/16-6-5	GROUND CABLE
M25988-3-110	O-RING
M25988/2-020	O-RING
M25988/2-120	O-RING
M25988/2-139	O-RING
M25988/2-218	O-RING
M25988/2-224	O-RING
M25X3/4	Flame Sensor Conduit Adapter
M270N6	Coupling Insert
M3425A	Beckwith Generator Protection Relay

Starfish PPS - Complete Catalog

Part Number	Description
M6706015	GASKET
M6709490	SCREEN, REPLACEMENT, 100 MESH
M6718132	Y-STRAINER
M6724139	Y STRAINER GASKET
M770H5	COUPLING INSERT, MAGNALOY
M83248/1-006	O Ring
M83248/1-008	O Ring
M83248/1-009	O Ring
M83248/1-010	O-Ring
M83248/1-012	O Ring
M83248/1-015	O Ring
M83248/1-016	O Ring
M83248/1-017	O-RING
M83248/1-018	O RING
M83248/1-019	O Ring
M83248/1-020	O Ring
M83248/1-021	O Ring
M83248/1-022	O Ring
M83248/1-023	O Ring
M83248/1-026	O Ring
M83248/1-028	O Ring
M83248/1-035	O Ring
M83248/1-036	O Ring
M83248/1-037	O Ring
M83248/1-042	O Ring
M83248/1-044	O-Ring
M83248/1-110	PACKING
M83248/1-114	O-RING
M83248/1-115	O Ring
M83248/1-117	O Ring
M83248/1-121	O Ring
M83248/1-122	O Ring
M83248/1-123	O-Ring
M83248/1-124	O-RING
M83248/1-125	O Ring
M83248/1-126	O Ring
M83248/1-129	O Ring
M83248/1-130	O Ring
M83248/1-132	O-RING
M83248/1-134	O Ring
M83248/1-135	O-RING
M83248/1-138	O Ring
M83248/1-139	O Ring
M83248/1-140	O Ring
M83248/1-145	O Ring
M83248/1-148	O Ring
M83248/1-150	PACKING
M83248/1-153	O-RING
M83248/1-160	O Ring
M83248/1-161	O Ring
M83248/1-163	O Ring
M83248/1-166	O Ring

Starfish PPS - Complete Catalog

Part Number	Description
M83248/1-175	O Ring
M83248/1-210	O Ring
M83248/1-213	O Ring
M83248/1-214	O Ring
M83248/1-216	O Ring
M83248/1-219	O Ring
M83248/1-220	O Ring
M83248/1-222	O Ring
M83248/1-224	O Ring
M83248/1-225	O Ring
M83248/1-228	O Ring
M83248/1-229	O Ring
M83248/1-230	O Ring
M83248/1-231	O-RING
M83248/1-234	O Ring
M83248/1-236	O-RING
M83248/1-238	O Ring
M83248/1-240	O Ring
M83248/1-241	O Ring
M83248/1-242	O-RING
M83248/1-243	O-RING
M83248/1-244	O RING
M83248/1-245	O Ring
M83248/1-247	O Ring
M83248/1-252	O Ring
M83248/1-255	O Ring
M83248/1-260	O Ring
M83248/1-262	O Ring
M83248/1-263	O Ring
M83248/1-264	O Ring
M83248/1-265	O Ring
M83248/1-266	O Ring
M83248/1-270	O Ring, V1000-270
M83248/1-278	O-RING
M83248/1-324	O Ring
M83248/1-341	O Ring
M83248/1-344	O-RING
M83248/1-390	O Ring
M83248/1-429	O Ring
M83248/1-433	O Ring
M83248/1-437	O Ring
M83248/1-444	O-RING
M83248/1-902	O-RING
M83248/1-903	O Ring
M83248/1-904	O-RING
M83248/1-905	O-RING
M83248/1-906	O Ring
M83248/1-908	O-RING
M83248/1-910	O Ring
M83248/1-912	O Ring
M83248/1-914	O Ring
M83248/1-916	O Ring

Starfish PPS - Complete Catalog

Part Number	Description
M83248/1-920	O Ring
M83248/1-975	O Ring
M83248/2-214	O-RING
M83248/2-219	O-RING
M83248/2-222	O-Ring
M83248/2-225	O-RING
M83248/2-228	O-RING
M83723/95G1005N	Cable, Electrical, Temp
M95H-3063-3371493	REGULATOR
MCD50	I/O Bus & power extension module
MCD51	I/O Bus & power extension module
MDD56-16N1B	DIODE PACK
METRIC BOLT	METRIC BOLT KIT, DO NOT DISCARD
METRIC BOLT, NEED FOR INSTALLATION	METRIC BOLT KIT, DO NOT DISCARD
MICSSEP0001	ASSEMBLY: MAVR MICRO AVR
MK102C616VVN3/4T6A	VALVE, SOLENOID
MK252C6100TTN11/2T6AY	VALVE, SOLENOID
MPU50	General controller/Communication controller/ACU
MPU50/51/52	General controller/Communication controller/ACU
MPU51	General controller/Communication controller/ACU
MPU52	General controller/Communication controller/ACU
MR105	NOx Water Pup Regulator
MR95L	REGULATOR, 3/4"
MS-T5544	Anti-Seize
MS122903	CLAMP
MS122907	Clamp, Loop
MS122909	Clamp, Loop
MS122926	CLAMP, LOOP
MS124662	INSERT, HELICOIL
MS124702	INSERT, HELICOIL
MS124741	INSERT, HELICOIL
MS124821	INSERT, HELICOIL
MS14103-5	BEARINGS
MS16555-682	PIN
MS16555-688	PIN
MS16555-689	PIN
MS16555-701	PIN
MS16555-702	PIN, STRAIGHT HEADLESS
MS20427F4-9	RIVET
MS20500-428	NUT, SILVER PLATED
MS20500-624	NUT, LOCK
MS20756-24	GASKET, FLANGE SEAL
MS21043-06	NUT
MS21043-3	NUT
MS21046C14	NUT, SS, ENGINE MOUNT
MS21046C4	NUT, 6 PT, SILVER PLATED
MS21046C5	Nut
MS21046C8	NUT
MS21060-4	NUT
MS21062-4	NUTPLATE
MS21076-4	NUTPLATE
MS21076L4N	NUT, SELF-LOCK

Starfish PPS - Complete Catalog

Part Number	Description
MS21083C4	Nut, SS Lock, 1/4
MS21083C5	Nut, SS Lock
MS21914-4J	FITTING
MS21914-5J	FITTING
MS24693-C272	SCREW
MS24693-C273	SCREW, MACHINE, FLATHEAD
MS24693-C342	SCREW
MS27196-12	Gasket
MS27196-16	Gasket
MS27196-20	Gasket
MS27196-24	Gasket
MS27196-32	Gasket
MS27196-40	Gasket, Seal-Flange
MS27196-48	Seal
MS29513-013	O-RING
MS3106F20-27S	Plug, free, 14 way
MS35275-215	Screw
MS35275-230	SCREW
MS35275-240	Screw
MS35307-414	BOLT, HEX SS
MS35649-2254	Nut
MS35842-12	Clamp Hose
MS35842-13	Clamp Hose
MS35842-14	Clamp, Hose
MS35842-15	Clamp Hose
MS51525B6S	FITTING
MS51830CA202	Insert
MS51830CA202L	INSERT
MS51831-201	INSERT
MS51832-202	INSERT
MS51914-6J	FITTING
MS9025-10	CLAMP
MS9025-20	CLAMP
MS9061-08	BCan Sleeve Bolts
MS9141-12	Gasket
MS9141-15	Gasket
MS9193-04	CONNECTOR
MS9197-12	NUT
MS9201-02	Nut
MS9201-03	Nut
MS9201-04	Nut
MS9202-042	Gasket, Metal
MS9204-151	Gasket
MS9209-16	BOLT
MS9217-05	BOLT
MS9218-12	BOLT, MACHINE
MS9276-10	Key Washer
MS9315-04	CAP
MS9315-10	CAP
MS9315-12	CAP
MS9321-09	Washer

Starfish PPS - Complete Catalog

Part Number	Description
MS9321-10	Washer
MS9321-12	WASHER
MS9371-15	Gasket
MS9371-16	GASKET
MS9372-029	Gasket
MS9373-020	SEAL RING
MS9373-021	SEAL RING
MS9373-023	SEAL RING
MS9373-029	Seal Ring
MS9373-035	Gasket
MS9373-041	Gasket
MS9373-045	GASKET
MS9373-055	Gasket
MS9373-061	GASKET
MS9375-035	Gasket, Ring
MS9375-038	Gasket, Ring
MS9375-047	Gasket, Ring
MS9375-071	GASKET, RING
MS9386-111	PACKING, PREFORM, O RING
MS9386-261	PACKING, PREFORM, O-RING
MS9388-210	O Ring
MS9388-219	Packing, O RING
MS9388-222	O Ring
MS9388-228	O Ring
MS9388-241	Packing - Preformed, Boss
MS9390-090	PIN
MS9404-04	Plug
MS9489-05	Bolt
MS9489-06	Bolt
MS9489-07	Bolt
MS9489-08	BOLT
MS9489-09	BOLT
MS9489-12	Bolt
MS9490-08	Bolt
MS9490-09	Bolt
MS9490-10	Bolt
MS9490-11	Bolt
MS9490-12	Bolt
MS9490-13	Bolt
MS9490-15	bolt
MS9490-16	Bolt
MS9490-17	Bolt
MS9490-18	Bolt
MS9490-20	BOLT
MS9490-21	Bolt
MS9490-22	BOLT, HEX
MS9490-23	BOLT, SS, 6 PT
MS9490-24	BOLT, SS, 6 PT
MS9490-26	BOLT, HEX
MS9491-13	BOLT
MS9491-15	Bolt
MS9491-18	Bolt

Starfish PPS - Complete Catalog

Part Number	Description
MS9491-20	Bolt
MS9491-22	BOLT
MS9491-24	BOLT
MS9501-07	Bolt
MS9501-12	Bolt
MS9501-17	Bolt
MS9556-04	Bolt, Machine DBL Hex
MS9556-07	BOLT
MS9556-09	BOLT, MACHINE
MS9556-10	Bolt, Machine DBL Hex
MS9556-14	BOLT, MACHINE
MS9557-06	BOLT
MS9557-07	Bolt, Machine DBL Hex
MS9557-08	Bolt, Machine DBL Hex
MS9557-09	BOLT, MACHINE, DBL HEX
MS9557-10	Bolt
MS9557-11	BOLT
MS9557-12	Bolt, Machine DBL Hex
MS9557-13	Bolt, Machine DBL Hex
MS9557-14	Bolt, Machine DBL Hex
MS9557-15	Bolt, Machine DBL Hex
MS9557-16	Bolt
MS9557-17	Bolt, Machine DBL Hex
MS9557-18	Bolt, Machine DBL Hex
MS9557-19	Bolt, Machine DBL Hex
MS9557-20	Bolt, Machine DBL Hex
MS9557-22	Bolt, Machine DBL Hex
MS9557-23	Bolt, Machine DBL Hex
MS9557-25	BOLT
MS9557-26	BOLT
MS9557-28	Bolt, Machine DBL Hex
MS9557-31	BOLT
MS9557-35	BOLT
MS9557-38AR	BOLT, AS REMOVED
MS9558-08	BOLT
MS9558-12	BOLT, MACHINE
MS9558-13	Bolt, Machine DBL Hex
MS9558-14	Bolt, Machine DBL Hex
MS9558-16	Bolt, Machine DBL Hex
MS9558-17	Bolt, Machine DBL Hex
MS9558-18	Bolt, Machine DBL Hex
MS9558-24	BOLT
MS9558-3	Bolt
MS9558-32	Bolt, Machine DBL Hex
MS9565-04	Bolt, Machine DBL Hex
MS9565-05	Bolt, Machine DBL Hex
MS9565-14	Bolt, Machine DBL Hex
MS9565-17	Bolt, Machine DBL Hex
MS9566-06	Bolt
MS9566-09	Bolt, Machine DBL Hex
MS9566-10	Bolt, Machine DBL Hex
MS9566-12	Bolt, Machine DBL Hex

Starfish PPS - Complete Catalog

Part Number	Description
MS9566-16	Bolt, Machine DBL Hex
MS9566-18	BOLT
MS9566-20	Bolt, Machine DBL Hex
MS9566-21	Bolt, Machine DBL Hex
MS9566-22	Bolt, Machine DBL Hex
MS9566-27	Bolt, Machine DBL Hex
MS9566-31	Bolt, Machine DBL Hex
MS9566-33	Bolt, Machine DBL Hex
MS9566-37	Bolt, Machine DBL Hex
MS9567-14	Bolt, Machine DBL Hex
MS9902-03	Plug, Borescope
MS9902-04	PLUG
MS9902-05	Plug, Borescope
MS9902-06	Plug
MS9902-08	PLUG
MS9902-10	PLUG
MS9953-05	PLUG
MS9966-06	Packing - Preformed, Boss
MS9966-07	Packing
MS9966-10	Packing, O RING
MS9966-16	Packing - Preformed
MS9967-036	O Ring
MS9967-116	Packing
MSM0004-AM	HOSE
MT100HP	Motor, TCF Aerovent
MT125HP	Motor, TCF Aerovent
MT125HP-OH	OVERHAULED Motor, TCF Aerovent
MTL728	DIODE, SHUNT
MTL728+	DIODE, SHUNT
MTL7729+	BARRIER, SHUNT-DIODE, SAFETY
MTL7796+	SHUNT DIODE, SAFETY
MVAJ053RA0802B	RELAY, TRIPPING, AREVA
Magnalloy200	Coupling
N14P35072	Screw
N173P2312	SCREW, SET
N213P00044	Nut
N227P00033	NUT
N22BP35036B	BOLT
N22P250012	SCREW
N271TP00039	NUT, 12 POINT
N271TP00050	Nut
N271TP39	Nut
N2720P00039	Nut
N272QP00039	NUT, LOCK
N272QP00044	Nut
N400BP11	WASHER
N400P41	washer
N402P18	Washer
N406P42	Washer, Lock
N500P1108	Pin
N5606P04003G11	Gasket
N58P21010	SCREW,MACHINE

Starfish PPS - Complete Catalog

Part Number	Description
N60CP44076	BOLT, LP INNER SHELL
N60HP33036	SCREW, HEX HEAD
N646P25020	SCREW,CAP
N733AP39048	Bolt
N733AP39144	BOLT, 12 POINT
N733AP50096	BOLT, 12 POINT
N733BP44104	BOLT
N733DP33028	BOLT
N733DP33036	BOLT
N733P39064	SCREW, 12 POINT
N733P39088	SCREW, 12 POINT
N733P50096	Bolt
N926BP329	Insert
NAS1102E3-8	SCREW
NAS1102E4-10	SCREW
NAS1149C0332R	Washer
NAS1149C0532R	WASHER
NAS1149C0632R	Washer
NAS1149C0832R	Washer; 1/2
NAS1149C1290R	Washer
NAS1291C8M	NUT
NE05023504NHXGE	AC
NE06023504NHXGE	AC, Panel
NE06023604EHAGE	AC, CABINET
NEXUS 1250-4	RTU, Power Quality, Revenue Meter
NMO-1200-LM6000	FOD Sock
O-RING-8.975IN-REP	Filter Head Gasket, Replacement
OFS-820X-12B	Filter, Fuel, Liquid
OFS-820X-3B	Filter, Liquid, 5uM
OFS820X12B	Filter, Fuel, Liquid
OFS820X3B	Filter, Liquid, 5uM
P-010-P4-IP	FILTER
P030648-016-190	HEPA Final Filter
P1202804001	FILTER, OIL
P13-2582	Fuse
P15-6458	Program Control
P16-5332	Hydraulic Filter
P16-5354	Hydraulic Filter
P16-5659	Filter, Element
P16-7183	FILTER, HYDRAULIC, CARTRIDGE
P16-7185	Hydraulic Filter, Jacking Oil Discharge
P162696	INDICATOR, FILTER (P16-2696)
P165332	Hydraulic Filter
P165354	Hydraulic Filter
P165659	Filter, Element
P165882	O Ring
P165965	INDICATOR
P167183	FILTER, HYDRAULIC, CARTRIDGE
P167185	Hydraulic Filter, Jacking Oil Discharge
P169985	Head, Dual Filter
P176567	Low Pressure Return & Case Drain Return Filter
P179075	Element, filter

Starfish PPS - Complete Catalog

Part Number	Description
P19-1129	Filter
P19-1469	Filter
P33Z70	Varistor
P553771	FILTER, LUBE
P564468	Element, filter
P566338	FILTER, VBV
P9B10VN	Block, Contact
PA-39946960	Pressure Transmitter
PA3000-500-48-13-21-00-93	Pressure Transmitter
PA3000-500-48-13-21-01-93	TRANSMITTER, PRESSURE
PA92146900	
PC-T400	Cable, Interface
PD1-A734-A2-R01	PUMP
PDFP1000A25V32P	Fuse
PDM4723	BOOT, INSUL
PDPS100M200P310	EMI Suppression Core
PDSB10A05P2RLCB	CIRCUIT BREAKER
PF1	SWITCH, DIGITAL NO FLOW
PH312	Filter Elements
PH312-01-CG	Filter Element
PH312-11-CG	Filter Element
PH404-12-CG	Filter
PH414-10-CG	Filter
PH414-12-CG	Filter
PH518-12-CG	FILTER, ELEMENT, 3 MICRON, GLO
PH718-03CN	Mineral Oil Filter
PH730-01-CG1VGE	Filter Element
PH739-11-CGV	Filter
PIRECLA1A1W1	Detector, Gas
PIRECLA4A2W1	PIRECL Infrared Hydrocarbon Gas Detector
PK-IS420ESWBH1A	Switch Kit
PK0027-00	AT10 Auxilary Relay Alarm Board
PLW375x156	Pantleg Washer, 0.375" x 1.5625"
PM1-5E1-XD3	HMI, BENTLY NEVADA
PM296	SATEC, POWER ANALYZER
PM6C3CA-AAAAP12	SWITCH, TEMPERATURE
POWLUBE-104	CHEMICAL,PETROLEUM BASED,LUBRICANT,POWLVAO KIT
PR440238	Ring
PRS09i-10T	Regulator, Sprint
PRS09i-20A	Regulator, Water
PS24-150	POWER SUPPLY; MARK VI
PS24-500DC-DC	POWER SUPPLY; MARK VI
PSX/006164F	Filter, Air, Gen 8
PTG5-1-110-SD03422F	Transformer
PTG5-1-110-SD03559F	TRANSFORMER
PTG5-110-SD03726-F	TRANSFORMER, VOLTAGE, BIL110kV
PTG5-2-110-1442FF	Transformer
PTP-2	HANGER, SPRING
PTW5-1-110-SD02552F	VOLTAGE TRANSFORMER 11000 VOLTS
PTX 611	4-20mA 600 psi abs. 9-30V dc
PTX59J2-150PSI	TRANSMITTER, PRESSURE

Starfish PPS - Complete Catalog

Part Number	Description
PTX59J2-2000PSI	TRANSMITTER, PRESSURE
PTX59J2-300PSI	TRANSMITTER, PRESSURE
PTX59J2-500PSI	TRANSMITTER, PRESSURE
PTX59J2-600PSI	TRANSMITTER, PRESSURE
PTX59J2-70PSI	TRANSMITTER, PRESSURE
PTX59J2-TD-A2-CA-HT-RP-300PSI	TRANSMITTER, PRESSURE
PTX59J2-TD-A2-CA-HT-RP-600PSI	TRANSMITTER, PRESSURE
PTX651-1000ABS	TRANSMITTER, PRESSURE
PTX651-300ABS	TRANSMITTER, PRESSURE
PTX651-500ABS	TRANSMITTER, PRESSURE
PTX651-600ABS	TRANSMITTER, PRESSURE
PTX651-700ABS	TRANSMITTER, PRESSURE
PTX651-70ABS	TRANSMITTER, PRESSURE
PW1772D32001	Ignitor
PW668B535001	SCANNER, FLAME
PWA85435-01	Power Terminal
PWT/120AC	WATT TRANSDUCER
PX780	UNION, ALUMINUM, 1/2"
Q468-5000	TRANSDUCER, VOLTS LM SERIES
Q478-0000	Signal conditioner
Q478-5002	Signal conditioner
Q478-5003	Signal conditioner
Q478-5004	Signal conditioner
Q501-2B00	2 Channel, 4/20 mA I
QU3	QUICK EXHAUST VALVE, 3/8" VITON SEALS
QX2GE02SRA	Fire System CO2 Block Limit Switch
QX2HE02SRA	Fire System CO2 Block Limit Switch
R1394P026	BOLT
R287P04	FITTING
R287P04L	FITTING
R287P06	FITTING
R287P08L	Fitting
R287P10	FITTING
R287P12	Fitting
R287P12L	NIPPLE
R289P06	ELBOW, TUBE
R289P10	Fitting
R291P06L	Fitting
R291P08L	Fitting
R294P04	FITTING
R297P04	WIRE, NONELECTRICAL, STEEL CRES ALY
R304P2A	Gasket
R306ET22BA11	In-Line Manifold
R413937	NUT
R413P02	Nut
R413P33	NUT
R413P41	Nut
R417P1	Nut
R4425-V90	O RING
R5077B090B	Hose, Assembly, Oil
R5077B100B	HOSE
R5078B172B	HOSE

Starfish PPS - Complete Catalog

Part Number	Description
R584P18U	BOLT, MACHINE, DBL HEX HD, 0.250-28 BY 1.312
R6W02033VO	Diode
R6W12033VO	Diode
R8900-F	SEAL, FILTER HOUSING, O RING
R902073462	Starter Motor
R909441692	Solenoid 24V
R928006646	Filter Element
R928010115	FILTER
R928046571	FILTER
RAO20093	Bently Nevada Interface Module
RAO20139	Driver
RAO21076	Woodward Driver
RAO21076-AR	WOODWARD DRIVER
RC778NZ097Z	DP INDICATOR, VISUAL, 100PSID
RC861CZ097H	SWITCH
RC861CZ097Z	SWITCH
RCBX12-21	AC Unit
RCBX36-21	AC Unit
RCN-2007A	PUMP, JACKING,
RCN-2029	Pump, Jacking Oil
RCN1970	Pump, Jacking Oil
RCN1970-AR	PUMP, JACKING OIL
RCN1970-OH	Pump, Jacking Oil
RCN1970A	Pump, Jacking Oil
RCN1970B	Pump, Jacking Oil
RCN2007A	PUMP, JACKING,
RCN2029	Pump, Jacking Oil
RCO260394301	Filter
RCO263580282	FILTER, SYNTHETIC OIL, MAIN
RCO369481121	Oil Filter
RCO39719	CABLE, STAGING VALVE
RCO39720	CABLE, STAGING VALVE
RCO39721	CABLE, TVBV/VSV/IGVO
RCO39722	CABLE, IGV/LVDT, LEFT
RCO39723	CABLE, IGV/LVDT, LEFT
RCO39724	CABLE, XN25
RCO39725	CABLE, CHIP DETECTOR, A/B
RCO39726	CABLE, VBV/VSV/VDT, LEFT
RCO39727	Cable
RCO39728	Cable
RCO39729	CABLE, VBV/VSV/LVDT, RIGHT
RCO39730	CABLE, STAGING VALVE
RCO39731	Cable
RCO39732	CABLE, T/C T48, RIGHT
RCO39733	CABLE, T/C T48, LEFT
RCO39734	CABLE, CDP, 16TH STAGE BLEED VALVE
RCO39735	CABLE, 8TH STAGING BLEED VALVE
RCO39736	Cable
RCO39737	CABLE, STAGING VALVE, GAS SWITCH
RCO39738	CABLE, TEMP, LUBE & SCAVENGE, SUPPLY
RCO39740	Cable
RCO39742	Cable

Starfish PPS - Complete Catalog

Part Number	Description
RCO39743	CABLE, CHIP DETECTOR, C/D/E/COMM
RCO39757	Cable
RCO39758	Cable
RCO39759	Cable
RCO39760	Cable
RCO39762	Cable
RCO39764	Cable
RCO39765	Cable
RCO39766	Cable
RCO39767	Cable
RCO39768	Cable
RCO39770	Cable
RCO39771	Cable
RCO39773	Cable
RCO39774	Cable
RCO39781	Cable
RCO39782	Cable
RCO39783	Cable
RCO43926	Cable
RCO43932	Cable
RCO43933	Cable
RCO43946	Cable
RCO43948	Cable, Dual RTD/VSV/LVDT
RCO43949	Cable, Chip Detector
RCO43950	CABLE
RCO43953	Cable
RCO43954	Cable
RCO43994	Cable
RCO43995	Cable
RCO47369	Cable
RCO47447	CABLE
RCO50665	Cable
RCO5300875	Cable, PT Speed NPT
RCO84224	Cable, NGG1 GG Speed
RCO85220	Cable
RDM312-SP-2DC	MODULE, DISPLAY, SATEC
RDQ17466	Nut
RE0016-05	Breaker
RG34155-6 Romec	Lube & Scavenge Pump
RH1-TP/FL	Hub, Ethernet, Rail
RH4B-U-DC-24V	RELAY, 24VDC COIL, 4PDT
RJO04208	PROBE, VIBRATION, REVERSE MOUNT
RJO04247	VIB PROBE
RJO04249	PT KP PROBE
RJO04868	SENSOR, SPEED, PT
RJO05385	PT KP PROBE
RJO06015	Clutch
RJO06015-AR	CLUTCH; AS REMOVED
RJO06017	Clutch
RJO5385	PROBE, KEYPHASER
RK5334	
RLO01267	GSOV, Woodward

Starfish PPS - Complete Catalog

Part Number	Description
RM2000GE-MODBUS	RELAY, PROTECTION, REMOTE MONITOR
ROHA S-375	Pump, High Press
RP0019-09	CAP,ELEC,75V,37000UF,2.5-IN
RPGCCWN-3800PSI-ZBW	VALVE, RELIEF
RPM074	Meter, Remote Power
RPQ54103	Stud
RPS12V	POWER SUPPLY
RR-56082	SENSOR, FLAME
RR0633961311	Detector
RR35230	PUMP, LUBE AND SCAVENGE
RRO00148	Flame Sensor
RRO00149	FLAME TRACKER
RRO00345	FLAME TRACKER
RRO56082	SENSOR, FLAME
RS-E2-0285P011	CABLE, UV FLAME DETECTOR
RS-E2-285	CABLE, UV FLAME DETECTOR
RS-FS-9001	Flame Sensor
RS-FS-9004	FLAME TRACKER
RS-FS-9006	Flame Sensor
RS-FS-9009	FLAME TRACKER
RS-FS-9009-03	FLAME TRACKER
RS-FS-9100	FT LITE
RS2-4TX	SWITCH, RAIL
RS2-4TX/1FX	SWITCH, RAIL
RSM RKC 5711-3M	CABLE, TURCK
RT00028	QUICK COUPLING
RT00029	QUICK COUPLING, NIPP
RTO02703	Temp Element
RVO237735210	Woodward GS6 valve
RVO518360000	GSOV, Woodward
RVO518360500	GSOV
RVO518361000	GSOV, Woodward
RVO90440	Valve, Fuel
Repair-Kit,2in,85-150200-000,WST-FS	Repair Kit
Repair-Kit,3in,85-170200-000,WST-FS	Repair Kit
S017651202	Grease, Coupling, Brush
S018713133	Compound, Sealing
S018757126	Detector, Temp
S024371603	Adaptor
S025281528	Heater
S025281572	Heator, Stator
S025281852	Heater, Exciter, Set of 2
S025711425	Fuse, Brush
S025711428	FUSE Brush
S02577502	PROTECTION UNIT
S028239088	Diode
S028239089	Diode
S029812762	THERMOCOUPLE, BRUSH
S132774704	Fuse
S187111115	Non-Setting Gasket and Jointing Compound
S2A	LVDT Signal Conditioner
S311722702	Weight, Balance, Generator

Starfish PPS - Complete Catalog

Part Number	Description
S311735202	Key, Machine
S312402403	PLATE, FUSE LOCKING
S312402408	PLATE, FUSE LOCKING
S312402409	PLATE, FUSE LOCKING
S3124245501	RTD
S312986501	DIODE WHEEL
S313033201	Temp Detector
S313174401	DIODE
S313174501	FUSE, 250V, 1000A
S313223712	Hose Assembly
S313223713	Hose, BRUSH
S313223714	Hose, BRUSH
S313223717	Hose, BRUSH
S313223719	Hose, Brush
S313223720	HOSE
S313223721	Hose
S313240102	Temp Detector
S313273905	HOSE, LUBE BRUSH
S313535601	GASKET,BEARING,(SET OF 2)
S313568201	VALVE, NON RETURN
S313825201	Gen Lube Pump
S313925005	BRACKET, MOUNTING POST
S313925701	ASSEMBLY: BRUSH HOLDER
S313941901	HOSE, LUBE BRUSH
S314011101	GASKET,BEARING,(SET OF 2)
S314023404	Hose, Lube
S314023412	HOSE
S314023414	Hose, Lubrication
S314081801	RTD, Dual
S314089901	Lube Pump
S314096901	ADAPTER
S314097101	Seal, bonded
S314149411	SEAL, OUTBOARD
S314149412	SEAL, INBOARD
S314149413	Shaft Seal, DE, OB
S314149414	Seal, IB
S314245501	TEMPERATURE DETECTOR - DUPLEX
S314263801	Coupling, GLO
S314263801-ALT	Coupling, Brush, Mech Lube Pump
S314263801-ALT-BLoad	GLO Lube Pump Coupling Flex Element
S314415402	Heater (Stator)
S314428801	Fuse
S314513901	WEIGHT, BALANCE, ROTOR
S314712001	PLATE
S315236618	KIT, Bearing Feed Inlet
S317436001	Stator Gasket Set
S317520801	DETECTOR, TEMP
S317520809	Temperature detector
S317638301	Gasket (set of 2)
S317658401	INSULATOR, BUSHING
S317684302	BEARING, BUSHING, COMPLETE, INSULATED
S317684402	BEARING, BUSHING, COMPLETE, INSULATED

Starfish PPS - Complete Catalog

Part Number	Description
S317695902	Temp Detector
S317696801	Seal, Brush, NDE, Outer
S317734800	Seal, Brush Bearing, DE
S317734900	Seal, Brush Bearing, NDE
S317741201	KIT: RECTIFIER, INDUSTRIAL, SPARES
S317779401	HOSE
S3178447-1	LVDT
S317929001	BUSHING, BEARING
S317931101	Bearing, Brush
S317946701	Gen Lube Pump
S317947301	Coupling, GLO
S317947301-ALT	Coupling, Brush, Mech Lube Pump
S317947301-ALT Element	GLO Lube Pump Coupling Flex Element (NOT AVAILABLE)
S317947301-ALT-BLoad	GLO Lube Pump Coupling Flex Element
S317947301-ALT-BLoad Element	FELX ELEMENT FOR BASELOAD ALTERNATE COUPLING
S317947301-ELEMENT	COUPLING, ALT-ELEMENT
S317978707	Filter, Air
S317987076	Power Supply
S317988102	Heater
S318347607	ASSEMBLY: BRUSH, EARTHING
S318347608	ASSEMBLY: BRUSH, EARTHING
S318347698	Gasket
S318761855	Switch, Float
S318930017	Make-Up Air Filter, Generator
S318992501	PLATE, LOCKING, SET OF 20
S319875101	FILTER, AIR, SET OF 2
S320965901	Kit, Rectifier Spares
S321371301	KIT, RADIAL JACKING OIL
S321400001	KIT, AXIAL OIL JACKING HOSE
S500-1-R	Fuse 1 A
S500-100-R	Fuse 100 mA
S500-2-R	Fuse 2 A
S500-250-R	Fuse 250 mA
S500-5-R	Fuse 5 A
S598931983Z	VALVE, SOL, BLEED AIR, REPLACEMENT
S701765801	Lube Pump, Counterclockwise
S701849400	Coupling, Replacement
S701849401	Coupling, Replacement
S701849500	Coupling, Replacement
S701849501	Coupling, Replacement
S704012801	DETECTOR, AERIAL, ROTOR, EARTH FAULT
S7131A116208U	Immersion Heater
S840012001	BRUSH, CARBON
S840012101	BRUSH HOLDER AND CLAMP
S840013102	Temperature Detector
S840013202	Temperature Detector
S840013210	Temp Sensor
S840014402	Temp Detector
S840019502	Transducer, Proximity
S840019503	Transducer, Proximity
S959200700	Handbook for (R10) REFM
S959202000	Handbook for A30

Starfish PPS - Complete Catalog

Part Number	Description
S960293300	MAVR Auto Power Card
S960294300	MAVR Power Factor Control Card
S960294700	MAVR Voltage Monitor Card
S960708700	Electronic Hand Control Card
S9608470	Excitation Limiter
S960847000	Excitation Limiter
S960848800	MAVR Excitation Monitor Card
S961159200	MAVR Control Card
S961502100	TRANSMITTER, ROTOR, EARTH FAULT
S961503300	RECEIVER, FAULT, ROTOR EARTH, R10
S961503700	AERIAL, ROTOR, EARTH FAULT
S961517500	MAVR Exitation Limiter Card Type B
S961529800	Card, MAVR, A30 Utilities
S961752200	A30 - BPL
S961755400	A30 Extender Card
S962243100	CARD, MAVR MAIN CONTROL
S962243400	Card, A30/Micro AVR Standby
S962243700	CARD, MAVR A30/MONITOR
S962425300	Card, MAVR, A30 Auxillaries
S962602800	Rack Chasis
S962608900	A30 Con Complete
S962609000	A30 Mon Complete
S962609700	Cable, Com Cab
S962609800	AVR HMI Software
S962609900	C10 Low Speed Detector
S962615908	Fuse, Semiconductor
S962615909	Fuse 5 A
S962615912	Fuse 250 mA
S962615913	Fuse 1 A
S962615914	Fuse 100 mA
S962615921	DIODE PACK
S962615922	THYRISTOR
S962615926	Motorised Pot Drive Unit
S962615936	Fuse 2 A
S963001810	TRANSFORMER
S963047300	Receiver assembly
S963091001	R10 RECEIVER, ROTOR, EARTH FAULT
S963097600	FUSE, 80000 AMP
S963100901	A30 AVR System
S963150501	C10 Low Speed Detector
S963191901	PRISMIC, MODEL R10, FIELD GROUND DETECTOR, EA
S963192001	PRISMIC, MODEL R10, FIELD GROUND DETECTOR
S963194001	T10 POWER SYSTEM STABILIZER
S963243101	PRISMIC, MODEL R10, FIELD GROUND DETECTOR, EA
S963303001	R10 ROTOR EARTH FAULT MONITOR
S963343201	A30 Con Complete
S963359201	Standby
S963416101	A30 Standby Card
S965011504	R10 RECEIVER, ROTOR, EARTH FAULT
S965011515	Receiver assembly
S965011518	REFM Receiver
S965011518	Ethos - list is \$10K REFM Receiver

Starfish PPS - Complete Catalog

Part Number	Description
SB0006A	KIT, COUPLING
SCM7B34-1582	RTD Input
SCM7B34-1583	RTD, 200 OHM
SCM7B47K-1509	INPUT, TC, TYPE K
SCM7B47K-1574	Converter - Isolated Linearized
SCM7BPT-1460	Converter - Non-Isolated Pass Through
SE-O-HF64-V	O Ring
SE-SW5U-SC	SWITCH, ETHERNET
SECO77-4/14	KIT, SEAL, COPPER
SELA36AI007	Breaker, Motor Control
SER1-03-10-0001	FOD SOCK
SF02002CF-316SS	Coalescer Panel, inlet
SF1530PVW4-X25-140	Thermostatic Valve
SF1530PVW4-X53-140	VALVE, THERMO, CONTROL
SGH2-00200	ISGH FILTER
SHIMS	Shims
SLX-10MG-1	Ethernet ring switch
SLX-18MG-1	Switch, Ring, Ethernet
SLX-6ES-4SC	Switch, Ring, Ethernet
SLX-6RS-4SC	SWITCH, ETHERNET, 6 PORT
SLX-6RS-4ST-D1	ETHERNET RING SWITCH, 4-10/100
SLX-8MS-4SC	Switch, Ethernet, 8 Port
SLX-9ES-2SC	Switch, Ring, Ethernet
SLX-9ES-2ST	SWITCH, ETHERNET
SMO0411347	INNER/OUTER TIP ASSEMBLY
SMO1610219	VALVE, STAGING
SMQ25654	Bushing
SN7S/002268F	Filter, Inlet
SNGF/000230F	Filter, Inlet
SPASI23	ANALOG INPUT MODULE ABB SYMPHONY PLUS
SPFEC12	MODULE, INPUT
SPS917-2	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
SPXCDXSO1SS	SENSOR, OXYGEN
SR-9631G001	RTD, Dual
SR1H-4A3EM-6-6C6-GF66C	RTD Assembly
SR71225-OH	KIT, COUPLING OVERHAUL
SRD08-00002	IGBT DF200R12KE3 VSR100 / VSR175
SRD08-00003	IGBT FD200R12KE3 VSR100 / VSR175
SRD09-00002	CAPACITOR .47UF 1200V for VSR100 / VSR175
SRD09-00031	CAPACITOR 3300UF 400V VSR100 / VSR175
SS-1610-2-16	ADAPTER, 90
SS-1610-F16-150	Adapter/Flange
SS-25MO-1-16BM	Swagelock 1
SS-2F-K4-2	FILTER, ELEMENT
SST7200	SWITCH, SPEED, DIGITAL
ST1050-016	O Ring
ST1540-06	Clamp
ST1540-10	Clamp
ST1946-010	Oring
ST1946-136	O-RING
ST2283-113	PACKING, PREFORM

Starfish PPS - Complete Catalog

Part Number	Description
ST2283-121	PACKING, PREFORM
ST260SHEX	Basket, Strainer
ST260Z6B	SEAL, STRAINER LID, EATON
STB1A2MW	QUAD-BOX, TERMINAL
STB2A2NW	BOX, JUNCTION, QUAD
STS-2015-PST	Innova HMI LM 6000 MARK VI
STS-2015-PTC	Innova HMI LM 6000 MARK VI
STS-2015-PTC-SSGE	Innova HMI LM 6000 MARK VI
SV209N11T/A	PUMP
SWAGELOK-316LOF	
Stands, LM6000	LM6000 Universal work stand, 2 Trunnion pedestals and 2 with attaching brackets
Switch, Ring, Ethernet	Switch, Ring, Ethernet
T24B734G01	SEAL, BEARING
T401	CURRENT OUTPUT & RELAY
T501.10	POWER SUPPLY
T6CM-B10-1R01-C1	PH VANE PUMP
T6CMB101R01C5	PH VANE PUMP
T6CY-017	PUMP, HYDRAULIC
TA4T6SL411	SOLENOID, 24V
TBVO BOLT KIT	KIT: HARDWARE, TBV ORIFICE
TCCS-10LM6-16-NF	NOZZLE, WATER
TEY230	BREAKER, CIRCUIT, 30 AMP
TH-1000-16F0-25	Valve, Thermostatic
THQL1130	BREAKER, 30 AMP GE PLUG IN
THREEBOND 1215	ADHESIVE, LIQUID GASKET
TM-900027	Filter Element
TM-900052	FILTER, ELEMENT
TME-S-200-CC10-V	Filter, Element, Sprint
TMR-S-00700-XHT-API-SS10-B	Filter Element
TMR-S-0663-API-PF010-V	Water Injection Pump Discharge Filter
TMR-S-620-CC10V	Filter, Element
TMR-S-710-H-CC3-V	DUPLEX, GAS, FUEL, 3" 3um
TMR-S-710-HCC3-V	DUPLEX, GAS, FUEL, 3" 3um
TMR-S-860-D-UPG-F	FILTER CARTRIDGE
TMR-S200-CC10V	Filter, Element, Sprint
TMR-S320-A-CC25-V	Filter, H2O Injection Skid
TMR-S320-A-GF-010V	Filter, H2O Injection Skid
TMR-S320-A-GF-020V	Filter, H2O Injection Skid
TMR-Z-320-A-GF006-V	Filter
TMR-Z320-GF006V	Filter
TR150R	FUSE
TRF BOLT KIT	KIT, BOLT, TRF TO EXHAUST DIFFUSER
TRM2	FUSE, 2A
TRM5	FUSE, 5A
TRN16282	Thermocouple
TRN16283	Thermocouple
TRN16284	Thermocouple
TRN17444	Thermocouple
TRS3R	FUSE, 3A
TRS6R	FUSE, 6A
TSU151	GENERATOR, SIGNAL, PRECISION

Starfish PPS - Complete Catalog

Part Number	Description
TT285N12KOF	Thyristor Module
TURKISH SURPLUS	8MM, 150GR
TURKISH SURPLUS BULLETS	8MM, 150GR
TZ1032GK100-8	Jeumont Honsburg Flow Meter
Thyro-Tool Family / Pro Version	Software for Thyro-Tool Family
U-51111	Cable, Turck
U252J085G0072	THERMOCOUPLE
U252K088U0026	THERMOCOUPLE
U252K088U0030	Thermocouple
U252K095U0016	Thermocouple
U336W062D0462	GASKET, ., VALVE,CAP, 4-5/8"1D X 5-7/8"OD, METAL, ROU S1NGLE
U336WI00DI756	GASKET, ., LOWER HD, 17-9/16"ID X 19-9/16"OD, METAL THK, SINGLE
U3HSSVT.125SS	Check Valve
U3HSSVT.500SS	Valve, check
U408A306L0262	PIN
U408A306L0438	Pin
U408A308L0437	Pin
U408A408L0162	Pin
U606P321L2125	STUD
U606P816L1190	Stud
U607P321L2075	Stud
U613P211	NUT, STEAM TURBINE
U613X000P0112	1.5" , 8 Hex Nut
U614X000P0214	NUT, TURBINE, COVERED, 1-3/4" DIA, 2-1/4 CHROME, 8
U615X000P0418	Nut
U623P208L0550	Bolt
U623P210L0637	Bolt
U623P307L0275	BOLT, VALVE COVER
U623P310L0375	BOLT, GUIDE
U624P208L0850	BOLT
U624P308L0238	BOLT, SOCKET HEAD
U624P308L0325	Bolt
U624P308L0338	SCREW
U624P308L0375	BOLT, ., 1" DIA, 3-3/4" LTH, 8UN, STEEL, SOCKET HD, TU
U624P310L0800	BOLT, HEX SOCKET HEAD
U627P308L0362	Bolt
U627P311L0400	BOLT, HEX HEAD
U810P306L0175	SCREW, CHAMBER
UA-1474-01	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
UA-1480-01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
UA-1481-01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
UA-1482-03	CABLE, SPEED, GAS GENERATOR
UA-1482-04	CABLE, SPEED, GAS GENERATOR
UA-1486-01	CABLE, ELECTRICAL, VBV/VSV/LVDT
UA-1492-04	CABLE, VBV/VSV/IGV
UA-1493-04	CABLE, MANIFOLD TEMPERATURE
UA-1494-04	CABLE, CHIP DETECTOR, A/B
UA-1496-04	CABLE, TEMP LUBE & SCAVENGE
UA-1497-04	CABLE, TEMP LUBE RTD, D&E SUMPS
UA-1498-04	CABLE, XN25 SPEED
UA-1499-03	CABLE, XNSD SPEED

Part Number	Description
UA-1502-03	CABLE, EGT THERMOCOUPLE, LOWER
UA-1518-04	CABLE, TEMP COMPRESSOR DISCHARGE, T3
UA-1559-01	CABLE, CHIP DETECTOR, A/B/COM
UA-1561-01	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT
UA-1577-04	CABLE, CRF ACCELEROMETER
UA-1802-01	CABLE, LPT, SPEED
UA-1802-02	CABLE, LPT, SPEED
UA-2267-03	Cable, Speed, Right
UA-2267-04	Cable, Speed, Left
UD10A5M28W2C	DISPLAY, DCU
UD10A5N28W2	Transmitter, DCU
UD10A5N28W2C	DISPLAY, DCU
UD10S5M25W2N	DISPLAY, RELAY
UN-3-100-SS-V-1/2	Valve, check
UN-3-100-SS-V-1/8	Check Valve
UR319CD32++20ZE1YT33	FILTER HOUSING
UR319CD3220ZE1YT33	FILTER HOUSING
USB-100-BST	USB adapter
V	Relief Valve
V1000-161	O Ring
V1000-243	O-RING
V1000-441	O-Ring
V1000-5X91	O-RING, GLO FILTER HOUSING
V1000-904	O-RING
V1000-905	O-RING
V1000-908	O-RING
V1007-214	O-RING
V1007-219	O-RING
V1007-222	O-Ring
V1007-225	O-RING
V1007-228	O-RING
V1028-114	O-RING
V12F12-SS	QUICK COUPLING, NIPP
V6EPB-S-S-3-S	Flow Switch
VAA-3321-316-33E-C471-D024	Solenoid Valve
VI-2W3-CV	VICOR, DC CONVERTER
VI-LC14-EU-H1	VICOR, DC
VI-LCW3-IY	VICOR, DC
VL1073GE13-12	Gasket
VL1073GE13-16	Gasket
VL1073GE13-20	Gasket
VL1073GE13-24	Gasket
VL1073GE13-28	Gasket, Seal-Flange
VL1074GE14	Gasket, Seal-Flange
VL1175GE25-05	E seal
VL1175GE25-08	Metal Gasket Ring, E Seal
VL1175GE25-10	Metal Gasket Ring, E Seal
VL1175GE25-12	Metal Gasket Ring, E Seal
VL1181GE25-17	Metal Gasket Ring, E Seal
VL1181GE25-24	Gasket, Liquid Fuel Mix Block
VL1222GE27	Gasket

Starfish PPS - Complete Catalog

Part Number	Description
VMK252C6100TTS1246BVBG1P1A	Valve, drain
VQCT118072-11	Filter
VQCT118072-18	Filter
VR1006-350	Clamp, Coupling
VR1006-400	Clamp
VR1006-450	Clamp
VSR175-S484	Pump, VFD
VSR175-S484-AR	Pump Assembly
VSVF502C440TTA246BVXG1G1	VALVE, BLOCK, 2-WAY, COAX
VSVF503C440TTA246BVXG1G1	Valve, 3 way
W24NT1200	POWER SUPPLY, 240VDC TO 24VDC
W6268349003	Filter Assembly
W8000-20-W	Filter Regulator
WA47124	O-RING, SET
WA83802	O-Ring
WD5000AAKX	HARD DRIVE, MARK VI
WF6560	Manual Pull
WFC02PS	SWITCH, HORN
WFEFDC281KHA	SWITCH, HORN
WK251821	CO2 Hose
WK803370	Nozzle, Size 5
WK803377	Nozzle, Size 8+
WK803378	Nozzle, Size 9
WK803379	Nozzle, Size 9+
WK803380	Nozzle, Size 10
WK803381	Nozzle, Size 2
WK872450	Plain Nut Discharge Head
X0003HXX0AX0077X	PLUG, SQUARE HEAD
X0003HXX0AX007X	Plug, Forged
X3301A4N11W1	DETECTOR, FLAME
X3301S4M23T1	DETECTOR, FLAME
X54-600-1-2-2-DA	POWER SUPPLY
X9800A4N11W1	Flame Sensor
X9800A4N14W1	SENSOR, FLAME
XA4AA	Kit, Diaphragm
XL31K5PA7	TRANSDUCER, ELECTRONIC WATT
XREF0155	Vibration Element
XREF0203	Sensor, Temp
XREF0212	Transmitter
XREF0220	VALVE, SOL
XREF0316	Filter, Element, Sprint
XREF75	RTD
YF105-NNNA3A-S3S3-E/FMF/SCT	Yokogawa Flow Meter
YFC150	Filter
YS81-SS-1/2	Y-STRAINER
YS81-SS-1/2"-GASKET	GASKET, Y-STRAINER
YS81S0050	Y-STRAINER
YS81S0050MP	Magnetic Plug
Z1028-113	PACKING, PREFORM
Z1028-121	PACKING, PREFORM
Z1352-113	PACKING, PREFORM
Z1352-121	PACKING, PREFORM

Part Number	Description
Z8670	Seal Kit
ZB2 BJ3	Selector Switch
ZOK 27	TURBINE COMPRESSOR WASH
iMOD096V083A23-02A	CAPACITOR